


TOSHIBA

FILE NO. 110-9807

3

SERVICE MANUAL

VIDEO CASSETTE RECORDER **V-858B**



CONTENTS

SECTION 1 GENERAL DESCRIPTIONS

OPERATING INSTRUCTIONS	1-1 to 1-18
------------------------------	-------------

SECTION 2 ADJUSTMENT PROCEDURES

1. MECHANICAL ADJUSTMENT	2-1	2. ELECTRICAL ADJUSTMENT	2-43
1-1. Mechanical Parts Location	2-1	2-1. Servo Circuit	2-45
1-2. Servicing Jig List	2-2	2-2. Self Diagnosis Function	2-47
1-3. Main Parts Servicing Time	2-3	2-3. 3DNR Module Troubleshooting Flow Chart	2-48
1-4. V3 Mechanism Check Method	2-4		
1-5. Mechanical Deck Removal and Mounting	2-7		
1-6. Main Parts Replacement	2-9		
1-7. Check and Adjustment	2-34		


SECTION 3 SERVICING DIAGRAMS

1. INSPECTION PROCEDURE	3-1	7-6. Conventional Audio Block Diagram	3-23
2. REMOVAL OF CABINET	3-2	7-7. Hi-Fi Audio Block Diagram	3-26
3. ELECTRICAL UNITS LOCATION DIAGRAM	3-2	8. CIRCUIT DIAGRAMS	3-30
4. STANDING PC BOARDS FOR SERVICING	3-2	8-1. Power Circuit Diagram	3-30
5. PART SYMBOLS	3-3	8-2. PIF Circuit Diagram	3-33
5-1. Precautions for Part Replacement	3-3	8-3. KDB Circuit Diagram	3-36
5-2. Solid Resistor Indication	3-3	8-4. Servo/Logic Circuit Diagram	3-39
5-3. Capacitance Indication	3-3	8-5. Video Circuit Diagram	3-44
5-4. Inductor Indication	3-4	8-6. Conventional Audio Circuit Diagram	3-48
5-5. Waveform and voltage Measurement	3-4	8-7. 3DNR Circuit Diagram	3-51
6. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM	3-5	8-8. Terminal/Audio Circuit Diagram	3-53
7. BLOCK DIAGRAMS	3-7	9. PC BOARDS	3-56
7-1. Power Block Diagram	3-7	9-1. Main PC Board	3-56
7-2. PIF Block Diagram	3-8	9-2. Terminal/Audio PC Board	3-59
7-3. KDB Block Diagram	3-9	9-3. FCB PC Board	3-60
7-4. Servo/Logic Block Diagram	3-13	9-4. JSB PC Board	3-60
7-5. Video Block Diagram	3-20	9-5. KDB PC Board	3-61
		9-6. 3DNR PC Board	3-61

SECTION 4 PARTS LIST

1. SAFETY PRECAUTION	4-1	4. EXPLODED VIEWS	4-2
2. NOTICE	4-1	4-1. Packing Assembly	4-2
3. ABBREVIATIONS	4-1	4-2. Remote Control Unit	4-2
3-1. Integrated Circuit (IC)	4-1	4-3. Cabinet Assembly	4-2
3-2. Capacitor (Cap)	4-1	4-4. Chassis Assembly	4-3
3-3. Resistor (Res)	4-1	4-5. Mechanism Assembly (1)	4-4
		4-6. Mechanism Assembly (2)	4-5
		5. PARTS LIST	4-6


Front Panel




LINE IN 2 (Front) jacks
If the connected equipment is monaural (has one audio output jack), connect the L (MONO) side, the same sound is recorded on both L and R on the Hi-Fi track.

- A REC (Record) button
- B CHANNEL buttons
- C DNR switch
- D ONSTANDBY button
- E Cassette compartment
- F PAUSE/STILL button
- G PLAY button
- H MIC jack
- I LINE IN 2 VIDEO jack
- J LINE IN 2 AUDIO L/R jacks
- K EJECT button
- L Remote sensor
- M VTR display
- N STOP button
- O JOG dial/SHUTTLE ring


Remote Controller



Rear Panel



VTR Display



SECTION 1

GENERAL DESCRIPTIONS

OPERATING INSTRUCTIONS


2 / AUTO SET UP

The Auto Set Up function automatically tunes in TV stations, sets the clock and sets the RF out channel. All you have to do is to connect the VTR to the main antenna aerial and your TV, and then plug the power cord into the mains outlet.


Auto Set Up

1 Connect the VTR to your TV with an aerial cable from the main antenna.

To receive TV stations only




To receive satellite channels as well



Turn on the satellite receiver and tune to SKY ONE.

2 Plug in the VTR to start its Auto Set Up.
The display will flash "AUTO" for a few minutes.



The Auto Set Up is being carried out.

3 When the VTR completed Auto Set Up, there are 3 possibilities:


- All Channels Found (Ch 1 ~ Ch 7)
- Some Channels Found
- No Channel Found

Notes

- The Auto Set Up procedure above is available only on the first time you connect this VTR. See pages beginning from 38 for the next time.
- If you press the CANCEL button, the Auto Set Up is cancelled.
- If the VTR display shows "0'00" after flashing, no stations are stored. Make sure that the VTR and the TV are connected correctly, and perform "MANUAL SET UP" (page 38) to store your stations and set the clock.
- The TV stations in tuning range numbers 2 and 3 are not stored automatically in this procedure. To receive these stations, you must store them manually. See "Manual Storing of TV Stations" on page 39.

All Channels Found

The screen below will appear when all channels are found.



- VTR will perform auto RF modulator preset and the smallest valid blank RF channel will be displayed on the VTR display. (The valid RF Out channel is between 21 and 69.)

2 The RF out channel can be changed by pressing the **SHIFT** buttons.


3 Press **MENU** button to exit to auto clock set mode.

4 When the auto set up is completed, the display will show the time, e.g. "14:30".

5 Press **MENU** to exit.


Some Channels Found

The screen below will appear when only some channels are found.



1 The RF out channel can be changed by pressing the **SHIFT** buttons.

2 Press **MENU** button to exit to channel swapping page. (For details, see page 12.)




3 Press **MENU** button to exit to auto clock set upon completion of channel swapping.

4 Auto clock set can only be performed if BBC1 is set else manual clock set is needed.

5 Press **MENU** to exit.

No Channel Found

The screen below will be displayed if no valid signal is detected.




Note
This screen is likely to appear if the aerial is not connected correctly. Make sure that the VTR and the TV are connected correctly.

1 The RF out channel can be changed by pressing the **SHIFT** buttons.

2 Press **number button 0** to retry the auto set up full scanning for stations.

3 If no channel found again the screen below will appear.



4 Perform "MANUAL SET UP" (page 38) to store your stations and set the clock.

5 Press **MENU** button to exit.

2 WATCHING THE VIDEO PICTURE

The way you operate the this VTR to watch a video picture depends on whether you use a SCART cable or not.

For SCART Cable Users

- To watch a video picture from the VTR
Insert a cassette and press the **PLAY** button on the remote controller or front panel of the VTR.
- To watch or record a programme from the connected satellite receiver
Press the **INPUT SELECT** button so that "SA" indicator appear in the VTR display. (See page 36.)

For Non-SCART Cable Users (Setting the Video Channel)

- The VTR signals are sent to your TV from the AERIAL OUTPUT socket. Your TV must have a channel set aside exclusively for these VTR signals. This is called the video channel.
- Preparation**
Set the VTR/TV selector to "VTR".
- 1 Turn on the TV
 - 2 Select a free channel on the TV which you wish to use for your video picture, for example channel 9.
This channel 9 will be only used for watching a video picture.
 - 3 Press the **ONSTANDBY** button to turn on the VTR.
 - 4 Hold down the **MENU** button for more than 5 seconds.

VTR display

VIDEO

21 ch

This is a case where the Auto Set Up has selected channel 21 as the RF out channel that transmits the VTR signal to the TV.

- 5 Tune the TV (on channel 9 for example in step 2) so that the following screen is shown clearly.
(For tuning the TV, refer to the TV's manual.)
- 6 Press the **MENU** button.
Video channel setting is complete.

Note on the Antenna Output

On the screen in step 5 in "Setting the Video Channel", the antenna output can be set to "MIX" or "SW".
(Applied when the VTR is connected to your TV only via the AERIAL OUTPUT socket.)
Press **number button 3** to select "MIX" or "SW".

- 3 You can watch a video picture on the video channel regardless of whether or not you have pressed the TV/VIDEO button.
The switch should only be set to "SW" if the video pictures or TV pictures cannot be obtained clearly.
- 2 You can watch a video picture on the video channel only when the "VIDEO" indicator is lit in the VTR display by pressing the TV/VIDEO button.

2 CHECKING AUTO SET UP / CHANNEL SWAPPING

This section explains how to check if the TV stations are stored on the VTR correctly. If they are not stored correctly, you must enter them manually. (See page 39.)

Checking Auto Set Up

Using the **CH/TRK** buttons on the VTR's remote controller, check that the order of the TV stations stored on the VTR is as below. (This is important for the correct functioning of Video Plus+.)

Position number	TV station
1	BBC1
2	BBC2
3	ITV
4	CHANNEL 4
5	CHANNEL 5
6	Satellite receiver

Position number 6 is reserved for a satellite receiver connected with an aerial cable. This position will be empty if there is no satellite receiver connected.


Any other stations are stored from position number 7 onward. If one of these has a better picture or is your preferred regional station, (e.g. Carlton instead of Meridian) then you can swap this into another position number. See the procedure below.

Channel Swapping


This VTR can move a TV station stored by Auto Set Up to another position number. This is called "Channel Swapping".

To move a TV station stored on position number 7 to position number 3.


- 1 Select position number 7 with the **CH/TRK** buttons.
- 2 Press the **MENU** button.
The MAIN MENU screen appears.



- 3 Press **number button 3** to select "INSTALLATION".
- 4 Press **number button 2** to select "MANUAL SET UP".



- 5 Press **number button 1**.
The following text will be superimposed over the position number you selected.
- 6 Press **number button 0 and 3** to select a new position number, then press the **SHIFT** button.



- 7 To select another stored station to move, press the **CH/TRK** buttons and follow step 6.
- 8 Press the **MENU** button.
Now Channel Swapping is complete.
Further press the **MENU** button three times to return to the normal TV screen.



3.5 TIMER PROGRAMME RECORDING

The programmable timer allows you to record up to 6 different programmes over one month.

Recording or Playback in the Timer Standby Mode

- First press the two **TIMER** buttons to release the timer standby mode, and then press the **ON/STANDBY** button to turn on the VTR. The VTR will be available for use.
- Be sure to press the two **TIMER** buttons again to return the VTR to the timer standby mode after you operate.

If a Power Failure Occurs During the Timer Programme Recording

- If the **⓪** indicator is missing in the VTR display after the power failure, the programmed contents have been cleared. Reset the timer programming.
- When power has failed for a short time, the colon of the current time display blinks. The programmed contents are not affected. Reset the clock.

Error Indicators

When the "Full (Clear prog?) message appears on the TV during programming, no more programmes can be entered. If you want to add another programme, select one existing programme on the screen by using number buttons, and press the **CANCEL** button to delete it.


If impossible PlusCode is entered, "Invalid code entered" blinks on the screen to tell you that the recording cannot be performed. Press the **CANCEL** button to clear the PlusCode and enter correct one.

If "Clash" message appears on the screen during programming, it tells you that two programmes with the same recording start time have been entered. You have to make a correction. On this screen, blinking item number means that the item has been entered later.

- Enter the number of the programme you want to correct using number buttons.
- Correct the timer programme data, or clear the data by pressing the **CANCEL** button and then press the **VIDEOPLUS+** button to enter the PlusCode.

Overlaps of the programmes

If two programmes overlap, the recording start time of programme 2 has a priority over the recording end time of programme 1.



Confirming the Video Plus+ DELUXE Timer Programme

- Before the VTR enters the timer standby mode (**⓪** indicator not lit)

- Press the **MENU** button to display the MAIN MENU screen.
- Press number button **1** to select "TIMER PROGRAMMING".




⓪ → 1

Check the programmed data.

- Press the **MENU** button twice to exit.

- During the timer programme recording (**⓪** indicator lit)

Press the **MENU** button. The screen for confirming appears.



MENU

After about 30 seconds, the screen disappears.

Cancelling the Video Plus+ DELUXE Timer Programme

- If the **⓪** indicator is lit, press the two **TIMER** buttons to turn it off, and turn on the VTR by pressing the **ON/STANDBY**.

- Press the **MENU** button to display the MAIN MENU screen.

- Press number button **1** to select "TIMER PROGRAMMING".

- Select a program number which you want to cancel by using number buttons.

- Press the **CANCEL** button. The line is cleared out.

- Press the **MENU** button.

Timer Programming Procedure

- Preparation**
- Select the video channel or video input mode on the TV.
 - Set the VTR/TV selector to "VTR".
 - Turn on the VTR.
 - Make sure that the clock is set correctly.

To record a programme of a station stored on position number 1 (e.g. BBC1) in the SP tape speed from 21:30 until 22:00 on August 30. Today is August 25.

- Load a cassette with the safety tab attached.
- Press the **MENU** button. The MAIN MENU screen appears.
- Press number button **1** to select "TIMER PROGRAMMING".



⓪ → 1

Programme number 1 is ready to accept your input.

- Select an empty programme number using number buttons **1** to **6**.



⓪ → 1

- To select position number 1, press number button **0** and **1**.



⓪ → 1


- If you record from the connected external equipment, make "L1", "L2" or "SA" appear by pressing the **INPUT SELECT** button as follows:

- L1: Via the AUDIO/VIDEO (SCART) socket on the rear panel.
- L2: Via the LINE IN 2 jacks on the front panel.
- SA: From the satellite receiver connected to the SATELLITE (SCART) socket on the rear panel.

To make corrections:

Press the **SHIFT** (←) button to move back to the item, or the **SHIFT** (→) button to move forward.


- Select a frequency of recording, (eg. once)



⓪ → 1


You can also set daily or weekly timer programme recordings. (See next page.)

- Set the recording date.



3 → 0


- Set the recording start time and the off time.



2 → 1 → 3 → 0


2 → 2 → 0 → 0

- To set PDC, press number button **1**; if not set, press number button **2**.



⓪ → 1

- Select the tape speed (SP).



⓪ → 1

(For the tape speed "AUTO", see next page.)

When you set PDC in step 9, "AUTO" cannot be chosen. Use either PDC or AUTO speed.

To set another programme, follow steps 4 to 10. In step 4, select next programme number.

3 BASIC OPERATION

3a OPTIONAL SETTINGS / COUNTER FUNCTION

These functions will help your playback.

Recording or Playback in the Timer Standby Mode

- First press the two **TIMER** buttons to release the timer standby mode, and then press the **ON/STANDBY** button to turn on the VTR. The VTR will be available for use.
- Be sure to press the two **TIMER** buttons again to return the VTR to the timer standby mode after you have finished.

Auto Speed Adjust

If you are not sure if the tape is long enough for timer programme recording in the SP tape speed, set the recording tape speed to "AUTO". Recording starts in the SP tape speed and the VTR automatically selects the tape speed to record the programme to the end. If the tape length is not long enough, the tape speed automatically changes from SP to LP.

Notes

- It is necessary to select the tape length beforehand on the USER SETTING screen. (See page 20, "Tape Time Remaining".)
- When the LP tape speed is selected and the tape length is not sufficient to record the programme to the end, the programme cannot be completely recorded.
- The picture will be distorted when playing the part where the VTR switched the recording speed from SP to LP.

Error Indication


- The "E" (Error) indicator appears in the VTR display if you press the **TIMER** buttons when:
 - a cassette is not loaded.
 - the loaded cassette has no safety tab.
 - no timer programme is set.
- In these cases, a recording can not be made.

If a Power Failure Occurs During the Timer Programme Recording

- If the **Ⓢ** indicator is missing in the VTR display after the power failure, the programmed contents have been lost. Reset the timer programming.
- When power has failed for a short time, the colon of the current time display blinks. The programmed contents are not affected. Reset the clock.

Overlap of the programmes

If two timer programmes overlap, the recording start time of programme 2 has priority over the recording off time of programme 1.



23 Press the **MENU** button.
Now programming is complete.

25 Press the two **TIMER** buttons simultaneously.


12 The power turns off and the VTR enters the timer standby mode.

Daily and Weekly Recording

- Daily recording**
You can record TV programmes on the same channel at the same time Monday through Friday. Press **number button 2** for "DAILY" in step 6.
- Weekly recording**
You can record TV programmes on the same channel on the same day and time every week. Press **number button 3** for "WEEKLY", then **number button 1** to 7 to select a day of the week in step 6.

Confirming the Timer Programmes (During the Timer Programme Recording)

- Press the **MENU** button.
The screen for confirming will appear.



After about 30 seconds, the screen disappears.

Changing/Cancelling the Timer Programmes


- If the **Ⓢ** indicator is lit, press the two **TIMER** buttons to turn it off, and then turn the VTR on by pressing the **ON/STANDBY** button.
- With steps 2 to 11, change the items.
 - To cancel a programme, select the programme number you want to cancel in step 4, and press the **CANCEL** button. The line is then cleared.
- Press the two **TIMER** buttons to return to the timer standby mode.

Optional Settings

You can easily make necessary settings using the on-screen display.

- Preparation**
- Turn on the VTR.
 - Set the VTR/TV selector to "VTR".
 - Select the video channel or video input mode on the TV.

- 1** Press the **MENU** button.
The MAIN MENU screen appears.



- 2** Press **number button 2** to select "USER SETTING".
For details on each item, refer to pages respectively as below.



With "ON" set, the VCR will update the VCR clock setting every morning at 8:00am. This auto clock updating will only operate if the channel set in the VCR position 1 carries valid clock information.

Press **number button 4** to switch "ON" and "OFF".

- Press **number button 3** to turn on or turn off the VTR display during power standby. With "ON" set, VTR display will be cut-off to reduce energy consumption.

- Press **SHIFT** (→) button to go to page 2/2 of USER SETTING.



- Press **number button 4** to select "OFF", if the TV programme or the tape is monochrome.
- With "ON" set, the PDC default setting for all timer programming will be set to on. Pressing **number button 1** switches "ON" and "OFF".

- 3** Press the **MENU** button twice to return to exit.


Counter Function

You can view the clock, linear time counter or tape remaining time in the VTR display or on the TV screen.

- Preparation**
Set the VTR/TV selector to "VTR".

Counter Displays

- Each time you press the **COUNT** button, the VTR display changes in sequence as follows:



- The indication above will also appear on the TV screen by pressing the **DISPLAY** button. They are switchable with the **COUNT** button.

- To reset the linear time counter to "0H00M00S"**
The counter is automatically reset to "0H00M00S" when a cassette is ejected. If you want to reset at another point, such as the beginning of a new recording, just press the **COUNTER RESET** button.

Notes

- The linear time counter does not work on non-recorded portions on the tape.
- When the tape is ejected or the VTR is turned off, the display changes to clock.
- If the tape rewinds back over "0H00M00S", "..." appears in the VTR display.
- The displayed time of the linear time counter is only an approximation.

Tape Time Remaining

- Turn on the VTR and load a cassette.
- Press the **MENU** button to display the MAIN MENU screen.
- Press **number button 2** to select "USER SETTING".
- Press **number button 1** to select the tape length to be used.
 - 1 E180: for an E-195 tape or shorter
 - 2 E240: for an E-210 or E240 tape
 - 3 E260: for an E-260 tape
 - 4 E300: for an E-300 tape
- Press the **MENU** button twice to exit.
- Press the **COUNT** button.
The tape time remaining indicator appears.

Notes

- The displayed remaining time is only an approximation.
- The time remaining is calculated according to the tape speed (SP, LP or SLP) and the cassette type.
- It is necessary to set the tape length correctly beforehand in step 4 when you use the time remaining display.

4 ADVANCED OPERATION NTSC-RECORDED TAPE PLAYBACK

This VTR can play back an NTSC-recorded tape. You can watch the playback picture on a PAL system TV or an NTSC 4.43 system TV.





Setting for NTSC Playback

When you play back an NTSC-recorded tape on this VTR, make a setting on the USER SETTING screen according to your TV.

NTSC tape: tapes on which NTSC M system broadcasts mainly broadcast in the U.S. and Japan are recorded, and tapes recorded in the NTSC video system which are commercially available on the market.

PAL System TV

- 1** Press the **MENU** button to display the MAIN MENU screen. **23**
- 2** Press number button **2** to select "USER SETTING". **4**
- 3** Press **SHIFT** (→) button to go to page 2/2 of USER SETTING and then set "NTSC ON PAL TV" to "ON" by pressing number button **2**. **22**
- 4** Press the **MENU** button twice to exit. **23**



Note
With this VTR, an NTSC tape recorded in the SLP tape speed can be played back. But there are some points to be observed.
- The quality of the playback picture and sound are not clear.
- Variable speed playback (picture search, still, slow playback, etc.) can't be performed properly.
- Digital auto tracking may not be performed properly.

• Use a TV compatible with PAL video signals of PAL 60 (525 lines).
When the TV, that is not compatible with PAL video signals of PAL 60, is used (when the TV, that is compatible only with PAL video signals of PAL 50 (625 lines), is used) NTSC playback pictures may roll up and down. This is not malfunction of the VTR or the TV.
If your TV is equipped with a V-HOLD control, it may be possible to stop the rolling of pictures by adjusting this control.
About PAL 50 and PAL 60 or PAL video signals:
PAL 50: is a normal signal and its PAL video signal is 50 fields (625 lines).
PAL 60: is a special signal and its PAL video signal is 60 fields (525 lines).
Some TVs operate properly only with PAL 50 signals, some TVs operate properly with both PAL 50 and 60 signals.
Therefore, if your TV is switchable between PAL 50 (625 lines)/PAL 60 (525 lines), you can view an NTSC recorded tape in the PAL colour system with your own TV.
Depending on the TV used, the picture may shrink vertically and black bars may appear both at the top and bottom of the TV screen.
This is not an indication of malfunction.
• Variable speed playback (picture search, still, slow playback, etc.) may produce a skewed image and quite a bit of noise on the picture.
• If the tape pre-recorded in the SP tape speed mode is played back in the picture search mode, the picture may be reproduced with no colour.

Note
For viewing an NTSC-recorded tape, we recommend using an NTSC 4.43 TV.

4 ADVANCED OPERATION VARIABLE SPEED PLAYBACK


You can play back a tape at various tape speeds.

Variable Speed Playback

A variety of tape speeds are available on this VTR.
Picture search: Plays back at 5 times or 13 times the normal playback speed so that you can quickly locate a particular scene.
Still picture: Freezes the picture so that you can watch closer.
Slow-motion picture: Plays back at 1/6th or 1/12th the normal playback speed.
Frame advance: Advances the picture frame by frame.

Picture Search

While playing back a tape, press the **FF** or **REW** button.
The tape runs at 5 times the normal playback speed.




Still Picture

While playing back a tape, press the **PAUSE/STILL** button.
The picture freezes.

Slow-motion Picture

While playing back a tape, press the **SLOW** button.
The tape runs at about 1/6th the normal playback speed.



Notes

- The still mode is automatically cancelled after about 5 minutes and returns to normal playback.
- The still picture may shake if a picture of a fast-moving object or scene is frozen. This is not a defect in the unit.

Adjusting Still Picture Stability

If the still picture is distorted or flickers, hold down one of the **CHTRK** buttons until the picture becomes stable.

Notes

- The slow-motion picture mode is automatically cancelled after about 5 minutes and returns to normal playback.
- The slow-motion picture may flicker up and down. This is not a defect in the unit.

Adjusting the Tracking Manually

If the slow-motion picture is noisy, hold down one of the **CHTRK** buttons until the best picture is obtained.


Note

The noise in the slow-motion picture may not be eliminated completely.

You can easily locate the desired programme using the index signal registered on the tape.

Index Search
The VTR plays back each programme with an index signal for about 5 seconds.


Skip Search
The VTR finds and plays back a programme with an index signal you specified.



To use this function, index signals have to be registered on your tape. For registering index signals, follow the procedure below.

■ Registering index signals automatically
An index signal is automatically registered when a recording starts.

Press the **INDEX (+)** button at a desired point.



Note When registering two or more index signals, certain intervals are required: more than 1 minute in the SP tape speed and more than 2 minutes in the LP tape speed.


While the picture is frozen (see "Still Picture"), press the **PLAY** button repeatedly. The picture advances one frame as you press the button.



If you press and hold the button, the tape runs at 1/25th the normal playback speed.

To resume normal playback, press the **PAUSE/STILL** button.

You can also play back a tape at various speeds by turning the **JOG** dial or the **SHUTTLE** ring on the VTR.

[illegible]

The reverse slow playback mode will be released automatically after about 1 minute and forward playback will start.
The reverse playback mode will be released automatically after about 5 minutes and forward playback will start.
Fast-forwarding or rewinding started from the stop mode continues even if the SHUTTLE ring is released. To stop, press the STOP button.

Notes

If you play back a tape recorded in the LP or SLP tape speed or a tape recorded on another VTR in various speed mode, the picture may be noisy or monochrome.

When you use an NTSC-recorded tape, picture search and accelerated picture search, the slow-motion picture speeds are as follows.

	Picture search	Accelerated picture search	Slow-motion
PAL (SP)	x5	x13	1/6
PAL (LP)	x5	x13	1/6
NTSC (SP)	x5	x7	1/5
NTSC (SLP)	x5	x27	1/5

4

NICAM COMPATIBILITY / AUDIO SELECT


This VTR incorporates a special decoder that can receive NICAM broadcast programmes.

Index Search

This function plays back the tape for about 5 seconds at each index signal.

- 1 Load a cassette with the index signals registered.
- 2 Press the **INDEX** (-) or (+) button in the stop or playback mode.

INDEX (-) : to search in the reverse direction
INDEX (+) : to search in the forward direction



The VTR fast-forwards or rewinds the tape. When an index signal is found, the VTR plays back the tape for about 5 seconds, and then resumes fast-forwarding or rewinding. This is repeated each time at an index signal.

- 3 Press the **PLAY** button when the desired programme is found. Normal playback starts.




- Notes**
- At the very beginning of the tape, the index search function may not work properly.
 - If you registered the index signals on a tape recorded on another VTR, the recording may be blurred at the index point and the index search may not work properly.

Skip Search

This function fast-forwards or rewinds the tape to the point at which the selected index signal is registered, and starts playback from there.

- 1 Load a cassette with the index signals registered.
- 2 Press the **INDEX** (-) or (+) button twice in the stop or playback mode.




- 3 Press the **INDEX** (-) or (+) button depending on the direction where your desired programme is located. Each time you press the (-) or (+) button, the number decreases or increases respectively.



The VTR starts to search for the point you specified with the (-) or (+) button. When the point is found, playback will start automatically.

- Notes**
- You can set an index number up to +20.
 - The skip search is cancelled when the **PLAY** or **STOP** button is pressed.

Locating the Index Number



- Example**
- To locate the beginning of first programme before, press the **INDEX** (-) button three times to set the index number -02.
 - To locate the beginning of next programme ahead, press the **INDEX** (+) button twice to set the index number +01.

NICAM Broadcast Programme

NICAM programmes are divided into 3 types: NICAM Stereo, NICAM Mono and Bilingual (transmission in another language). NICAM programmes are always accompanied by a standard mono sound broadcast and you can select the desired sound on the screen (for recording) or with the **A SELECT** button (for playback).

NICAM Broadcast Setting

- 1 Press the **MENU** button.



- 2 Press number button 2.



- 3 Press number button 5 to set "NICAM" to "ON".



ON: Normally set at this position.
OFF: Only set at this position to record the standard mono sound during a NICAM broadcast if the stereo sound is distorted due to inferior reception conditions.

- 4 Press the **MENU** button twice to exit.

Monitoring Sound Output

- When monitoring a TV programme or playing back a Hi-Fi recorded video tape, press the **A SELECT** button to select a desired sound output. As the **A SELECT** button is pressed, the sound output and the indicator change as below:

Sound type	Stereo sound	Bilingual sound	Standard sound broadcast
VTR display	Heard in stereo from both the left and right channels	Channel I (MAIN) heard from the left speaker, Channel II (SUB) from the right speaker	Heard in monaural
	Left channel heard from both the left and right speakers	Channel I (MAIN) heard from both the left and right speakers	Heard in monaural
	Right channel heard from both the left and right speakers	Channel II (SUB) heard from both the left and right speakers	Heard in monaural
Both [L] and [R] go off	Heard in monaural	Channel I (MAIN) heard from both the left and right speakers	Heard in monaural
[L] and [R] go on	Sound mixed the left and right channel, and the normal audio track (see below).		

Sounds of a recorded TV programme

This VTR is capable of recording sound in Hi-Fi system. Stereo broadcasts and bilingual sound broadcasts are recorded in its original sound system regardless of the setting. (See the list above)

- Notes**
- When listening to a stereo broadcast or playing back a Hi-Fi tape recorded in stereo, you have to connect the VTR with the stereo audio system or the stereo TV with a SCART cable.
 - The sound which is output from the **AERIAL OUTPUT** socket is monaural.
 - If a tape which is not Hi-Fi recorded is played back, [L] and [R] indicators go off automatically and the sound output is monaural.

Audio Select

This unit's Hi-Fi stereo audio track (2-channel) can be used to playback an excellent Hi-Fi sound. Sound that has been recorded on the normal audio track is compatible with conventional VTR's.

- When playing back a Hi-Fi recorded tape, press the **A SELECT** button to select desired sound output. The [L], [R] indicators in the VTR display tell you what kind of sound output you are selecting. Accordingly, you can select the desired sound output while observing the lit and/or unit indicators. (See above "Monitoring Sound Output".)

Audio Mix Function

You can select different audio outputs, e.g. mixing one of the Hi-Fi stereo audio tracks and one of the normal audio track.

- This function enables you, for example, to record your voice on a Hi-Fi recorded tape ("Audio Dubbing", page 29). Press the **A SELECT** button several times to make "MIX" appear in the VTR display.




4 5 ADVANCED OPERATION

16:9 (WIDE SCREEN) COMPATIBILITY

This VTR is compatible with the 16:9 (Wide Screen) format.

16:9 (Wide Screen) Compatibility

The VTR automatically adjusts the image to fill the wide TV screen when you play back a tape commercially available which is recorded in the wide screen format, or when you record or play back a wide TV programme via the connected satellite receiver, etc.




Important

Connect equipment compatible with wide screen, to the VTR using the SCART cable.

Setting of 16:9 Wide Screen


- 1 Press the **MENU** button.



- 2 Press number button 2.



- 3 Press number button 2 to set "16:9".



AUTO: Set when you use a wide TV.

The VTR detects wide TV programmes and normal TV programmes automatically when playing back and recording.

ON: The VTR always plays back and records in the mode compatible with 16:9 wide screen.

Set if the VTR cannot detect wide TV programmes with "AUTO" set.

OFF: Set if you do not use a wide TV.

- 4 Press the **MENU** button twice to return to the normal TV screen.


4 6 ADVANCED OPERATION

EDITING

You can create original videos by inserting various scenes and dubbing sounds for example.

Video Insert Editing

You can easily replace a scene on a recorded tape with another scene by importing a picture and sound from external equipment.



- 1 Search for the end point of the portion you want to replace by pressing the **PLAY** button.



- 2 At the end point, pause the picture by pressing the **PAUSE/STILL** button, and press the **COUNTER RESET** button to set the counter to "0H00M00S".



- 3 Rewind the tape to the starting point of the portion you want to replace by pressing the **REW** button.




- 4 At the starting point, play the tape and press the **PAUSE/STILL** button to pause the picture.



- 5 Press the **VIDEO INSERT** button.



- 6 Press the **PAUSE/STILL** button to start video insert editing, and start playback on the external equipment. The recording will automatically stop when the counter reaches "0H00M00S".




Notes

- The colour noise will be produced when playing the parts where the video insert editing started and finished.
- The colour noise may be produced when playing the part you imported by the video insert editing.


- Connection to other VTR or external equipment using the **LINE IN 2 AUDIO/VIDEO** jacks (phono type)

Select "L2".



- Connection to external equipment using the **AUDIO/VIDEO** socket (SCART) or **SATELLITE** socket

Select "L1" or "SA".





MULTI BRAND REMOTE CONTROLLER

The remote controller can be compatible with various brands of TV by setting their control codes. The TOSHIBA code has initially been set to control TOSHIBA TVs.

Audio Dubbing

You can record sounds by importing from a microphone or an external equipment connected to the LINE IN 2 jacks, onto the normal audio track of a pre-recorded tape, without erasing the pictures or sounds on the Hi-Fi stereo track. For example, you can record your narration on a tape which has been recorded on a video camera recorder.



- 1 Load a cassette you want to make audio dubbing on.
- 2 Press the **PLAY** button to start playback.
- 3 Press the **PAUSE/STILL** button where you want to start audio dubbing.
- 4 Press the **A.DUB** button.

Some flickers may be produced on the screen. This is not a malfunction.


- 5 Press the **PAUSE/STILL** button to start audio dubbing. Speak into the microphone or play the sound from the external equipment.

Notes

- Be sure to pull out the microphone from the jack after using.
- To monitor the recorded sound, press the **ASELECT** button to select the sound output. (See page 26.)

Tape Copying

Using another VTR or external equipment, you can copy a tape.



- 1 Press the **INPUT SELECT** button so that the VTR display shows "L1" or "L2" depending on your connection. When using the AUDIO/VIDEO (SCART) socket, When using the LINE IN 2 phono type jacks (front panel).
- 2 Press the **SPILP** button to select the recording tape speed.
- 3 Play the tape on the playback VTR and press the **REC** buttons to start recording on this VTR.
- 4 Press the **STOP** button on each VTR when copying is finished.

Important

It is permissible to record television programmes only in the event that third party copyrights and other rights are not violated.

Notes

- The picture quality of the copied tape is slightly less than the original picture quality.
- When monitoring a picture being recorded, press the **TV/VIDEO** button to make the "VIDEO" indicator appear in the VTR display and select the video channel on the TV.

Setting Control Codes

Preparation

Set the VTR/TV selector to "TV".



- 1 While holding down the **MENU** button, enter the two digits of your TV's brand code (listed right) using **number buttons**.
Hold down: example: **0** → **2**
- 2 Release the **MENU** button.
- 3 Point the remote controller at your TV and use each button listed below to make sure that your TV is operated correctly.

ON/STANDBY	To turn the TV on or off.	17
CH	To select TV channels in the upper or lower direction.	20
VOL (Volume)	To adjust the sound level.	22
INPUT SELECT	To select an external source such as a VTR.	3
Number buttons/ENTER button	To select TV channels. Way of use may differ with models of TV. Check how they work on your TV. Ex. To select channel 3: • 0 → 3 • 0 → 3 → ENTER • ENTER → 3 To select channel 16: • 1 → 6 • 1 → 6 → ENTER • ENTER → ENTER → 1 → 6	4 21

Important

Some TVs may not respond to all the operations above, or may not be operated at all with this remote controller. In this case, operate your TV with its own remote controller.

Notes

- For some brands, several control codes (brand codes) are allocated. Try each of them until the buttons work on your TV.
- If you replace the remote controller's batteries, set the brand code again.

Table of Brand Codes

Brand name of your TV	Brand code
TOSHIBA	01, 14, 15, 16, 17, 19
AKAI	08
BANG & OLUFSEN	20
BLAUPUNKT	04
BRANDT	11
BRIONVEGA	20
CCE	19
CONTINENTAL EDISON	22
FERGUSON	11, 24, 25
FINLUX	02, 15, 20
FISHER	08
FORMENTI	20
GOLDSTAR	02
GRUNDIG	04, 15, 19
HITACHI	06, 10, 11, 22
IMPERIAL	19
JVC	07
LOEWE	02
LOEWE OPTA	02, 20
METZ	20
MITSUBISHI	02, 09, 14
MIVAR	19
NOKIA	21
NORDMENDE	10, 11, 22
PANASONIC (NATIONAL)	03, 21, 26
PHILIPS	02, 18, 20
PHONOLA	02, 18, 20
PIONEER	11, 21
RADIOLA	02, 18
RADIOMARELLI	20
REX	21
SABA	10, 11, 20, 21, 22
SALORA	21
SAMSUNG	02
SANYO	08, 14, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37
SCHNEIDER	02
SELECO	21
SHARP	05, 14, 27
SIEMENS	04
SINGER	20
SINUDYNE	20
SONY	13, 14
TELEAIA	11
TELEFUNKEN	11, 24
THOMSON	10, 11, 22
WEGA	20
YOKO	02

4.3 ADVANCED OPERATION ALL-IN-ONE OPERATION

This function lets you make a set of basic operations on both the VTR and the TV by simply pressing a button.

ALL-IN-ONE Operation

Preparation

- Make your TV compatible with this VTR. (See "MULTI BRAND REMOTE CONTROLLER" on page 30.)
- Locate the VTR and the TV as close as possible so both units can receive the infrared signals from the remote controller.
- Be sure to load a cassette on the VTR.

By pressing a button, the VTR and the TV work as below.

ON/PLAY button
ON/PLAY

TV: Turns on.
VTR: Turns on and starts playback.

SHUT OFF button
SHUT OFF

TV: Turns off.
VTR: Rewinds the tape to the beginning and then turns off.

PROG. SCREEN button
PROG. SCREEN

TV: Turns on.
VTR: Turns on and displays a screen for Video Plus+ DELUXE programming.

Notes

- This function is not available when the VTR is in the timer programme recording standby mode.
- Depending on TVs, this function may not be applicable for them even if they are compatible with this VTR.

4.4 ADVANCED OPERATION nextViewLink

If your TV has the "EasyLink / nextViewLink" function, the VTR makes your VTR's setup and operations easier.


nextViewLink FUNCTION of this VTR

Using a SCART cable (21 pins), a mutual control is available with the TV, VTR, SAT receiver, etc.


- The VTR automatically stores all your current TV stations in the VTR in the same position order as the TV channels. ("TV CH P. DOWN LOAD")
- Even if the TV is in standby mode, the TV automatically turns on and displays the video picture when you start playback on the VTR.
- The VTR automatically selects the same picture as you are watching on the TV, and record it. ("TV PICTURE RECORD")
- The VTR takes in the data and turns to timer standby mode, after a program data reserved is transferred to the VTR by a TV using such as a EPG (Electronic Program Guide). In this case, the TV's and the VTR's channel position must be set to the same TV station. The position could be stored from 1 to 99. Also the VTR's clock must be set.

Connect your EasyLink / nextViewLink TV to the AUDIO/VIDEO (SCART) socket on the VTR using the SCART cable. Refer to your TV's manual additionally.

■ Connection to your EasyLink / nextViewLink TV



■ Connection to your EasyLink / nextViewLink TV and a satellite receiver



When connecting another VTR supporting EasyLink / nextViewLink functions

The "nextViewLink" system can connect 2 VTRs (VTR1 and VTR2) at the same time. This VTR is adjusted to "VTR1", so it should be connected to VTR2.




TV CH P. DOWN LOAD

Preparation

- Turn on the VTR.
- Select the video input mode on the TV.
- Set the VTR/TV selector to "VTR".

22

- Press the **SHIFT** (→) button to start downloading.




1

- Press the **MENU** button to display the MAIN MENU screen.


23

- Press **number button 4** to select "nextViewLink SETTING".



4

- Press **number button 1** to select "TV CH P. DOWN LOAD".



1

23

- When the downloading is finished, the "nextViewLink SETTING" screen returns.

23

- Press the **MENU** button twice to exit.

Notes

- The available position numbers on the VTR are 1 to 99.
- When the TV's channel position is realigned, the VTR automatically makes "TV CH P. DOWN LOAD".

5 / SATELLITE CONTROL OF SATELLITE CHANNELS

Your satellite channels can be selected or changed on this VTR via the connected satellite receiver, same as TV channels.

TV PICTURE RECORD

Setting

Preparation

- Turn on the VTR.
- Select the video input mode on the TV.
- Set the VTR/TV selector to "VTR".

- 1 Press the **MENU** button to display the MAIN MENU screen.
- 2 Press **number button 4** to select "nextViewLink SETTING".
- 3 Press **number button 2** to set "TV PICTURE RECORD" to "ON".



- 4 Press the **MENU** button twice to exit.

Note

It is necessary that the MANUAL SET UP screen has set "ANTENNA SELECT" to "MIX".
When you do not perform "TV PICTURE RECORD", set "TV PICTURE RECORD" to "OFF".
If the TV has a key to operate the TV picture recording, the "TV PICTURE RECORD" could be started from the TV. In this case, the VTR's "TV PICTURE RECORD" must be set to "ON".

Pictures and TV PICTURE RECORD

Picture	The VTR records:
Channel selected on the TV If you performed "TV CH P. DOWN LOAD" (TV stations stored on the VTR and the TV in the same position order).	VTR channel of the same number as the TV channel Continued.
If you did not perform "TV CH P. DOWN LOAD" (TV stations not stored on the VTR and the TV in the same position order).	LINE 1 (output of the TV) Stopped.
Pictures of external equipment connected to the TV	LINE 1 (output of the TV) Stopped.
Channel selected on the VTR	VTR channel Continued.


Setting to Control Satellite Channels

You can select satellite channels by operating this VTR.

It is also possible to automatically change the satellite channels according to your programme setting in the timer programme recording (page 18).

Important

Put the satellite receiver on the top of the VTR as shown below. Do not block the sensor window.



The infrared signals come out of the sensor window and the front of the VTR. Then they bounce off walls and other objects in the room and are received by the satellite receiver. The VTR sends out infrared signals to your satellite receiver even during timer programme recording.

Note


If the channels cannot be controlled properly because the infrared signal fails to reach the satellite receiver, change the position of the satellite receiver on the VTR so that it can receive the signal.

Preparation


- Keep the connected satellite receiver turned on.
- Make sure your satellite receiver is connected to the VTR correctly. (See page 9.)
- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".

- 1 Press the **MENU** button to display the MAIN MENU screen.

- 2 Press **number button 3** to select "INSTALLATION".



- 3 Press **number button 3** to select "SATELLITE SETTING".




- 4 Select 1 to 4 using **number buttons** as below depending on your satellite receiver connection.

• SATELLITE (SCART) socket • AERIAL INPUT socket



- 1 Select "SATELLITE SCART".
- 2 Select "RF AERIAL".




• AUDIOVIDEO (SCART) socket



- 3 Select "AV SCART".

• LINE IN 2 AUDIOVIDEO jacks




- 4 Select "FRONT AV".




- 5 Enter three figures of the brand code for your satellite receiver by **number buttons**. Check the brand code list (page 35).

Ex. To enter brand code 33:
0 → 3 → 3



When you enter the brand code, the VTR sends a test signal to the satellite receiver to make sure that the brand code has been entered correctly. The signal will set the satellite channel to 12. If channel 12 is displayed on your satellite receiver, it means the brand code is set correctly.



- 6 Press the **MENU** button.

5 2 RECORDING FROM A SATELLITE RECEIVER

If you are using a satellite receiver, you can connect it to this VTR to record a satellite programme.

Recording Procedure

Preparation

- Turn on the VTR.
- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".
- Make sure your satellite receiver is connected to the VTR correctly using a SCART cable (page 9), and turn it on.

1 Load a cassette with the safety tab attached.

2 Press the **TV/VIDEO** button so that the "VIDEO" indicator appears in the VTR display.

3 Press the **INPUT SELECT** button so that "SA" indicator appears in the VTR display.

Each time you press the **INPUT SELECT** button, the display changes as follows:
 → TV (position number) → L1 → L2 → SA (satellite)

4 Select the desired satellite channel on the connected satellite receiver.

Make sure that the selected channel is on the TV.

5 Press the **SP/LP** button to select the recording tape speed.

6 Press the **REC** button on the VTR, or simultaneously press the two **REC** buttons on the remote controller.

Recording starts.

7 Press the **STOP** button to stop recording.

Controlling Satellite Channels

Using the remote controller of this VTR

- Press the **SAT/CONT.** button to make "SAT" "SA" appear in the VTR display.
- Select a desired satellite channel using number buttons.

Way of use may differ. Check how they work on your satellite receiver.

Ex. To select channel 3:

- 0 → 3
- 0 → 3 → ENTER
- 1 → 6 → ENTER
- ENTER → ENTER → 1 → 6

Important

Some satellite receivers may not respond to all the operations above, or may not be operated at all with this remote controller. In this case, operate your satellite receiver with its own remote controller.

Notes

- Each time the **SAT/CONT.** button is pressed, this function goes on or off.
- To make a position number appear in the VTR display, see page 18.
- If you have cancelled this function, press the **INPUT SELECT** button.

Changing satellite channels automatically in the timer programme recording

When timer recording programming, press the **SAT/CONT.** button to display [SA] on the screen, and then enter a desired satellite channel using number buttons (step 5, page 18).

Go through steps 1) and 2) above beforehand and confirm that channels are properly selected.

Note

Keep the satellite receiver turned on even while the VTR is in the timer programme recording.

7 Select 1 to 4 using number buttons as below depending on your satellite receiver.

Select . . .


- If the channel of SKY ONE is 1.
- If the channel of SKY ONE is 8.
- If the order is personal
- If the order is personal

If you select 3, the screen changes as below.

Refer to the "GUIDE Channel Table" (page 40).

If you select 3, the screen returns to the **INSTALLATION MENU** of your setting after a few seconds.

Follow steps from 4 on page 37 to set "CH P" column for all your satellite channels.



8 Press the **MENU** button twice to exit.

Table of Satellite Receiver Brand Codes

Brand name	Brand code
TOSHIBA	17, 33
ALBA	1, 2, 9, 16, 17, 65, 66
AMSTRAD	3, 4, 5, 17, 55, 56, 76, 77, 89, 90, 91, 124
ARMSTRONG	17, 43
BIG BROTHER	7, 8, 17
BT	17, 122, 123
BUSH	2, 9, 16, 17, 65, 66
CABLE STAR	17, 101, 102, 103, 104
CABLETIME	17, 101, 102, 103, 104
CAMBRIDGE	17, 122, 123
CHANNEL MASTER	2, 3, 10, 17
D2MAC DECODER	17, 72
DRAKE	17, 45
ECHOSTAR	13, 14, 17, 92, 93, 94
FERGUSON	9, 15, 16, 17, 23, 38, 39, 59, 108
GRUNDIG	17, 19, 28, 71, 125
ITT/NOKIA	17, 26, 27, 50, 51, 52
JVC	17, 122, 123
LENCO	17, 49
MASPRO	17, 20, 64, 67
MATSUI	17, 125
NEC	17, 22, 57
NETWORK	9, 16, 17

- For some brands, several brand codes are allocated.
- Some satellite receivers may not be operated at all with this VTR.

Satellite Monitor Function

You can watch a satellite programme from your connected satellite receiver even while the VTR is recording a TV programme, or is in the playback or stop mode.


Important

This function only applies when the TV and the satellite receiver are connected to the VTR using the SCART socket.

Watching a satellite programme while recording a TV programme

- While recording a TV programme, press the **SAT/MONI.** button.

The "MONI" indicator appears.



Each time you press the **SAT/MONI.** button, the indicator goes on or off.

- Choose a desired satellite channel on the connected satellite receiver.

Watching a satellite programme while the VTR is in the playback or stop mode

- Press the **SAT/MONI.** button so that the "MONI" indicator appears in the VTR display.

- Press the **TV/VIDEO** button so that the "VIDEO" indicator appears in the VTR display.

- Choose a desired satellite channel on the connected satellite receiver.

Notes

- If you make the on-screen display (ex. MAIN MENU screen) appear on the TV, this function is cancelled.
- The satellite monitor function is also available in the timer programme recording mode (page 18) or the one-touch timer recording mode (page 15).

Watching a TV programme while recording a satellite programme

- While recording a satellite programme, press the **TV/VIDEO** button so that the "VIDEO" indicator disappears in the VTR display.
- Choose a desired TV channel on the TV.

5 3 Video Plus+ DELUXE RECORDING OF SATELLITE PROGRAMMES

You have to set the GUIDE channel to record a satellite programme by Video Plus+ DELUXE.

GUIDE Channel Setting for Satellite Channels (Using a Satellite Receiver)

The VTR generally does this setting during "Setting to Control Satellite Channels" procedure (page 34). Use this procedure to correct the GUIDE channels or to make the GUIDE channel setting if your satellite receiver has a channel order other than SKY or ASTRA.


Preparation

- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".

To set a **GUIDE** channel 101 of SKY ONE.


1 Press the **MENU** button to display the MAIN MENU screen.

2 Press number button **3** to select "INSTALLATION".




③

3 Press number button **4** to select "VIDEO PLUS+ GUIDE CH".



④

4 Scroll the numbers to put 101 in the center position of the "GUIDE" column using the **SHIFT** button.




Refer to the chart you prepared (page 40).

Satellite stations	GUIDE	Channel on your satellite receiver
SKY ONE	101	A 1 B
SKY NEWS	102	2 12
SKY MOVIES SCREEN 1	103	3 16
SKY MOVIES SCREEN 2	104	4 20
SKY SPORT	105	5 24
NICKELDEON	106	6 48
PARAMOUNT CHANNEL	107	7 48
EUROSPORT	108	8 48
GALA VISION	109	9 48
SKY SPORTS 3 PLAYBOY TV SHOP	148	17
T.N. (CARTOON NETWORK)	149	29 37

*A is typical SKY order. *B is ASTRA TRANSPONDER order.

5 Press the **SAT.CONT.** button (SA displayed), and enter a channel number on the satellite receiver using number buttons.

If SKY ONE is channel 8 on your satellite receiver channel selector...



6 To set GUIDE channels for other satellite channels, repeat steps 4 and 5.

7 Press the **MENU** button three times to exit.

Now you can make Video Plus+ DELUXE recordings of satellite channels. (See page 16.)

6 1 MANUAL SET UP

The manual procedure of Auto Set Up will help an additional TV station storing or clock resetting, etc. This VTR can store up to 48 positions for TV stations.

Reset-Up Automatically

Use this procedure if the Auto Set Up needs to be made again, for example, after a power failure, when plugged off, or in the event of receiving stations change.

Preparation

- Turn on the TV, and select the video input mode or video channel if you made the aerial connection (page 11).
- Set the VTR/TV selector to "VTR".
- If your satellite receiver is connected using an RF lead, select SKY ONE on the satellite receiver. Auto Set Up will allocate position number 6 on the VTR for the satellite output.


1 Press the **ONSTANDBY** button to turn on the VTR.

2 Press the **MENU** button to display the MAIN MENU screen.



MENU

3 Press number button **3** to select "INSTALLATION".



③

4 Press number button **1** to select "AUTO SET UP".

The VTR starts automatic TV station storing and clock setting if you press the **SHIFT** (+) button.



Note

If "—" is shown, perform "Manual Storing of TV Stations" (page 39) for the TV station.

5 Press the **MENU** button three times to return to the normal TV screen.

Notes

- If the time of the clock is not correct after this procedure, perform "Clock Setting" on this page.
- The TV stations in tuning range numbers 2 and 3 are not stored automatically in this procedure. To receive these stations, you must store them manually. See "Manual Storing of TV Stations" on page 39.

Clock Setting

If BBC1 is stored in position number 1, the VTR automatically sets the clock, and will adjust it to the BBC1 signal at 8:00 every morning. If BBC1 is not stored in position number 1, follow the procedure below to set the clock.

The item to be set blinks. You can change the position by pressing the **SHIFT** buttons.

To set the clock to 14:30 on August 25, 1998

1 Press the **MENU** button to display the MAIN MENU screen.

2 Press number button **4** to select "CLOCK SET".




④

3 Set the hours and minutes. (24 hours clock format)




① → ④ → ③ → ①

4 Set the day and month.



② → ⑤ → ① → ⑧

5 Set the year with its last two digits.



⑨ → ⑧

6 Press the **MENU** button. Now the clock starts.



7 Press the **MENU** button again to exit.

6 1 MANUAL SET UP

GUIDE Channel Table

TV stations	GUIDE	Position number in which the TV station has been transferred to the VTR
BBC1	001	1
BBC2	002	2
ITV	003	3
CHANNEL 4	004	4
CHANNEL 5	005	5
RTE (IRELAND)	006	
NETWORK 2 (IRELAND)	007	
TV NA GAELTACHTA	008	

Satellite stations	GUIDE	Channel on your satellite receiver
SKY ONE	101	1
SKY NEWS	102	2
SKY MOVIES SCREEN 1	103	3
SKY MOVIES SCREEN 2	104	4
SKY SPORT 1	105	5
NICKLODEON	106	6
PARAMOUNT CHANNEL	107	7
EUROSPORT	108	8
GALA VISION	109	9
MTV EUROPE	110	10
ICE CHALLENGE (Home Shopping Network)	111	11
DISCOVERY	112	12
BBC WORLD SERVICE	113	13
UK ARENA	114	14
UK STYLE	115	15
UK HORIZONS	116	16
SAT 1	117	17
PREMIERE	118	18
3 SAT	119	19
NATIONAL GEOGRAPHIC	120	20
PRO 5	121	21
SCIENCE FICTION HISTORY	122	22
SOAPS Christian Channel	123	23
UK GOLD	124	24
DISCOVERY: Discovery Home and Leisure	125	25
BRAVO EBN TROUBLE	126	26
CNN	127	27
WEATHER RACING	128	28
SKY BOX OFFICE 2	129	29
PERFORMANCE	130	30
THE FANTASY CHANNEL	131	31
UK LIVING THE FANTASY CHANNEL	132	32
GRANADA PLUS	133	33
GRANADA MEN & MOTORS	134	34
SKY SCOTTISH SKY BOX OFFICE 3	135	35
TV5 EUROPE	136	36
TV5 INTERNATIONAL	137	37
MBC ARABIC	138	38
QVC	139	39
SPORTNET	140	40
EUROPEAN MUSIC TV	141	41
VIDEO HITS ONE	142	42
SKY SPORT 2	143	43
TV ASIA	144	44
GRANADA GOOD LIFE, COMPUTER CHANNEL	145	45
SKY BOX OFFICE 4	146	46
LIVE TV	147	47
NBC	148	48
VIDEO HITS ONE VH-1 ENGLISH	149	49
SELECTED ADULT CH	150	50
SKY SPORTS 3 PLAYBOX TV SHOP	151	51
TNT/CARTOON NETWORK	152	52

*A is typical SKY order. *B is ASTRA TRANSPONDER order.

7 If a clear picture does not appear on the TV screen after searching is finished, make fine adjustment with the **INDEX** buttons.

If the picture is monochrome, press the **INDEX** button. If the stripes appear, press the **INDEX** button.

8 Repeat steps 5 to 7 for other TV stations, and for satellite stations if your satellite receiver is not connected by a SCART.

Record all position numbers you stored on the VTR in the chart (GUIDE Channel Table) so that you will be ready to use the Video Plus+ DELUXE recording.

9 Press the **MENU** button. Channel tuning is now finished.

Once station storing is done, you can select a TV programme by the position number on which the TV station is stored.

20 You can prevent the use of certain position numbers.

1) Set the VTR to the tuning mode following steps 1 to 4 of the station storing procedure.

2) Select the position number you want to skip with the **CH/TRK** button.

To skip position number 4.

4 Press number button 3. The following indication will appear in the VTR display with the skip function on or off.

Skip function off Skip function on

23 Press the **MENU** button to exit.

To cancel channel skipping Follow steps 1) to 4) above.

Important This procedure can be performed only when the VTR display shows a position number on the VTR. If the "L1", "L2" or "SA" is displayed, press the **INPUT SELECT** button so that the position number appears.

1 Press the **MENU** button to display the MAIN MENU screen.

2 Press number button 3 to select "INSTALLATION".

3 Press number button 2 to select "MANUAL SET UP".

4 Press number button 2 to select "MANUAL TUNING". The VTR is now in the tuning mode, and the screen display disappears.

5 Press the **CH/TRK** button to select position number 1.

To change the tuning range number Press number button 6 repeatedly to select a tuning range number. (See the table on left.)

6 Press and hold the **SHIFT** button to start searching for BBC1.

Higher numbered channel Lower numbered channel

If the received TV signal is not BBC1, press and hold the **SHIFT** button again.

Manual Storing of TV Stations

Information Each TV station operating in the U.K. (e.g. BBC1, ITV) broadcasts on a unique frequency, which in turn has been allocated a transmission channel number (21 - 69). However, this unique frequency and corresponding number changes for each TV station from area to area. For example, BBC1 in London uses channel number 26, while in Oxford BBC1 uses channel number 57 (i.e. CH57). This VTR will indicate these channel numbers (1 - 9, 21 - 69) during tuning.

Tuning range number	Band	TV channel number
1	VHF	A - J (1 - 10), 11, 13 E2 - E12 (82 - 92)
2	UHF	E21 - E69 (21 - 69)
3	CATV	X, Y, Z (71, 72, 73)
4	CATV	1 - 53 (48MHz to 464MHz 8MHz steps)
5	CATV	S1 - S41 (1 - 41)

Preparation

- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".
- Turn on the VTR.
- If you use a satellite receiver, make the connection correctly (page 9) and turn it on.

To store BBC1 to position number 1 on your VTR.

Allocation of the TV stations into the memory of the VTR is expected to be as follows, for Video Plus+ DELUXE recording.

BBC1: Position number 1
BBC2: Position number 2
ITV: Position number 3
CHANNEL 4: Position number 4
CHANNEL 5: Position number 5

Satellite: Position number 6, example (if connected by an RF lead only as shown below.)

Diagram showing TV, AERIAL INPUT, AERIAL, and Satellite antenna connected to a Satellite receiver, which is connected to the TV via RF IN and RF OUT.


In this case, select position number 6 in step 5, and channel 38 in step 6 if the output channel of your satellite receiver is 38, for example. Make sure that TV receives a satellite broadcast. Whenever you watch or record a satellite programme, select position number 6.

GUIDE Channel Setting for TV Channels Manually

Video Plus+ DELUXE is a timer recording system for an easier programming that requires you only to enter a PlusCode assigned to a desired programme. This section explains the necessary set-up to make Video Plus+ DELUXE recordings.

Information

You can perform timer recording very easily using the Video Plus+ DELUXE programming system of this VTR. Before making a Video Plus+ DELUXE recording, it is necessary to set GUIDE channels in the VTR.



Important

There is no need to perform this procedure if the TV stations have been stored to the position numbers (1 for BBC1, 2 for BBC2, 3 for ITV, 4 for CHANNEL 4 and 5 for CHANNEL 5) on the VTR (page 12).

Preparation


- Select the video channel or video input mode on the TV.
- Set the VTR/TV selector to "VTR".

1 Press the **MENU** button to display the MAIN MENU screen.

2 Press number button **3** to select "INSTALLATION".



3 Press number button **4** to select "VIDEO PLUS+ GUIDE CH".



GUIDE channels 1 to 5 have been factory set to position numbers 1 to 5 respectively. Make sure that the numbers are matched as above.

Note

To set another TV channel, select the GUIDE channel using the SHIFT button, and in the "CH P" column enter the position number in which you have stored the TV station by number buttons.

4 Press the **MENU** button three times to exit. The GUIDE channel setting for TV channels is complete.

Now you can make a Video Plus+ DELUXE recording of TV programmes. (See page 16.)

If you use a satellite receiver, make the GUIDE channel setting for satellite channels as well.

SECTION 2

ADJUSTMENT PROCEDURES

1. MECHANICAL ADJUSTMENT

1-1. Mechanical Parts Location





Fig. 2-1-1 Top view











Fig. 2-1-2 Bottom view

1-2. Servicing Jig List

Table 2-1-1

<p>Alignment tape</p>  <p>70909409 (ST-C6) 70909410 (ST-C7)</p>	<p>Back tension cassette gauge</p>  <p>70909103</p>	<p>Torque cassette gauge (KT-300NR)</p>  <p>70909199</p>
<p>Taper nut driver</p>  <p>70909228</p>	<p>VTR cleaning kit</p> 	<p>VTR lubrication kit</p> 
<p>Grease</p> 		

Note:

- Conventional alignment tapes ST-C1 (70909227) and ST-C3 (70909264) can be used partially.

1-3. Main Parts Servicing Time

- Part replacement time differs from servicing life time of each part.
- Following table is prepared based on a standard condition (room temperature, room humidity). The replacement time will be varied depending upon operation environment, using methods, operation duty, etc.
- Particularly, life of the upper cylinder depends upon operation conditions.

Table 2-1-2

	Part Name	Service time (Operating Hours)										Note
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
Tape Transport System	Tension post											• When cleaning, use a swab or piece of gauze soaked in alcohol.
	S/T slant guide post											
	Impedance roller *											
	No. 8 guide post	△	△	△	△	△	△	△	△	△	△	• After cleaning, cleaned parts are dried completely, and then load a video cassette.
	Capstan											
	No. 9 guide post											
	No. 3 guide post											
	S/T guide roller	△	△	△	○	○	○	○	○	○	○	• When lubricating, always use the specified oil.
	Upper cylinder	△	○	○	○	○	○	○	○	○	○	
	Slip ring assembly		○	○	○	○	○	○	○	○	○	
	FE head	△	△	△	○	○	○	○	○	○	○	• When the lubricating, apply one or two drops of oil after the cleaning with alcohol.
	ACE head	△	○	○	○	○	○	○	○	○	○	
	Pinch roller	△	○	○	○	○	○	○	○	○	○	
Tape Drive System	Capstan motor	△	△	△	△	△	○	○	○	○	○	• Check the back tension.
	Loading motor				○	○	○	○	○	○	○	
	Loading belt/ Reel belt	△	○	○	○	○	○	○	○	○	○	
	S reel table assembly		○	○	○	○	○	○	○	○	○	
	T reel table assembly		○	○	○	○	○	○	○	○	○	
	Idle gear assembly	△	○	○	○	○	○	○	○	○	○	
Other	Band brake assembly		○		○		○		○		○	

△ : Cleaning ○ : Check and replace if necessary

* There are two types. One type has an impedance roller and another type has no impedance roller.

1-4. V3 Mechanism Check Method

If the abnormal condition is caused by the mechanism itself, analyze the cause according to the following procedures.

1-4-1. External Appearance Check

- (1) Check whether there are foreign matters or not inside the VTR.
- (2) Check whether the cylinder and the guides for tape transport system are contaminated.

1-4-2. Motor Sensor System Check

Check whether some abnormalities are found in the motor or the sensor system (including control circuits) according to the flow chart.




Fig. 2-1-3




Fig. 2-1-4

1-4-3. Abnormality Analysis by Self-check Function

The unit used V3 mechanism has a self-check function. The self-check function works as a system which stored some abnormal condition. So, use this function to try to analyze the cause(s).

For the data display method and the content of the data, refer to the self-check function (described on page 2-47) in item 2-2.

Notes:

- Abnormal data is displayed only when the first abnormal condition occurs, and is not displayed in the second time. Accordingly, the claim from customers and the actual data displayed may be different.
- The data is stored only when the power turns off after occurring the abnormality condition(s). The data is not stored when the unit operation is recovered by the microcomputer.
- After repairing, initialize the data by pressing the [COUNTER RESET] button while displaying the abnormal mode.

The typical examples in abnormal condition are shown below.

Table 2-1-3

A	B	C	Abnormal Condition	Check Item
06	01	09	Cylinder is stopped at playback position during playback the tape.	Check the cylinder motor. Check if the cylinder and tape transport guide are clogged.
02	01	0d	Cylinder is stopped at FF/REW position during rewind the tape.	
06	02	09	T reel sensor is abnormal at playback position during playback the tape.	Check the capstan motor. Refer to the cases 2 and 3 describe on the table "Defective analyzing list".
03	03	07	S reel sensor is abnormal at playback position during REVIEW the tape.	
01	04	02	Cassette-in and out operation cannot be performed.	Refer to the case 1 described on the table "Defective analyzing list".
03	05	08	Mode shift cannot be performed during shifting to REVIEW.	

A: System control mode, B: Abnormality No., C: Mechanical position when an abnormality occurs.

1-4-4. Check by Defective Analyzing List

If the abnormality causes the mechanism abnormal condition, presume, confirm and treat the defective according to the "Defective analyzing list" in table 2-1-4.

(1) Manual mechanism operation (mode shift) method

Push in the lock lever R and L manually and turn the worm wheel counterclockwise as shown in Fig. 2-1-3. The cam gear is turned clockwise and the mode shifts to the direction where the loading operation can be performed. So, check the mechanism condition in the defective mechanism position when the abnormality occurs.

(2) Defective parts replacement

When a defective occurs due to the defective part(s) and the part(s) is replaced, take care the following items.

- Especially as for the mechanical parts requiring the phase alignment, take care of the part replacement E.g., Assembling mode, phase alignment mark and etc.

- As for the part(s) requiring lubricant such as a specified amount of oil or grease, apply grease or oil according to the instructions and do not stick grease or oil to the portions without allowing to stick it (especially in removal and assembly).

(3) Check after treating the defective

After replacing a defective part and/or aligning a part, first check the mechanism operation manually and confirm that no problem occurs, and then mount the mechanical deck, turn the power ON and check the mechanism operation.

Note:

- After replacing the defective parts according to the procedure of the treatment method for the "damage and phase shift of mechanical part", check the operation of the mechanism again, since the same (or similar) defective problem may occur due to other serious cause (in mechanism or electrical circuit) when performing the actual total check with turning the power on.

Table 2-1-4 Defective analyzing list

Case	Defective Phenomenon (Main Items)	Presumed Cause (Main Cause)	Check Method
1	Power does not turn on. Loading operation is defective. Mode shift operation is defective.	<General> Mechanical stops due to mechanical phase unmatching.	Check mode shift "Cassette out FF/REW position" can be performed when turning worm wheel.
	Loading operation is not performed.	Loading motor does not rotate. (Loading motor is defective or circuit is defective.)	Check loading motor whether it turns by the outer power supply (12.5V).
	Unloading operation is not performed.	S reel does not wind the tape.	Refer to case 3 in this table.
2	Playback operation is not performed. Playback operation is defective.	<General> Main brake is not released. (ON) T soft brake is not released. (ON) Idler does not swing. Pinch does not press.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
	Playback picture does not appear. Video recording can not be performed.	<In case of no mechanical problem> Cylinder is defective. (Circuit is defective.)	Check cylinder assembly.
3	Playback interruption. Defective phenomenon during playback. Recording interruption.	Reel rotation detection is defective. (Sensor is defective. Circuit is defective.)	Check sensor output.
		Idler does not swing.	Check mechanical position.
		Reel belt is removed.	Check the reel belt is removed or not.
4	FF operation is not performed. FF operation is defective. REW operation is not performed. REW operation is defective. Others: REV/FF is not performed. Others: REV/FF is defective.	Main brake is not released. (ON) T soft brake is not released. (ON) Idler does not swing. Pinch is not released.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
5	REVIEW is not performed.	Main brake is not released. (ON) T soft brake is not actuated. Idler does not turn. Pinch does not press.	Check mechanical position.
		Capstan motor does not rotate. (Capstan motor is defective or circuit is defective.)	Check capstan motor.
6	Slot-in is not performed. Cassette can not be inserted.	<General> When the F/L is mounted on the mechanical deck, the position is not correct.	Check mechanical position.
7	Capstan servo does not work. Capstan servo is uneven. Tape speed is fast. Tape speed is slow. Tape speed is uneven. FG pulse is not output.	Capstan motor is defective.	Check capstan motor.
		ACE head control output is defective. (Circuit is defective.)	Check ACE head. Check CTL output.
8	Audio output does not come out. Audio output is small. Audio output variation is large. Audio output is uneven. Audio distortion. Audio noise. Others: Audio is defective.	ACE head is defective.	Check ACE head. Check CTL output.
		Tape transport adjustment is not defective.	Perform tape transport adjustment again after confirming tape transport condition.
		Hi-Fi head (cylinder) is defective. (Circuit is defective.)	Check cylinder. Check whether B+14V is supplied.

Treatment: If the mechanical is found out to be defective according to the procedures described above, perform the following treatment.

- Misassembling, mechanical phase mismatchRepair correctly.
- Parts defect, parts damage.....Replace parts.

If the mechanical is found out not to be defective according to the procedures above, check the circuit(s).

1-5. Mechanical Deck Removal and Mounting

1-5-1. Mechanical Deck Removal

1. Remove three screws (1) mounting the top cover (2) and unlock two hooks at both left and right of the rear side, then remove the top cover sliding backward and lifting upward.
2. Remove the connector (4) (KDB unit side) of JSB unit, and then remove the front panel (5).
3. Remove the FFC (6) connecting between main unit (7) and KDB unit (8), FFCs (9) and (10) connecting between terminal/audio unit (11) and FCB unit (12), lead wire (13) connecting between main unit (7) and FCB unit (12).

Remove two lead wires (14) and (15) between a mechanical deck (16) and FCB unit (12) by loosening the screw (17).

Note:

- In this case, remove FFC (6) on KDB unit (8) side, FFC (9) on FCB unit (12) side and lead wires (14) and (15) on mechanical deck (16) side.
4. Remove two FFCs (19) and (20) on 3DNR unit (18) and lead wire (21).
 5. Remove a screw (22) securing the mechanical deck (16).




Fig. 2-1-5

6. Undo the hook of the terminal board (23) by pressing it and lift it up.




Fig. 2-1-6

7. Remove the mechanical deck (16) with main unit (7) from the chassis lifting its rear side slightly and pulling it upward.




Fig. 2-1-7

Note:

- When pulling the top bracket upward, take care not to deform the reinforcement plate located below the F/L assembly.
8. Remove the lead wire connecting between the mechanical deck (16) and the main unit (7).
 9. Turn over the mechanical deck (16).
 10. Remove the reel belt (24) and one screw (25).
 11. Remove four claws securing the mechanical deck (16) and the main unit (7), and then remove the main unit (7) pulling upward.

1-5-2. Mechanical Deck Mounting

1. Turn over the mechanical deck and lower the main unit vertically adjusting the tape end sensor and etc. to the holes.

Notes:

- Adjust the rotor of the cylinder motor and the stator of the main unit, and then lower the main unit further more till four claws catch the mechanical deck completely.
 - Take care not to damage the rotor and the stator.
 - When locking the claw of the front right side to the main unit, turn the REC inhibit lever so as not to damage the switch.
2. Mount the mechanical deck on the chassis in reverse order of removal.

Note:

- When mounting the front panel, mount it with its door fully open.

1-5-3. Confirmation of Each Operation Mode without Cassette

1. Shut out the light to the start/end sensor.
2. Release the both sides of the lock lever and make a slot-in condition.
3. Turn the reel table manually located on the opposite side of the rotating reel table.
4. In this condition, confirmation of each operation mode can be performed.

Note:

- When turning the opposite side reel table of the rotating reel table manually in playback, FF/REW mode, and sending no reel pulse, the auto eject or power off function is performed.

1-6. Main Parts Replacement

1-6-1. Top Bracket Replacement

1. Remove two securing screws (2) on the top bracket (1).
2. Remove the top bracket (1) lifting in the direction shown by the arrow.




Fig. 2-1-8

3. When mounting the top bracket (1), move the tip of the grip lever (3) on the cassette holder assembly to the inclined portion of a trapezoidal cam, and then mount the top bracket (1).




Fig. 2-1-9

Note:

- After remounting the top bracket (1), move the cassette holder forward and backward, and then confirm the claws of the lock lever (5) catch completely the both left and right sides of the stopper section (4) at the top bracket (1).




Fig. 2-1-10

1-6-2. Cassette Holder Assembly Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. The cassette holder assembly (1) is guided along the guide grooves (2) with both left and right bosses of the cassette holder assembly (1). So first remove each side boss (3) on both left and right sides of cassette holder assembly (1) from the guide groove (2).
3. When the cassette holder assembly (1) is set at the EJECT position, the boss is located at (a), so move the boss from (a) to (b) and remove the bosses on both left and right sides simultaneously.





Fig. 2-1-11

Note:

- The grip lever (4) on the cassette holder assembly (1) may catch the trapezoidal cam on the mechanical deck (2), so perform the work lifting the grip lever in the direction shown by the arrow.




Fig. 2-1-12

4. After removing the front side bosses (5) on both left and right sides, remove the cassette holder assembly (1) pulling to the front side.
5. When mounting the cassette holder assembly (1), insert the front side bosses (5) to the U shaped groove of the drive arm (6) and the guide groove (2) on the mechanical deck lifting the rear side of the cassette holder assembly (1).




Fig. 2-1-13

6. When mounting the rear side bosses (3), perform the reverse order of removal.

1-6-3. Door Open Lever Replacement

1. Release the lock lever (2) on the cassette holder assembly (1) pressing in the direction shown by the arrow.




Fig. 2-1-14

2. Move the cassette holder assembly (1) slightly to the rear side.
3. Remove the claws (A) and (B) on the door open lever (3) from the mechanical deck (4).
4. Match the boss on a new door open lever (3) and the hole (C) on the mechanical deck, and then insert the claws (B) first and then (A) to the mechanical deck (4).




Fig. 2-1-15

5. Remount the cassette holder assembly to the position as it was.

1-6-4. Drive Lever Gear Replacement

1. Make the cassette holder assembly to the slot-out (EJECT) position.

Note:

- In this condition, both mark holes on the F/L drive slider (1) and the mechanical deck fit with each other, also the hole of the boss on the drive lever gear (2), the center of the gear tooth and the marking line are in line.
2. Move the claw of the drive arm (3) to the direction of the arrow (A) and remove the drive lever gear (2) upward.




Fig. 2-1-16

3. When remounting the drive lever gear (2), take care of the phase position (refer to the note described above.) and mount in the reverse order of removal.

1-6-5. Drive Arm Assembly Replacement

1. Remove the top bracket assembly. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the door open lever. (Refer to item "1-6-3. Door Open Lever Replacement".)
4. Remove the drive lever gear. (Refer to item "1-6-4. Drive Lever Gear Replacement".)
5. Pull the REC-inhibiting lever slightly to the front side, turn the drive arm assembly (1) to the front side and push it in the direction shown by the arrow. Remove the left side boss (2) on the drive arm assembly (1) from the cutout of the guide groove on the mechanical deck (3).
6. Remount the drive arm assembly (1) in the reverse order of removal.




Fig. 2-1-17

1-6-6. Cam Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
4. Remove the loading drive assembly. (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
5. Remove the drive lever. (Refer to item "1-6-39. Drive Lever Replacement".)
6. Remove the pinch roller assembly. (Refer to item "1-6-20. Pinch Roller Assembly Replacement".)
7. Remove the cam gear. (Refer to item "1-6-30. Cam Gear Replacement".)
8. Move the cam lever (1) until it stops in the direction shown by the arrow (A). Pull out the cam lever (1) lifting up straightly at the position where the cam lever (1) stops.
9. Apply grease to the portions of bosses (A) to (C) on a new cam lever.

Notes:

- Confirm that the boss (A) on the cam lever (1) is inserted into the hole on the F/L drive slider (2).
- After inserting the cam lever (1), confirm that the cam lever (1) moves smoothly.

10. Replace the cam lever in the reverse order of removal.




Fig. 2-1-18

1-6-7. F/L Drive Slider Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
4. Remove the loading drive assembly. (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
5. Remove the drive lever. (Refer to item "1-6-39. Drive Lever Replacement".)
6. Remove the pinch roller assembly. (Refer to item "1-6-20. Pinch Roller Assembly Replacement".)
7. Remove the cam gear. (Refer to item "1-6-30. Cam Gear Replacement".)
8. Remove the cam lever. (Refer to item "1-6-6. Cam Lever Replacement".)
9. Remove the drive lever gear. (Refer to item "1-6-4. Drive Lever Gear Replacement".)
10. Push the F/L drive slider (1) in the direction shown by the arrow (A) and slide it. Furthermore, pull out it to the front side lifting it in the direction shown by the arrow (B).
11. Apply grease to the shaded parts (a) to (d) on a new F/L drive slider (1).

Note:

- For the phase alignment of the drive lever gear, refer to item "1-6-4. Drive Lever Gear Replacement".

12. Replace the F/L drive slider (1) in the reverse order of removal.

Note:

- After completion of the replacement, confirm that the F/L drive slider (1) moves smoothly.




Fig. 2-1-19

1-6-8. Arm Brake Lever Assembly and Arm Brake Torsion Spring Replacement

1. Make the cassette holder assembly to the slot-out (EJECT) position.
2. Turn the arm brake lever assembly (1) in the direction shown by the arrow (A) until it stops. Pull out the arm brake lever assembly (1) to the front at the position it stops.

Note:

Take care that the arm brake torsion spring (2) is removed forcefully.




Fig. 2-1-20

4. Insert the hook portion on the arm brake lever assembly (1) to the cutout on the mechanical deck.
5. Turn the arm brake lever assembly (1) counterclockwise and fix it at the position which the arm brake lever assembly (1) faces to the straight below.
6. When pushing the tip of the arm brake torsion spring (2) located at (B) position, the tip is removed from the temporary hook and moves to the hook on the mechanical deck.
7. The arm brake lever assembly turns to the specified position by force of the arm brake torsion spring.




Fig. 2-1-22

3. Hook the arm brake torsion spring (2) temporarily to a new arm brake lever assembly (1).

Note:

- Take care of the direction of the arm brake torsion spring (2) so that the longer end of the arm brake torsion spring (2) is hooked on the temporary hook.




Fig. 2-1-21

1-6-9. Cylinder Assembly Inspection and Replacement

<Inspection>

1. Check if the tape transport surface on the lower cylinder assembly are not damaged.
2. Check if the rotation of the upper cylinder assembly is not abnormal.

When any abnormality is found according to the inspection procedures described above 1 and 2, replace the cylinder assembly.

<Replacement>

1. Remove the ground brush assembly.
2. Remove the head cleaner. (Refer to item "1-6-13. Head Cleaner Replacement.")
3. Remove the FPC (1) on the Preamplifier.
4. Remove three screws (2) and the cylinder holding plate (3) and (4). (Refer to item "1-6-12. Cylinder Holding Plate Replacement".)
5. Remove the cylinder assembly (5).
6. Remount the cylinder assembly (5) in the reverse order of removal. Fix the cylinder pressing slightly in the direction shown by the arrow (A) and the cylinder holding plate (3) pressing slightly in the direction shown by the arrow (B). (Tightening torque: $294 - 392 \text{ mN}\cdot\text{m}$ ($3 - 4 \text{ kg}\cdot\text{cm}$))




Fig. 2-1-23

Note:

- When replacing, take much care not to touch the video head directly and damage the cylinder.
7. Perform the tape transport adjustment.

1-6-10. Upper Cylinder Assembly Inspection and Replacement

<Inspection>

1. Check if the video heads are damaged or worn out.
2. Check the video heads for clogging. (In case that the clogging is not remedied after cleaning.)

<Replacement>

1. Remove the ground brush assembly.
2. Remove two securing screws (1) and remove the upper cylinder assembly (2).
3. Clean the new upper cylinder assembly (2) and the flange (3) mounting surface with a cleaning kit.
4. Align the head (A) (green) and the marker on the rotary transformer PC board (4) and then mount the upper cylinder assembly (Tightening torque : $294 - 392 \text{ mN}\cdot\text{m}$ ($3 - 4 \text{ kg}\cdot\text{cm}$))




Fig. 2-1-24




Fig. 2-1-25




Fig. 2-1-26

Note:

- During the work in steps 3 to 4, take care not to touch the connector assembly and deform the spring.
5. Perform the tape transport adjustment according to its procedures.

1-6-11. Lower Cylinder Assembly Inspection and Replacement

<Inspection>

1. Check if the tape transport surface on the lower cylinder assembly is not damaged.
2. Check if the rotation of the upper cylinder assembly is not abnormal.
3. Check if the FPC on the Preamplifier is not damaged.

When any abnormality is found under the inspection described in the steps (1) to (3), replace the cylinder assembly.

<Replacement>

1. Remove the cylinder assembly. (Refer to item “1-6-9. Cylinder Assembly Inspection and Replacement”.)
2. Remove two securing screws (1) and remove the upper cylinder assembly (2).
3. Replace the lower cylinder assembly (3).
4. Mount the lower cylinder assembly in the reverse order of removal taking care not to touch the video head directly and damage the cylinder.

Note:

- Take care not to deform the joint spring on the upper cylinder assembly (2).
5. Perform the tape transport adjustment according to its procedures.




Fig. 2-1-27

1-6-12. Cylinder Holding Plate Replacement

1. Remove screws (1) and (2) securing the cylinder holding plate (3) and a screw (5) securing the cylinder holding plate (4).
2. Remove the cylinder holding plate (3) and (4) sliding in the direction shown by the arrow (B) and (A).
3. Eliminate the cylinder lock key (wedge shaped parts).
4. After replacing the cylinder holding plates (3) and (4), mount new parts in the reverse order of removal.

Notes:

- When remounting, fix the cylinder while pushing in the direction shown by the arrow (A) and the cylinder holding plate (3) in the direction shown by the arrow (B). Then tighten three screws while pushing the cylinder holding plate (4) toward the stopper on the outsert of the mechanical deck.
- Tightening order of the screws is (1) → (2) → (5).
- Tightening torque of the screws (1), (2), (5) is 294 – 392 mN•m (3 – 4 kg•cm).




Fig. 2-1-28

1-6-13. Head Cleaner Replacement

<Roller sub assembly replacement>

1. Remove the roller sub cleaner assembly (2) pulling upward from the hook (A) on the cleaner lever (1).
2. After replacing the roller sub assembly, mount in the reverse order of removal.

<Cleaner lever replacement>

1. Undo the hook (B) of the cleaner lever (1) from the mechanical deck, and pull out the cleaner lever (1) upward.
2. Replace the cleaner lever (1) on the roller sub assembly (2), and mount the cleaner lever (1) in the reverse order of removal.

Note:

- Take care the roller sub assembly (2) is not stained with grease or oil.




Fig. 2-1-29

Note:

- When remounting the head cleaner, position the stopper rib (C) in front of the stopper (D).




Fig. 2-1-30

Note:

- Confirm that the joint portion (E) of the elastic spring positions in front of the assist pin (F) on the cleaner assist lever (4).




Fig. 2-1-31

1-6-14. No. 8, No. 3 Guide Sleeves Replacement

1. When replacing the No. 8 guide sleeve (1), first remove the guide cap (2) on the loading bracket assembly.
2. Pull out the guide sleeve (1) from the guide post (3).

Note:

- Take care not to break the No. 8, No. 3 guide posts on the mechanical deck if twisting the guide sleeve forcefully.

3. Insert a new guide sleeve (1) to the guide post.

Note:

- When inserting the guide sleeve (1), take care so that its hole faces the opposite side to the tape transport surface.
4. For No. 8 guide sleeve, insert the No. 8 guide cap (2) onto it.




Fig. 2-1-32

1-6-15. ACE Head Assembly Replacement

1. Remove the FFC (1) from the connector.
2. Remove two screws (2) and remove the ACE main base (3) and ACE head assembly (4).
3. Remove three adjusting screws (5), (6), and (7) and then remove the ACE head assembly (4).

Note:

- When replacing ACE head (9) only without replacing its PC board, unsolder the ACE head (9) on the ACE head PC board (8) and then remove the ACE head (9) and the ACE head PC board (8).

4. Mount the ACE head assembly (4) in the reverse order of removal.

Note:

- When reassembling the ACE head assembly (4), First set the ACE springs (10) between the ACE head assembly (4) and the ACE main base (3), and secure the adjusting screws (5), (6), and (7).




Fig. 2-1-33

- When securing three adjusting screws, mount the ACE main base (3) and ACE head assembly (4) so that the clearance between them becomes parallel with the specified preset value (4.3 ± 0.1 mm).
5. After replacing, perform the tape transport adjustment.

Note:

- When replacing the ACE head assembly (4), always use an ACE head (9) having the same part number. Do not use any other ACE head assembly.

1-6-16. FE Head Replacement

1. Open the FE head holding hook (1) on the mechanical deck slightly in both left and right directions and remove the FE head (2) by moving in the direction shown by the arrows.
2. Replace the FE head (2) and mount the parts in the reverse order of removal.
3. Perform adjustment from the linearity adjustment item in the tape transport system adjustment.

Notes:

- When mounting the FE head, Push the head backward completely.
- Though FE head (2) can be removed upward by opening the FE head holding hook (1) to both left and right directions, perform the standard replacement procedure described above since this may cause deformation of the hook.




Fig. 2-1-34

1-6-17. S,T Slider Replacement

1. Remove the tension lever assembly. (Refer to item "1-6-22. Tension Lever Assembly Replacement".)
2. Remove the loading slider. (Refer to item "1-6-24. Loading Slider Assembly Replacement".)
3. Remove the S loading assembly. (Refer to item "1-6-23. S Loading Assembly Replacement".)
4. Remove the T loading assembly. (Refer to item "1-6-23. T Loading Assembly Replacement".)
5. Remove the S slider (1) and T slider (2) lifting up to the cutout of the groove on the mechanical deck (3).
6. Remove the S and T guide rollers and mount a new slider.
7. Mount the parts in the reverse order of removal.

Note:

- Perform the phase alignment between the loading slider (4) and S, T loading assemblies (5), (6) referring each replacement procedure.




Fig. 2-1-35

8. After completion of the replacement, perform the adjustment from item 1 in the tape transport system adjustment.

1-6-18. S, T Guide Rollers Replacement

The same replacement procedures will be applied for the S, T guide rollers.

1. Turn the guide roller (1) counterclockwise and remove the guide roller (1) from the slider assembly (2).
2. Mount a new guide roller on the slider assembly (2) turning clockwise.
3. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment..

Notes:

- O ring is not applied to the T guide roller.
- For the T guide roller, marking is located on the upper flange. So take care not to mis-mount with the S guide roller.




Fig. 2-1-36

1-6-19. S, T Impedance Roller Replacement

1. Remove two screws (1) and (2), and then remove two brackets (3), (4).
2. Replace two impedance rollers (5), (6).
3. Mount the parts in the reverse order of removal.
4. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment.

Note:

- S, T impedance rollers (5), (6) is not always applied to all models.




Fig. 2-1-37

1-6-20. Pinch Roller Assembly Replacement

1. Remove the loading drive assembly (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
2. Remove the pinch assembly (1) lifting vertically from the pinch post (2).
3. Remove the pinch spring (5) from the hooks on the pinch drive assembly (3) and the pinch lever assembly (4).
4. Turn the projection (A) on the pinch drive assembly (3) counterclockwise till it goes to the cutout on the pinch lever assembly (4).
5. After replacing, mount the parts in the reverse order of removal.
6. After completion of the replacement, perform the tape transport adjustment.




Fig. 2-1-38

Notes:

- For the removal and assembling of the loading drive assembly, refer to item 1-6-28.
- When inserting the pinch assembly (1) into the pinch post (2), insert it so that the pinch drive post (D) enters the groove (E) inside the cam gear.
- Take care not to touch the surface of the pinch roller and the grease is not stained on it.
- Be sure to apply grease to the surface of the bar-ring on the pinch lever assembly (4) and the pinch post (2) on the mechanical deck.

1-6-21. No. 9 Guide Lever Assembly Replacement

1. Remove the loading drive assembly. (Refer to item “1-6-28. Loading Drive Assembly Replacement”.)
2. Remove the drive lever. (Refer to item “1-6-39. Drive Lever Replacement”.)

3. Remove the pinch assembly. (Refer to item “1-6-20. Pinch Roller Assembly Replacement”.)
4. Remove the ACE head assembly. (Refer to item “1-6-15. ACE Head Assembly Replacement”.)
5. Remove the cam gear (2) from the cam gear post (1).
6. Remove the T soft brake spring (3).
7. Remove the No. 9 guide lever assembly (4) lifting the No. 9 guide lever assembly upward from the No. 9 guide post (5).
8. After replacing, mount the parts in the reverse order of removal.
9. After completion of the replacement, perform the tape transport adjustment.

Notes:

- When mounting the No. 9 guide lever assembly (4), confirm that (A) side of the No. 9 guide lever assembly (4) touches the capstan motor housing portion.
- After inserting the No. 9 guide lever assembly (4) into the No. 9 guide post (5), confirm that the lower projection of the No. 9 guide lever assembly (4) touches to the upper surface of the mechanical deck.
- Take care that the grease is not stained on the No. 9 guide post of the No. 9 guide lever assembly (4).
- Be sure to apply grease to the No. 9 guide post (5).




Fig. 2-1-39

1-6-22. Tension Lever Assembly, Band Holder and Band Brake Replacement

1. Remove the tension spring (1).

Note:

- Take care not to extend or deform the tension spring.
2. After setting the band brake adjuster to the band holder assembling position, undo the claw of the snap-fit type and remove the band holder from the band brake adjuster by lifting it upward.




Fig. 2-1-40 Detail of band holder assembling

3. Undo the claw of the outsert on the mechanical deck catching the shaft of the tension lever assembly (3) and remove the tension lever assembly lifting it upward.
4. Remove the band brake (5) from the reel table while pulling the S soft brake lever (4) in the direction shown by the arrow.
5. Remove the band brake (5) from the hook on the tension lever assembly (3).

Note:

- Take care not to contaminate, bend or damage the felt surface on the band brake (5).
6. After replacing the tension lever assembly (3), clean the shaft on the tension lever and apply a few amount of oil.
 7. Mount the parts in the reverse order of the removal.
 8. After mounting, check the tension post position and perform the adjustment and back tension check.
 9. After completion of the replacement, perform the adjustment from the linearity adjustment in the tape transport system adjustment.

Notes:

- The band holder (2) can be replaced in the procedures described above steps 1 to 3.
- The band brake (5) can be replaced in the procedures described above steps 1 to 5.
- When replacing the band holder (2) and band brake (5), the linearity adjustment is not necessary.




Fig. 2-1-41

1-6-23. S,T Loading Assembly Replacement

1. Remove the mechanical deck assembly from the main PC board.
2. Set the mechanical position to the F/L out position (front side). Turn over the mechanical deck.
3. Remove the loading slider assembly. (Refer to item "1-6-24. Loading Slider Assembly Replacement".)




Fig. 2-1-42

4. Remove the S, T loading assemblies (1), (2).
5. Insert the S, T slider assemblies (3), (4) along the cutout of the S, T loading holes (A) and (B) on the mechanical deck and set the S, T slider assemblies (3), (4) to the loading position (rear side).
6. Insert the T loading assembly (2) to the post (C) on the T slider assembly (4) and the post (D) on the mechanical deck. And insert the S loading assembly (1) to the post (E) on the S slider assembly (3) and the post (F) on the mechanical deck.




Fig. 2-1-43

Note:

- Align the phases of the ▲ marks on the S, T loading gear (1), (2).
7. Set the S, T slider assemblies (3), (4) to the F/L out position.




Fig. 2-1-44

1-6-24. Loading Slider Assembly Replacement

1. Remove the mechanical deck from the main PC board.
2. Set the mechanical position to the F/L out position.
3. Turn over the mechanical deck.
4. Remove the stop ring (1).
5. Remove the loading slider assembly (2) while lifting its tip upward using the mold portion on the loading slider assembly (2) as a fulcrum.
6. Mount the parts in the reverse order of removal.

Notes:

- When mounting the loading slider assembly (2), insert the tip of the loading slider assembly (2) slightly to the mold portion, then mount it so that the claw on the outsert is in the position of the cutout portion of the loading slider assembly.
- Confirm that the position mark on the loading slider assembly (2) and the mark on the T loading gear match each other in position.




Fig. 2-1-45 View from mechanical deck bottom side




Fig. 2-1-46

1-6-25. Hook Lever Assembly Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. Remove the tension spring (1).
5. Turn the hook lever assembly (2) counterclockwise slightly, and remove the claw on the hook lever assembly (2) then replace.
6. After replacing the hook lever assembly (2), insert the (A) portion of the hook lever under the S reel table assembly. When the portions (B), (C), (D) are in line, push the claw into the mechanical deck.




Fig. 2-1-47

7. Turn the hook lever assembly (2) clockwise till it stops, and mount the tension spring (1). After replacing the hook lever assembly (2), slide the cam slider in the direction shown by the arrow, and then position the boss (E) under the cam slider.




Fig. 2-1-48

1-6-26. Hook Replacement

1. Remove the hook lever assembly. (Refer to item "1-6-25. Hook Lever Assembly Replacement".)
2. Turn over the hook lever assembly (1) and remove the hook lever assembly (1) opening the portion (A) of the hook (2) slightly and lifting the hook (2) upward.
3. When mounting a new hook, push the hook (2) in the portion (B) from above.

Note:

- Take care not to confuse the mounting direction of the hook (2).




Fig. 2-1-49

1-6-27. Tension Drive Lever Replacement

1. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
2. Turn over the mechanical deck and remove the tension drive lever (1) from the projection (A) moving counterclockwise slightly.
3. After replacing the tension drive lever (1), mount in the reverse order of removal.

Note:

- For the cam slider mounting, refer to the notes in item 1-6-40.




Fig. 2-1-50

1-6-28. Loading Drive Assembly Replacement

1. Remove the F/L ground plate and the head cleaner assembly. (Refer to item "1-6-13. Head Cleaner Assembly Replacement".)
2. Remove two flat cables (1) from the connectors.
3. Pull out the portion (A) (No. 8 guide cap) from the motor bracket (2).
4. Remove four claws (a), (b), (c), (d) securing the motor bracket in the order of (a) → (b) → (c) → (d).




Fig. 2-1-51

Notes:

- Remove the claw (a) inserting a driver.
- Remove the claws (b) and (c) pushing inside previously and opening the claws slightly.






Fig. 2-1-52

<Preparation for loading drive assembly mounting >

- a) Confirm that the head cleaner assembly is removed.
 - b) Confirm that the small hole b) on the cam gear aligns with the hole on the mechanical deck.
 - c) Confirm that the clearance between the pinch lever assembly and the cam gear is approx. 0.3 mm. (Confirm that the pinch lever assembly is correctly mounted on the groove of the cam gear.)
 - d) Confirm that the clearance between the drive lever and the cam gear is approx. 2 mm. (Confirm that the drive lever is correctly mounted on the groove of the cam gear.)
 - e) Confirm that the Δ mark on the rotor of the cam switch aligns with the Δ mark on the motor bracket.
5. After completion above steps a) to e), mount the loading drive assembly. Push four claws to the motor bracket in the order of (d) \rightarrow (c) \rightarrow (b) \rightarrow (a) and push the portion (A) (No. 8 guide cap) into the motor bracket.
 6. Confirm that the Δ mark on the rotor of the cam switch aligns with that on the bracket when the hole b) on the cam gear aligns with the hole on the mechanical deck. If the alignment of the Δ marks cannot be confirmed, remove loading drive assembly once again and reinstall after confirming the above steps a) to e).
 7. Mount two flat cables.
 8. Mount the F/L ground plate and the head cleaner assembly.




Loading drive assembly bottom side


Fig. 2-1-53

1-6-29. Loading Motor Sub Assembly, Cam Switch and Loading Drive Unit Replacement

1. Remove the loading drive assembly. (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
2. Remove the cleaner assist lever (1) from the claw (A).
3. After removing the cleaner assist lever (1), the worm wheel can be also removed upward.
4. Insert a slot-type screwdriver into the portion (C) of the loading drive bracket (3) and push the loading motor 2 – 3 mm lower. And push the tip of worm gear from the portion (D) of the loading bracket (3), then remove the worm gear (4) from the claw (E).
5. Remove the cam switch (5) from the claw (F) on the loading drive bracket (3) and pull out the loading drive unit (7) and the worm gear (4) simultaneously.
6. Replace the loading drive unit (7). When mounting the PC boards of the cam switch (5) and the loading drive unit (7), take care that no clearance is allowed.
7. Insert the loading drive unit (7) and the worm gear (4) into the loading drive bracket (3).
8. Push the tip (G) of the worm gear (4) into the claw (E) on the loading motor bracket.
9. Push the cam switch (5) into the claw (F) on the loading motor bracket.
10. Mount the parts in the reverse order of removal.



Loading drive assembly (Top Side)



Loading drive assembly (Bottom side)

Fig. 2-1-54

1-6-30. Cam Gear Replacement

1. Remove the loading drive assembly. (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
2. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
3. Remove the drive lever. (Refer to item "1-6-39. Drive Lever Replacement".)
4. Remove the pinch roller assembly. (Refer to item "1-6-20. Pinch Roller Assembly Replacement".)
5. Remove the cam gear.
6. Apply grease on a new cam gear on the shaded portion as shown in Fig. 2-1-55 and the shaft of the main base.




Fig. 2-1-55

7. Make the S, T slider to the slot out condition.
8. Push the cam lever (1) and the pin (2) (loading slider) in the direction shown by the arrows (A) and (B).
9. Mount the cam gear at the angle which the small hole (a) on the cam gear aligns with the hole on the mechanical deck. (Refer to Fig. 2-1-55.)




Fig. 2-1-56

10. Mount the parts in the reverse order of removal.

1-6-31. S Reel Table Assembly and Washer 2 Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
4. Remove the S soft brake and S main brake assembly. (Refer to item "1-6-37. S Soft Brake Replacement and 1-6-36. S Main Brake Assembly Replacement".)
5. Remove the tension lever assembly. (Refer to item "1-6-22. Tension Lever Assembly Replacement".)
6. Remove the S reel table assembly (1) pulling it out upward.
7. Remove the washer 2 (2).
8. After cleaning the reel shaft (3) with a cleaning kit, insert a new washer 2 (2) to the reel shaft (3) and apply a drop of oil to the shaded portions (two locations) on the reel shaft (3).
9. After replacing, mount the parts in the reverse order of removal.
10. Confirm the reel torque using a torque cassette.

Note:

- The washer 2 (2) can use repeatedly.




Fig. 2-1-57

1-6-32. T Reel Table Assembly and Washer 2 Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the T soft brake and T main brake assembly (Refer to item "1-6-40. Cam Slider Replacement".)
4. Remove the T reel table assembly (1) pulling it out upward.
5. Remove the washer 2 (2).
6. After cleaning the reel shaft (3) with a cleaning kit, insert a new washer 2 (2) to the reel shaft (3) and apply a drop of oil to the shaded portions (two locations) on the reel shaft (3).
7. After replacing, mount the parts in the reverse order of removal.
8. Confirm the reel torque using a torque cassette.




Fig. 2-1-58

Note:

- Washer 2 (2) can use repeatedly.

1-6-33. Idle Arm Assembly Replacement (Center Gear Pulley, Idle Kick Lever, Idle up/down Lever)

1. Remove the mechanical deck from the main PC board.
2. Remove the stop ring (1) turning over the mechanical deck.
3. Remove the center gear pulley (2) lifting it upward.
4. Remove the claw (A) on the idle kick lever (3) moving and pulling it upward.
5. Remove the slit washer (4).
6. Remove the idle up/down lever (5) and the idle arm (6) simultaneously from two claws (B) on the mechanical deck.
7. After cleaning the center gear post (7) using a cleaning kit, apply a few drops of oil to the shaded portion on the center gear post.
8. Mount the parts in the reverse order of removal.

Notes:

- Stop ring (1) is impossible to use again.
- When mounting the parts, take care of the notice shown in Fig. 2-1-60.




Fig. 2-1-59




Fig. 2-1-60

1-6-34. Holder Center Post Assembly Replacement

1. Turn over the mechanical deck and remove the center gear pulley and the idle arm. (Refer to item "1-6-33. Idle Arm Assembly Replacement".)
2. Turn over the mechanical deck and remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Assembly Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. After removing two screws (1), replace the holder center post assembly (2).
5. After replacing, mount the parts in the reverse order of removal.




Fig. 2-1-61

Notes:

- When mounting, push the cutout (A) on the holder center post assembly (2) aligning with the projection on the mechanical deck.
- Screw tightening torque is 294 – 392 mN•m (3 – 4 kg•cm).
- Before mounting the center gear pulley, apply a few drops of oil. (Refer to Fig. 2-1-59.)

1-6-35. REC Inhibiting Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
4. Remove the tension spring (2).
5. Undo the claw (A) on the S soft brake (1) sliding and lifting it upward.
6. Remove the projection (B) on the REC inhibiting lever (3) sliding in the direction shown by the arrow and lifting it upward.
7. After replacing the REC inhibiting lever (3), mount the parts in the reverse order of removal.




Fig. 2-1-62

1-6-36. S, T Main Brake Assembly Replacement

1. Remove the mechanical deck from the main PC board and turn the mechanical deck upside down.
2. When replacing the T main brake assembly (2), first remove the idle kick lever (3). (Refer to item "1-6-33. Idle Arm Assembly Replacement".)
3. Remove the tension spring (4).
4. Remove the claws on the S, T main brakes (1), (2) from the mechanical deck lifting the S, T main brakes (1), (2) upward.
5. After replacing the S, T Main brake assemblies (1), (2), mount the parts in the reverse order of removal.

Note:

- When mounting the S, T main brake assemblies (1), (2) take care that both ends of the S, T main brakes (1), (2), do not touch the gear of the reel table.




Fig. 2-1-63

1-6-37. S Soft Brake Replacement

1. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
2. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
3. Remove the S soft brake spring (1).
4. Remove the S soft brake (2) after removing the claw (A) on the S soft brake from the mechanical deck.

Notes:

- When mounting the S soft brake spring (1), take care not to deform the hook (B).
- When mounting the S soft brake (2), take care of the band brake (3).




Fig. 2-1-64

1-6-38. T Soft Brake Replacement

1. Remove the T soft brake spring (1).
2. Remove the claw (A) on the T soft brake (2) from the mechanical deck and remove the T soft brake (2).
3. After replacing the T soft brake (2), mount the parts in the reverse order of removal.

Notes:

- When mounting the T soft brake spring (1), take care not to deform the hook (B).
- Take care not to touch the surface (C) on the brake pad.




Fig. 2-1-65

1-6-39. Drive Lever Replacement

1. Remove the top bracket. (Refer to item "1-6-1. Top Bracket Replacement".)
2. Remove the cassette holder assembly. (Refer to item "1-6-2. Cassette Holder Assembly Replacement".)
3. Remove the drive arm assembly. (Refer to item "1-6-5. Drive Arm Assembly Replacement".)
4. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
5. Remove the Loading Drive Assembly. (Refer to item "1-6-28. Loading Drive Assembly Replacement".)
6. Remove the drive lever (1).

7. After replacing the drive lever (1), mount the parts in the reverse order of removal.

Notes:

- Be sure to align the phase of the cam gear (2). (Refer to item 1-6-40. Cam Slider Replacement".)
- Mount the drive lever (1) so that it is positioned between the mark (A) on the mechanical deck and the outsert (B).
- Apply grease to the surface between the mark (C) on the mechanical deck and the drive lever shaft (D).




Fig. 2-1-66

1-6-40. Cam Slider Replacement

1. Remove the top bracket and the cassette holder assembly. (Refer to item "1-6-1. Top Bracket Replacement and 1-6-2. Cassette Holder Assembly Replacement".)
2. Remove the tension spring (1).
3. Turn the hook lever assembly (2) counterclockwise and turn the S soft brake (3) counterclockwise.
4. Move the cam slider (4) to the right and align the projection (A) on the mechanical deck and the cutout portion (B) on the cam slider (4).
5. Remove the claw (C) on the cam slider (4) and remove the cam slider (4) lifting the cam slider (4) upward.




Fig. 2-1-67

6. Apply grease on the shaded portion of a new slider for the replacement.
7. Mount the parts in the reverse order of removal. After inserting the cam slider, slide it to the left direction till it stops. (Fig. 2-1-48 shows this condition.)

Notes:

- When mounting the cam slider (4), slide the tension drive lever in the direction shown by the arrow (counterclockwise).
- After completion of the replacement, confirm that the cam slider (4) can slide to left and right directions smoothly.




Fig. 2-1-68

1-6-41. Idle Centering Lever Replacement

1. Remove the cam slider. (Refer to item "1-6-40. Cam Slider Replacement".)
2. Remove the claw on the idle centering lever (1) and remove the idle centering lever (1) lifting it upward.
3. After replacing the idle centering lever (1), mount the part in the reverse order of removal.




Fig. 2-1-69

1-6-42. Capstan Motor Replacement

1. Remove the reel belt (1).
2. Remove one screw (2) from the bottom of the mechanical deck, and remove the PC board (3).

Note:

- Take care not to misuse the screw with others.




Fig. 2-1-70 View from mechanism deck bottom side

3. Remove the capstan motor (4) after removing three screws (5).

Note:

- Take care not to drop the capstan motor.




Fig. 2-1-71

4. Take care not to damage and scratch the motor itself, and mount the capstan motor (4) fitting the hole (A) on the mechanical deck and the hole (B) on the capstan motor (4).




Fig. 2-1-72

5. Mount the capstan motor (4) with three screws (5) viewing from the top side of the mechanical deck.




Fig. 2-1-73

Notes:

- Do not use once-removed screws again.
 - Take care that no clearance is allowed when securing three screws.
6. After replacement, mount the parts in the reverse order of removal.

Note:

- In this case, take care not to twist the reel belt and stick the grease or etc. on it.
7. After replacing, perform the adjustment according to the tape transport adjustment procedures.

1-6-43. S-VHS Switch Assembly Replacement (S-VHS model only)

1. Slide the cassette holder assembly (1) until the screw (2) can be seen from the hole on the top bracket (3).
2. Insert a screwdriver from the hole provided on the top bracket (3) and secure the screw (2).
3. Remove the S-VHS switch assembly (4) upward.
4. After completion of the replacement, mount the parts in the reverse order of removal.




Fig. 2-1-74

1-7. Check and Adjustment

1-7-1. Check of Tension Pole Position

1. Turn the worm wheel counterclockwise after removing the cassette holder assembly on the front loading mechanism, and set the cam gear at playback position.
2. Turn the S reel table assembly (1) clockwise slowly.
3. Adjust the adjuster (3) counterclockwise from the position shown in Fig. 2-1-40 so that the clearance between the left end of the tension lever assembly (2) and the left side of the mechanical deck becomes 7.5 ± 1 mm.

Note:

- There is a long mark at the position of 7.5 mm from the round surface of the mechanical deck. Make sure the position of the mark when adjusting.




Fig. 2-1-75

1-7-2. Reel Torque Check

(1) Reel torque

1. REVIEW mode (supply side)

Poor torque may not wind the tape. On the other hand, excessive torque will cause damage to the tape during REVIEW mode.

2. Record/Playback mode (take-up side)

Too little torque does not rewind the tape to the end. If too large torque, the tape may be stretched by excessive tension.

3. Inspection

Rewind the torque cassette to the end, then check the torque values shown below:

Review	$15.95 \pm 3.65 \text{ mN}\cdot\text{m}$ ($162.5 \pm 37.5 \text{ g}\cdot\text{cm}$)
--------	--

Record/Playback	$6.85 \pm 2.45 \text{ mN}\cdot\text{m}$ ($70 \pm 25 \text{ g}\cdot\text{cm}$)
-----------------	--

For checking method, refer to the following item (2).

(2) Reel torque and back tension check

1. First, record a TV broadcast program on the entire torque cassette tape (KT-300NR) in the SP mode.
2. Load the torque cassette tape (KT-300NR) in the VTR and feed it forward until the end of the tape, before proceeding with measurement.
3. Set the VTR to the REVIEW mode and feed the tape for about 15s, and then make sure the take-up torque described above is obtained while observing the left torque meter.
4. After completion of step 3), feed forward to tape start position and set the VTR to the PLAY mode and feed the tape for about 30s. Read the right torque meter and check the torque described above is obtained.
5. If the review torque and playback torque are out of limit, replace the clutch assembly.
6. When the S reel table assembly, the T reel table assembly and the idle arm assembly are replaced, perform the reel torque check.

<Precautions for Use of Torque Cassette (KT-300NR)>

1. Before loading a torque cassette in a VTR, always remove tape slack. The tape slack can be removed by rotating the reel to its take-up direction. (The tape tends to slack when there is no reel brake actions.)
2. When the torque cassette is loaded, confirm followings:
 - Make sure the tape does not ride up or over the No. 8 cap. If it does, do not eject the tape but return the tape to its correct position, taking care not to damage the tape.
 - Make sure the tape is not slackened. If slackened, operate the VTR in FF or REW mode and then stop the tape. Then make sure the tape is not slackened again.
 - After above confirmation, proceed to the reel torque adjustment and confirmation.
3. Caution for removal of torque cassette
 - When removing the torque cassette from the VTR, set the VTR to the STOP mode and wait for several seconds. Then, make sure the tape is not slackened. Push the EJECT button to remove the cassette.
4. If the previous precautions 1), 2) and 3) are not performed properly, the tape may be damaged and correct measurements can not be performed.
5. Do not use worn out or damaged tape, if used they may damage video heads on the cylinder. In such a case always replace the tape with a new one. The replacement tape is of E-180, 10 m in length.

1-7-3. Tape Transport System

The tape transport system has been precisely adjusted in the factory, so no check and alignment are necessary except the followings:

- Noises observed on the screen
- Tape damage
- Parts, shown in the adjustment procedures for the tape transport system were replaced.

Electrical signal output terminal required for adjustment differs depending upon the models. Refer to the test point location in the Electrical Adjustment Section.

(1) Location of tape transport adjustment

<Adjustment reference>

Lower flange height of No. 8 guide is used as the basic reference for the transport adjustment. To keep height of the No. 8 guide, do not apply excessive force onto the main base to prevent the main base from deformation.

Rectangles shown in Figs. 2-1-76, 2-1-77 show the adjusting locations.




Fig. 2-1-76 Tape travel diagram





Fig. 2-1-77 Location of tape transport adjustment

(2) Tape transport system adjustment flow chart






Fig. 2-1-78

(3) Tape transport system adjustment

<Pre-adjustment>

When the part(s) listed in Table 2-1-5 is replaced, perform required adjustments by referring to procedures for the tape transport system. When the part(s) listed in Table 2-1-5 is replaced, the tape path may be changed and may damage alignment tape. To prevent this, first run a E-240 tape and make sure excessive tape wrinkle does not occur at each tape guide.

1. If tape wrinkle is observed at the S, T guide rollers, turn the S, T guide rollers until wrinkle disappears.
2. If tape wrinkle is observed at the No. 8 guide, perform the tilt adjustment of the ACE head.

Table 2-1-5

Parts replacement	Adjustment procedure
<ul style="list-style-type: none"> • Cylinder assembly • S, T sliders • ACE head • Pinch lever assembly • Capstan motor • No. 9 guide lever assembly 	From item 1)
<ul style="list-style-type: none"> • Upper cylinder 	From item 2)
<ul style="list-style-type: none"> • S, T guide rollers • Tension lever assembly • FE head 	From item 3)
<ul style="list-style-type: none"> • Reel clutch assembly • S, T reel tables 	From item 4)

<Adjustment procedures>

1) ACE head assembly coarse adjustment

a. Audio head height adjustment

1. Playback the tape recorded in the SP mode. Observe the surface of the ACE head.
2. Turn the ACE height adjusting screw so that upper tape edge matches to the upper edge of the audio head core.

b. ACE head tilt adjustment

1. Playback the tape recorded in the SP mode and observe running condition of the tape at the lower flange of No.8 guide.

2. Turn the ACE tilt adjusting screw until tape wrinkle is caused at the lower flange of No. 8 guide as shown in Fig. 2-1-80 (A).
3. Turn the ACE tilt adjusting screw counterclockwise until the tape travels along the lower flange as shown in Fig. 2-1-80 (B).

c. Audio head azimuth adjustment

1. Playback the 7 kHz audio signal on the alignment tape in the SP mode.
2. Connect a millivoltmeter or oscilloscope to the audio line output terminal.
3. Turn the ACE azimuth adjusting screw to obtain maximum audio output.




Fig. 2-1-79




Fig. 2-1-80 No. 8 guide rough adjustment

d. ACE head position adjustment

1. Playback the 2 MHz video envelope signal in the alignment tape in the SP mode. Loosen the ACE head position securing screw.
2. Insert a slot-type screwdriver into the ACE head position adjusting slit on the ACE main base and adjust the ACE main base so that the video envelope reaches a peak level at the tracking center position when the channel (tracking) up/down buttons of VTR are pressed simultaneously.

2) Playback phase adjustment

1. Perform the adjustment according to the methods stated in the electrical adjustment (servo circuit).

3) Linearity adjustment

1. Playback the LP mode white video signal on the alignment tape.

Note:

- For models SP mode only, use the 2 MHz (A ch) video signal in the SP mode.
- 2. Trigger the scope with the switching pulse to issue the envelope signal output.
- 3. Make sure the video envelope waveform (in its maximum output) meets the specification shown in Fig. 2-1-81. Again make sure the same by playing back the SP mode 2 MHz video signal on the alignment tape. If not satisfied, adjust as follows:

Note:

- a = maximum output of the video RF envelope
- b = minimum output of the video RF envelope at the entrance side
- c = minimum output of the video RF envelope at the center point of cylinder
- d = minimum output of the video RF envelope at the exit side of cylinder




Fig. 2-1-81

4. If the (A) section in Fig. 2-1-82 does not meet the specifications, adjust the S guide roller in up or down direction.
5. If the (B) section in Fig. 2-1-82 does not meet the specifications, adjust T guide roller in up or down direction.




Fig. 2-1-82

6. After completion of the adjustment(s), push the channel (tracking) up/down button and make sure video envelope variations are almost flat. Next, playback the 2 MHz SP mode video signal on the alignment tape and makes the video RF envelope variations are also flat when channel (tracking) UP/DOWN buttons is pushed.
7. If the envelope varies like NG figures as shown in Fig. 2-1-83, perform the adjustment again. Smooth secondary curves are allowable level.




Fig. 2-1-83 Abnormal waveform variation

4) ACE head assembly fine adjustment

a. ACE head height fine adjustment

1. Playback the stereophonic alternative recording 300 – 500 Hz audio signal on the alignment tape.
2. Adjust the ACE height adjusting screw so that the signal envelope is obtained almost flat.




Fig. 2-1-84

Note:

- If there is no alignment tape (ST-C6, ST-C7), do not perform this item "a. ACE head height fine adjustment", and perform the process of the note in item "e. Audio head height check" described later.

b. ACE tilt adjustment

1. Observe the lower flange of No. 8 guide. If any wrinkle is observed, turn the ACE tilt adjusting screw counterclockwise until the wrinkle disappears.
2. If a gap is observed between the lower flange of No. 8 guide and the lower edge of tape, turn the ACE tilt adjusting screw clockwise until the tape travels along the lower flange.

Note:

- This adjustment is performed easily in SP mode playback, double speed playback mode or CUE mode.

c. Audio head height check

1. Playback the stereophonic alternative recorded 300 – 500 Hz audio signal as described in the step 4)-a, and check if the audio envelope is flat. If not, repeat the adjustment described in step 4)-a again.

d. Audio azimuth adjustment

1. Playback the 400 Hz, 7 kHz audio signal on the alignment tape.
2. Turn the ACE azimuth adjusting screw until the maximum audio output is obtained.

e. Audio head hight check

1. Playback the alignment tape described in step 4)-a and check if the audio envelope is flat. If not, repeat the adjustment described in step 4)-a.

Note:

- If there is no alignment tape (ST-C6, ST-C7), perform the audio height alignment using the current alignment tape at this adjustment step.

1. Playback the 400 Hz audio signal (SP mode) on the alignment tape.
2. Turn each three alignment screw of the ACE head to the same direction in 45 degrees steps evenly so that the audio output level becomes maximum.
3. Perform the confirmation and adjustment for the tilt and the azimuth again.

f. ACE head postion adjustment

1. Playback the white envelope (LP mode) on the alignment tape.
2. Push the channel (tracking) up/down buttons simultaneously and reset the tracking at its center position.

3. Trigger the oscilloscope with the video switching pulse and observe the video envelope waveform.
4. Slide the ACE main base until the maximum envelope output is obtained as described in ACE head position coarse adjustment.
5. Playback the 2 MHz video signal (SP mode) on the alignment tape.
6. Make sure the envelope output is maximum when the tracking control is placed at its center position. If no envelope output is obtained with the tracking control set to the center position, again adjust it for maximum envelope output in SP and LP modes. When envelope output is maximum in the LP mode at the tracking center, difference with the case in the SP mode is within 3 ms.
7. Tighten the ACE head position fixing screw and secure the ACE main base.
- g. After completion of ACE head fine adjustment, apply screw lock to two screws (tilt, azimuth adjusting screws) in front of the ACE head.

5) No. 9 guide lever adjustment

1. Set the VTR to Cue mode with E-240 tape (at beginning portion) loaded. Switch the Cue mode to the review mode when the tape has been rewound into the T-reel table to some extent.
2. Check tape wrinkle at the upper and lower flange of No. 8 guide. Check the tape does not come off from the flange while running. If the tape comes off from the flange, replace the pinch lever, capstan motor or No. 9 guide lever since the part(s) is (are) defective.

Note:

- Modify the lid of the cassette for the alignment tape E-240 previously so that the alignment is performed easily.

6) Check for transitional operation from Review to Play, slot-in to play

1. Playback the LP mode white video signal on the alignment tape in Review mode and observe the video envelope with the oscilloscope.
2. Switch the Review mode to the Play mode. When switched to the Play mode, make sure the entrance side envelope comes to an approximate steady state within 3s as shown in Fig. 2-1-85.

If it does not rise within 3s, take the following steps starting 4).

3. Switch the cassette slot-in mode to the Play mode. As in item 2), if it does not rise within 3s, adjust as follows.




Fig. 2-1-85 Video envelope rising when operation mode is switched from review to play mode

4. Adjust the S guide roller and perform the linearity adjustment again.
5. Check above items 2) and 3) to see that the video envelope rises within 3s. If not, S slider assembly or the tension lever is damaged. Replace either (or both) of them.

Note:

- If the rising characteristic is poor in Review mode, screen noise may occur in synchronous editing recording. Perform the adjustment carefully.

7) Envelope check

1. Make recordings and playback the tapes (E-180 and E-240) in SP and LP modes and make sure the playback output envelope meets the specifications shown in Fig. 2-1-81.
2. In playback the tape (with a E-180), the video envelope should meet the specification as shown in Fig. 2-1-86.

Note:

- Check for both modes, SP and LP. Also check for AFM envelope when using a Hi-Fi model.




Fig. 2-1-86 Envelope output and output difference

3. If the performance does not meet both specifications above 1 and 2 above, replace the upper cylinder assembly.

4. Set the VTR to Rec mode (LP) with the E-180 tape loaded (at the beginning part) and check operation of the synchronous editing recording.
5. If picture noises are observed at the starting position of the editing, perform "6) Check for transitional operation from Review to Play, slot-in to play".

8) Tape wrinkle check

1. Playback the E-240 tape in the normal Play mode, CUE mode, Review mode and the frame advance mode, and check each guide for wrinkle.
2. If excessive tape wrinkle is observed at the mode shown below, perform the associated adjustments also shown below. (The parts described in () may need to replace.)

a. Playback mode

Tape wrinkle at the S, T-guide rollers section

Item 3) Linearity adjustment
(Slider assembly)

Tape wrinkle at No. 8 guide flange

Item 1) ACE head assembly coarse adjustment
(Pinch roller)

Tape wrinkle at lower flange of No. 1 guide

Item 6) Check for transitional operations from
Review to Play, and Slot-In to Play
(Tension lever)

b. Review mode

Tape wrinkle at No. 8 guide

Item 1) ACE head assembly coarse adjustment
(Pinch lever, No. 9 guide lever,
capstan motor)

Tape wrinkle at the guide rollers

Guide roller adjustment (Slider assembly)

c. Frame advance mode

Tape wrinkle at No. 8 guide

Item 3) Linearity adjustment
(Pinch lever, capstan motor)

9) Maximum AFM envelope output point check (Hi-Fi model)

1. Playback the SP mode 3 MHz video signal and the 400 Hz AFM signal on the alignment tape.
2. Trigger the oscilloscope with the video switching pulse, adjust the tracking control and check the control pulse phase at the maximum video envelope (A ch) output point.
3. Make sure the control pulse phase difference among each maximum point of AFM envelope, Ach and Bch is within ± 3 ms with the above point used as the basic reference.

Note:

- If the phase difference exceeds 3 ms, replace the upper cylinder.

<Color bar signal>

Color bar signals of 75% recorded on the alignment tapes are shown in Fig. 2-2-1.




Fig. 2-2-1

2. ELECTRICAL ADJUSTMENT

<Test equipment required>

Adjustment will be performed with the following test equipment.

1. Color TV (Monitor)
2. Oscilloscope, 2 CHs, 15 MHz or higher with delay system
3. Frequency counter (7 digits or higher)
4. Millivoltmeter
5. Digital voltmeter
6. Tester (20 k Ω /V)
7. Audio generator
8. Audio attenuator
9. Alignment tapes
Part code: ST-C6: 70909409, ST-C7: 70909410
10. Alignment screw driver (jig)
11. Color pattern generator
12. Video sweep generator

<Specified input and output levels, and impedance>

- Video input: Negative sync, standard composite video signal 1 V(p-p), 75 Ω
- Video output: Same as the video input 1 V(p-p), 75 Ω
- Audio input: 308 mV(rms), more than 47 k Ω (phono type), more than 10 k Ω (21 pin type)
- Audio output: 308 mV(rms), less than 4.7 k Ω (phono type), less than 1.0 k Ω (21 pin type)

<Alignment sequence>

Recorded the alignments in the sequence as shown in Fig. 2-2-2.





Fig. 2-2-2

Alignment tape specifications

[1] ST-C6

Table 2-2-1

Segment	System	Playback Time (min)	Video Signal	Audio Signal	Applications
1	PAL & SECAM	10	Mono Scope	1 kHz	Playback phase check, audio level check
2	PAL & SECAM	5	3 MHz A ch	400 Hz and 7 kHz	ACE head position adjustment, ACE head azimuth adjustment, Linearity adjustment
3	PAL & SECAM	5	3 MHz A ch	1 kHz (stereo)	ACE head position adjustment, ACE head height adjustment, Linearity adjustment
4	PAL	5	Color bar	3 kHz	Video and Sound checks
5	SECAM	5	Color bar	3 kHz	Video and Sound checks
6	MESECAM	5	Color bar	3 kHz	Video and Sound checks
7	NTSC	5	Color bar	1 kHz	Video and Sound checks

[2] ST-C7

Table 2-2-2

Segment	System	Playback		Video Signal	Audio Signal	Applications
		Time (min)	Mode			
1	PAL	5	LP	3 MHz A ch	500 Hz (stereo)	ACE head position adjustment, ACE head height adjustment, Linearity adjustment
2	PAL	3	LP	Color bar	3.2 kHz	LP mode operation check, ACE head azimuth check and adjustment
3	PAL	3	SP	Color bar	AFM 400 Hz	SP mode operation check, AFM check
4	PAL & SECAM	5	SP	3 MHz A ch	AFM 400 Hz	AFM tracking checks
5	SECAM	5	LP	3 MHz A ch	No signal	Linearity adjustment
6	SECAM	3	LP	Color bar	No signal	LP mode operation check
7	SECAM	3	SP	Color bar	AFM 400 Hz	SP mode operation check, AFM check

2-1. Servo Circuit




Fig. 2-2-3 Main PC board




Fig. 2-2-4 Terminal/Audio PC board

2-1-1. Playback Phase (PG) Adjustment

Test point: Pins 1 and 2 of BW001, Pin 19 of BX101 (Video out)

Test equipment: Oscilloscope

1. During playback press the VTR's channel up and down buttons simultaneously to reset to tracking center.
2. Confirm that phase difference between the fall of the DFF pulse (pin 1 of BW001) and the rise of CTL pulse (pin 2 of BW001) is 12 ± 0.5 ms.
3. Further, observe the envelope (pin 4 of BW001) waveform, and confirm that the ACE head position adjustment and linearity adjustment have been made, and C-SYNC (pin 70 of IT001) is being input during playback.
4. Set the VTR to the STOP mode.




Fig. 2-2-5

5. Press the unit's channel up/down buttons simultaneously for more than 5s.
6. Afterwards, within 2s, press the PLAY button on the remote controller.
7. The automatic adjustment will be made for about 10s, all the displays will blink. If the automatic adjustment is not carried out, confirm that the alignment tape has a safety tab or not, and redo from the step 3.
 - 1) When adjustment has been completed:
The display will blink for 10s, stop blinking and return to the normal display in the STILL mode for 1.2s, then it shifts to the playback display in the playback mode.
The display is as shown below.




Fig. 2-2-6

- 2) When adjustment fails:
It goes into the STOP mode.
8. Confirm that the play indicator is displayed, and confirm that the rising and falling edge of the SW pulse is $6.5 \pm 0.5H$ from the V-sync front edge of the video signal.

2-1-2. When IT004 is Replaced

When IT004 is replaced, the data in the VTR is required to memorize in the new one. So perform the following procedures.

1. Press the channel up/down buttons on the VTR simultaneously for more than 5s while the display blinks and the unit is in the power off mode.
2. And then within 2s, press the CANCEL button on the remote controller.
3. After displaying the address at the channel display area and the data at the minute display area, set the address to 12 using the channel up/down buttons on the remote controller.
Next, set the data to C3 using the FF/REW buttons on the remote controller. The data goes up using FF button and down using REW button.




Fig. 2-2-7

4. Set each address and data in the table below following the description above.

Table 2-2-3

Address	Data
24	0A
25	03
26	15
27	0A

5. Perform the adjustment described in the item "2-1-1. Playback Phase (PG) Adjustment".
6. Pull out the power cord plug from the AC outlet once and insert the power cord plug into the AC outlet again.
7. Perform the channel presetting as the IT004 replaced has no channel data.

2-2. Self Diagnosis Function

2-2-1. Outline

When a tape running stops or the VTR enters the power OFF mode, etc. due to some abnormality, the abnormality is stored in the EEPROM and displayed on the display tube.

2-2-2. Storing abnormal modes

- The abnormality is classed into 5 groups, and the abnormality number, system control mode, and the mechanism position at which the abnormality occurred are stored in the EEPROM.
- The writing timing is just after the abnormality occurred.

2-2-3. Abnormality mode display

- Press the CH UP and CH DOWN buttons on the VTR simultaneously for more than 5s.
- And then within 2s, press the STILL button on the remote control.
- The system control mode at which the abnormality occurred is displayed at the channel display area, "E" is displayed at the hour digit, abnormality generation number is displayed at the minute digit, and the mechanism position is displayed in the second digit position.
- The abnormality mode is displayed regardless of the power on off.




Fig. 2-2-8

- When the Counter Reset button is pressed in the display period, the abnormality display data is initialized and "-" is displayed.

The data displayed are as follows:

Table 2-2-4 Abnormality generation number

01	Cylinder stop
02	Reel abnormality (take up)
03	Reel abnormality (supply)
04	Abnormal slot in/ slot out
05	Abnormal loading

Table 2-2-5 Abnormal system control modes

00	Standby
01	Stop
02	Rewind
03	Review
04	FF
05	Cue
06	Playback
07	Still, slow playback
08	X2 speed
09	Unloading stop
0A	Reverse playback
0b	Still in reverse playback, Reverse slow playback
0C	Recording
0d	Record pause
0E	Power off eject
0F	Eject
10	Short FF
11	Short REW

Table 2-2-6 Abnormal mechanism positions

01	F/L out
03	F/L down
05	Loading/unloading
07	Reverse rotation with pinch roller ON
09	Playback with pinch roller ON
0b	Stop with main brake ON
0d	FF/REW
0F	Position detection impossible

Positions 0, 2, 4 exist as mechanism positions. For example, 8 shows a position between 7 and 9 (between playback position and review position).

2-3. 3DNR Module Troubleshooting Flow Chart

Chart

3DNR module (HR001) is checked with the following procedures, and if some defects are found, replace the module with new one.

2-3-1. Example of Operation Check Procedure

(1) Preparing equipments

- V-858B
- Standard color bar generator
- Alignment tape

(2) Connection procedure




Fig. 2-2-9

(3) Operation check procedure

Turning [3DNR] off. → Playback the tape which the color bar signal is recorded. → Turning [3DNR] on after checking whole murky noises on the color bar. Be sure that whole noises are reduced in this status.

2-3-2. Troubleshooting Flow Chart

Procedure 1.

- First, check the power supply voltage and the installation state of the 3DNR module.

Procedure 2.

- Classify the defective symptoms into groups.
- Check the screen on playback according to the operation check procedure 2-3-1.

Procedure 3.

- Check the defects according to the flow chart.

Table 2-2-7

No.	Defective symptoms	Flow chart
(1)	No display appears when playing-back, or large turbulence and noises occur.	A
(2)	No color appears when playing-back, or color noises appear a lot.	B

A: No display appears when playing-back, or large turbulence and noises occur.




Fig. 2-2-10

B: No color appears when playing-back, or color noises appear a lot.




Fig. 2-2-11

SECTION 4

PARTS LIST

SAFETY PRECAUTION

The parts identified by Δ mark are critical for safety. Replace only with part number specified.

The mounting position of replacement is to be identical with originals.

The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

NOTICE

The part number must be used when ordering parts in order to assist in processing, be sure to include the model number and description.

Parts marked # are of chip type and mounted on original PC boards.

However, when they are placed for servicing works, use discrete parts listed on the parts list.

ABBREVIATIONS

1. Integrated Circuit (IC)

2. Capacitor (Cap)

- Capacitance Tolerance (for Nominal Capacitance more than 10pF)

Table 4-2-1

Symbol	B	C	D	F	G	J	K	M	N
Tolerance %	± 0.1	± 0.25	± 0.5	± 1	± 2	± 5	± 10	± 20	± 30

Symbol	P	Q	T	U	V	W	X	Y	Z
Tolerance %	+ 100 0	+ 30 - 10	+ 50 - 10	+ 75 - 10	+ 20 - 10	+ 100 - 10	+ 40 - 20	+ 150 - 10	+ 80 - 20

Ex. 10 μ F J = 10 μ F $\pm 5\%$

- Capacitance Tolerance (for Nominal Capacitance 10pF or less)

Table 4-2-2

Symbol	B	C	D	F	G
Tolerance pF	± 0.1	± 0.25	± 0.5	± 1	± 2

Ex. 10pF G = 10pF ± 2 pF

3. Resistor (Res)

- Resistance tolerance

Table 4-3-1

Symbol	B	C	D	F	G	J	K	M
Tolerance %	± 0.1	± 0.25	± 0.5	± 1	± 2	± 5	± 10	± 20

Ex. 470W J = 470W $\pm 5\%$

4. EXPLODED VIEWS

4-1. Packing Assembly




Fig. 4-4-1

4-2. Remote Control Unit




Fig. 4-4-2

4-3. Cabinet Assembly




Fig. 4-4-3

4-4. Chassis Assembly




Fig. 4-4-4

4-5. Mechanism Assembly (1)




Fig. 4-4-5

4-6. Mechanism Assembly (2)




Fig. 4-4-6

5. PARTS LIST

LOCATION NUMBER	PART NUMBER	DESCRIPTION	LOCATION NUMBER	PART NUMBER	DESCRIPTION
- MECHANICAL PARTS -			K220	70396337	Washer
△0001C	70062072	Owner's Manual English	K222	70396336	Washer
0010C	70148913	Remote Control Unit	K223	70326716	Center Post Assy
0013C	70011442	Cable	K226	23723002	Screw 2. 6x6mm
△0014C	70012246	Mains Cord	K242	70326698	Tension Lever Sub Assy
0155F	70052211	Cassette Door	K252	70353149	Band Brake Assy
0170F	70051372	Spring	K254	70361598	Band Holder
△0220	70052226	Front Panel	K260	70356324	Spring
0240	70051999	Knob	K270	70363315	Hook Lever
0245	70052000	Knob	K280	70363316	Hook Lever
0250	70070025	Screw, 2. 6x6mm	K290	70363317	Tension Drive Lever
△0260	70051766	Bottom Plate	K320	70363250	Rec Inhibit Lever
0275	70031485	Screw	K330	70326710	S Main Brake Assy
0285	70051391	Rubber Foam	K340	70326711	T Main Brake Assy
0286	70869451	Insulator(Right)	K350	70356330	Spring
0287	70869452	Insulator(Left)	K360	70363345	S Soft Brake Lever
△0290	70051181	Top Cover	K370	70356331	Spring
0300	70030702	Screw	K380	70326712	T Soft Brake Assy
0340	70061715	Packing(Rear)	K390	70356332	Spring
0350	70061714	Packing(Front)	K402	70363462	Drive Lever
0360	70062233	Case	K410	70366175	Cam Slider
9070C	70062062	Quick Reference Manual	K420	70356333	Spring
AT03	70108916	Case Battery	K430	70363347	Idle Up Down Lever
B218	70379660	Center Holding Post	K440	70363348	Idle Kick Lever
B410	70322511	Loading Drive Assy	K450	70363349	Idle Centering Lever
B424	70322513	Loading Motor Sub Assy	K470	70363446	Cam Lever
B432	70145370	Cam Switch	K480	70376040	FL Drive Slider
B435	70322521	Loading Drive Unit	K490	70324901	Cassette Holder Assy
B440	70333454	Cam Gear	K530	70324887	Drive Arm Assy
B450	70322514	S Loading Assy	K550	70333457	Drive Lever Gear
B470	70322516	T Loading Assy	K562	70361608	Arm Brake Lever
B490	70322518	Loading Slider Assy	K564	70356339	Spring
B500	70396193	Washer FI 2. 6x6x 0. 5mm	K570	70371988	Top Bracket
B560	70125704	Capstan Motor Assy	K580	23712308	Screw 3x0. 5x8mm
B570	70391024	Screw 2. 6x6mm	K590	70031483	Door Open Lever
B580	70031881	Belt Reel	U501A	70070070	Screw
G001S	70031739	Cylinder Assy			
G010	70031444	Plate(Cylinder)			
G020	70031643	Screw 2. 6x5mm			
G021	70031644	Screw 2. 6x5mm			
G030	70031445	Plate(Cylinder)			
G040	70031644	Screw 2. 6x5mm			
G060	70031449	Screw			
G101	70031695	Upper Cylinder Assy			
G101A	70031521	Screw			
G102	70031741	Lower Cylinder Assy			
G103	70031683	Ground Cap Assy			
G181	70391422	Screw 2x4mm			
G410	70338212	Guide Sleeve			
G420	70322508	S Slider Assy			
G428	70322435	Roller Assy			
G448	70353153	O ring			
G450	70322506	T Slider Assy			
G458	70322438	Roller Assy			
G478	70353153	O ring			
G480	70318593	ACE Head Assy			
G484	70182100	ACE Head Sub Assy			
G498	23901248	Socket, 7P			
G506	23712208	Screw 2x8mm			
G510	70391824	Screw 2. 6x10mm			
G520	70326704	No. 9 Guide Lever Assy			
G530	70183019	FE Head			
G560	70326762	Pinch Lever Assy			
G580	70326708	Pinch Drive Assy			
G590	70356326	Spring			
G680	70031493	Cleaner Lever Assy			
G690	70031540	Ground Brush			
K110	70327126	S Reel Assy			
K130	70396329	Washer			
K140	70327128	T Reel Assy			
K170	70396329	Washer			
K180	70327137	Idle Arm Assy			
K200	70333450	Center Gear Pulley			

LOCATION NUMBER	PART NUMBER	DESCRIPTION
- ELECTRICAL PARTS -		
0050	70095278	Main Assy
0005M		P C Board Assy Main
- INTEGRATED CIRCUITS -		
II050	70012805	IC TDA9817
△IP050	70012894	IC K324PG
IS001	70012895	IC LA7286
IT001	70012910	IC TMP90CS74EDF-6724
IT002	70011888	IC TA7291S
IT003	70011887	IC TB6515AP
IT004	70012489	IC ST24C08/CB1
IT005	70011808	IC PST7032MT
IV001	70012911	IC LA71528AM
IV100	70012843	IC LC89977M
IV401	70012824	IC MM1226XFB
IV500	70012823	IC LA7217M
IY001	70012842	IC SDA5650X
IZ100	70012913	IC TCE2ACU
- TRANSISTORS -		
GT005	70010181	Transistor, Photo PT493F
GT006	70010181	Transistor, Photo PT493F
TI011	70010150	Transistor BC848B
TI020	70011393	Transistor MMBTH10LT1
TI055	70010150	Transistor BC848B
TP020	70012897	Transistor, FET STP3NA90
TP022	70010131	Transistor BC337-40
TP023	70010142	Transistor BC327-40
TP071	70010947	Transistor BC858
TP082	70010947	Transistor BC858
TP086	70010150	Transistor BC848B
TS002	A6004020	Transistor, Chip RN1402
TS004	A6004020	Transistor, Chip RN1402
TS030	A6319311	Transistor 2SC1959-Y
TS051	70010150	Transistor BC848B
TS052	A6319311	Transistor 2SC1959-Y
TT001	A6004040	Transistor, Chip RN1404
TT002	A6004040	Transistor, Chip RN1404
TT003	70010150	Transistor BC848B
TT004	70012032	Transistor, Chip 2SA1162GR
TT005	70011386	Transistor 2SA1020-Y
TT006	70010150	Transistor BC848B
TT013	70010947	Transistor BC858
TV001	70010150	Transistor BC848B
TV002	A6004020	Transistor, Chip RN1402
TV003	70010150	Transistor BC848B
TV004	70010150	Transistor BC848B
TV005	70010947	Transistor BC858
TV008	70010150	Transistor BC848B
TV009	70011788	Transistor, Chip RN2402
TV010	A6004020	Transistor, Chip RN1402
TV012	70010150	Transistor BC848B
TV013	70010947	Transistor BC858
TV014	70010150	Transistor BC848B
TV401	70010947	Transistor BC858
TV402	70010150	Transistor BC848B
TV403	70010947	Transistor BC858
TV404	A6004020	Transistor, Chip RN1402
TV405	70010947	Transistor BC858
TW001	70010150	Transistor BC848B
TW002	A6014030	Transistor, Chip RN2403
TW003	A6325549	Transistor 2SC2236-Y
TW004	70012921	Transistor 2SC3279M
TW005	70012920	Transistor 2SA1300GR
TW006	70010134	Transistor BC548B
TW007	70010134	Transistor BC548B
TW008	70011788	Transistor, Chip RN2402
TW009	70010131	Transistor BC337-40
TW010	70010142	Transistor BC327-40
TW011	70010150	Transistor BC848B
TX350	A6004020	Transistor, Chip RN1402
TX351	70011788	Transistor, Chip RN2402
TX352	A6004020	Transistor, Chip RN1402
TZ032	70010150	Transistor BC848B

LOCATION NUMBER	PART NUMBER	DESCRIPTION
TZ033	70010947	Transistor BC858
TZ034	70010947	Transistor BC858
- DIODES -		
DP001	70012827	Diode BYW27-1000
DP002	70012827	Diode BYW27-1000
DP003	70012827	Diode BYW27-1000
DP004	70012827	Diode BYW27-1000
△DP005	70012923	Diode, Zener BZX55B43
DP006	70012923	Diode, Zener BZX55B43
DP018	70012760	Diode LS4148
DP019	70010153	Diode 1N4148
DP020	70010957	Diode, Zener ZPD10
DP025	70012434	Diode BAV20
DP029	70010957	Diode, Zener ZPD10
DP031	70012679	Diode FR104
DP037	70012760	Diode LS4148
DP040	70012434	Diode BAV20
△DP044	70010957	Diode, Zener ZPD10
DP051	70012679	Diode FR104
DP053	70012679	Diode FR104
DP054	70012922	Diode, Zener BZX55B27
DP056	70012434	Diode BAV20
DP061	70012679	Diode FR104
DP064	70012630	Diode 1N5822
DP066	70012907	Diode SR560
△DP067	70012810	Diode MA2062
DP070	70012760	Diode LS4148
DP071	70012760	Diode LS4148
DP073	70012509	Diode, Zener MTZJ4. 7C
DP081	70012760	Diode LS4148
DP082	70012760	Diode LS4148
DT013	70012760	Diode LS4148
DV002	70012761	Diode LS4448
DV003	70012761	Diode LS4448
DV166	70012760	Diode LS4148
DV167	70012760	Diode LS4148
DW001	70011967	Diode, Zener ZPD12
DW002	70012760	Diode LS4148
DW003	70012822	Diode RLS4153
DW004	70011440	Diode ZP5. 1
DW086	70012342	Diode 1N4001
DW087	70012342	Diode 1N4001
DX351	70012760	Diode LS4148
DX352	70010153	Diode 1N4148
GT002	70010180	Diode, LED GL451V
- COILS -		
LI040	70012918	Coil
△LP001	70011950	Line Filter
△LP050	70012893	Power Transformer
LP057	70012095	Coil, Peaking
LP064	70012428	Coil, Peaking
LP066	70012429	Coil, Peaking
LS001	70012915	Coil
LS002	70011594	Coil, Peaking
LS030	70012909	Coil
LS050	70012460	Coil, Bias Oscillator
LT001	70011953	Coil, Peaking
LT002	23237981	Coil, Peaking TRF4330AC
LT004	70011953	Coil, Peaking
LV001	23237976	Coil, Peaking TRF4820AC
LV003	70012918	Coil
LV004	70012918	Coil
LV005	70012918	Coil
LV007	70012904	Coil
LV014	70012916	Coil
LV401	70012919	Coil
LV402	70012917	Coil
LV403	70011849	Coil, Peaking
LV410	70012918	Coil
LV500	23237967	Coil, Peaking TRF4471AC
LY001	70012918	Coil
LZ004	70012904	Coil
LZ005	23238714	Coil, Peaking TRF4100AJ
LZ011	23238714	Coil, Peaking TRF4100AJ
LZ032	70010273	Coil, Peaking

LOCATION NUMBER	PART NUMBER	DESCRIPTION				LOCATION NUMBER	PART NUMBER	DESCRIPTION			
		- CAPACITORS -									
CI001	70041629	Cap, Chip	1nF	M	50V	CS054	70041977	Cap, Plastic	82nF	J	50V
CI013	70041657	Cap, Chip	22nF	K	25V	CT001	70041328	Cap, Chip	100nF	Z	25V
CI015	70041657	Cap, Chip	22nF	K	25V	CT002	70041596	Cap, Chip	10nF	K	50V
CI020	70041328	Cap, Chip	100nF	Z	25V	CT003	70041630	Cap, Chip	1nF	J	50V
CI021	70041629	Cap, Chip	1nF	M	50V	CT004	70041648	Cap, Chip	1000pF	J	50V
CI022	70041657	Cap, Chip	22nF	K	25V	CT005	24285103	Cap, Chip	0.01 μ F	K	50V
CI024	70042390	Cap, Electrolytic	2.2 μ F	M	35V	CT006	70041596	Cap, Chip	10nF	K	50V
CI025	70042284	Cap, Electrolytic	2.2 μ F	M	50V	CT007	24285103	Cap, Chip	0.01 μ F	K	50V
CI026	70042234	Cap, Chip	220nF	Z	16V	CT008	70042373	Cap, Electrolytic	100 μ F	M	16V
CI041	70041629	Cap, Chip	1nF	M	50V	CT009	70042112	Cap, Electrolytic	47 μ F	M	16V
CI043	70041328	Cap, Chip	100nF	Z	25V	CT010	24815222	Cap, Chip	2200pF	K	50V
CI063	70041596	Cap, Chip	10nF	K	50V	CT011	70041328	Cap, Chip	100nF	Z	25V
CI069	70041713	Cap, Electrolytic	100 μ F	M	16V	CT012	24774090	Cap, Chip	9pF	D	50V
CI070	24285103	Cap, Chip	0.01 μ F	K	50V	CT013	70041323	Cap, Chip	8pF	C	50V
CI077	70041328	Cap, Chip	100nF	Z	25V	CT014	70041596	Cap, Chip	10nF	K	50V
ACP001	70042150	Cap, Plastic	100nF	M		CT015	70041596	Cap, Chip	10nF	K	50V
ACP010	70041047	Cap, Electrolytic	47 μ F	M	385V	CT016	70041328	Cap, Chip	100nF	Z	25V
CP011	70042328	Cap, Electrolytic	4.7 μ F	M		CT017	70041328	Cap, Chip	100nF	Z	25V
CP019	70042387	Cap	8200pF	M	50V	CT018	70041328	Cap, Chip	100nF	Z	25V
CP020	70042149	Cap, Chip	6.8nF	M	50V	CT020	70041328	Cap, Chip	100nF	Z	25V
CP021	70042362	Cap	2200pF		1kV	CT021	70041648	Cap, Chip	1000pF	J	50V
CP022	70041155	Cap, Chip	1.5nF	J	50V	CT022	70041648	Cap, Chip	1000pF	J	50V
CP024	70042397	Cap, Ceramic	330pF	K	400V	CT023	70041037	Cap, Electrolytic	47 μ F	M	16V
CP025	70042328	Cap, Electrolytic	4.7 μ F	M		CT024	24774151	Cap, Chip	150pF	J	50V
CP026	70041015	Cap, Chip	10nF	M	50V	CT025	70041130	Cap, Chip	470nF	Z	16V
CP031	70042328	Cap, Electrolytic	4.7 μ F	M		CT026	70041130	Cap, Chip	470nF	Z	16V
CP038	70042345	Cap, Chip	220pF	J	50V	CT027	24774101	Cap, Chip	100pF	J	50V
CP040	70042327	Cap, Electrolytic	1 μ F	M		CT028	24774101	Cap, Chip	100pF	J	50V
CP041	70041271	Cap, Chip	2.2nF	K	50V	CT029	70042122	Cap, Electrolytic	1 μ F	M	50V
ACP050	70042379	Cap	1000pF	M	250V	CT030	70042122	Cap, Electrolytic	1 μ F	M	50V
CP051	24793101	Cap, Electrolytic	100 μ F	M	10V	CT031	70041183	Cap, Electrolytic	47 μ F	M	16V
CP053	70040096	Cap, Ceramic	470pF	M	400V	CT032	70040998	Cap, Chip	100nF	Z	25V
CP054	70042353	Cap, Electrolytic	33 μ F	M	50V	CT034	70042345	Cap, Chip	220pF	J	50V
CP056	70040096	Cap, Ceramic	470pF	M	400V	CT035	70042345	Cap, Chip	220pF	J	50V
CP057	70041500	Cap, Electrolytic	47 μ F	M	50V	CT037	70041882	Cap, Chip	4pF	C	
CP058	70041500	Cap, Electrolytic	47 μ F	M	50V	CT039	70042386	Cap	200pF	J	50V
CP061	70042167	Cap, Electrolytic	220 μ F	M	35V	CT040	24774101	Cap, Chip	100pF	J	50V
CP064	70042152	Cap, Electrolytic	0.001F	M	25V	CT041	24774470	Cap, Chip	47pF	J	50V
CP065	70040725	Cap, Electrolytic	100 μ F	M	25V	CT042	24774470	Cap, Chip	47pF	J	50V
CP066	70042381	Cap, Electrolytic	4700 μ F	M	10V	CT043	70042256	Cap, Electrolytic	3300 μ F	M	6.3V
CP067	24794102	Cap, Electrolytic	1000 μ F	M	16V	CT044	70042222	Cap, Electrolytic	470 μ F	M	10V
CP068	70040725	Cap, Electrolytic	100 μ F	M	25V	CT046	70041328	Cap, Chip	100nF	Z	25V
CP071	70042327	Cap, Electrolytic	1 μ F	M		CT049	70041596	Cap, Chip	10nF	K	50V
CP081	70042327	Cap, Electrolytic	1 μ F	M		CT050	70040998	Cap, Chip	100nF	Z	25V
CP082	70042327	Cap, Electrolytic	1 μ F	M		CT052	70042122	Cap, Electrolytic	1 μ F	M	50V
CS001	70041639	Cap, Electrolytic	4.7 μ F	M	16V	CT054	70042122	Cap, Electrolytic	1 μ F	M	50V
CS002	70041301	Cap, Electrolytic	22 μ F	M	16V	CT060	70040530	Cap, Electrolytic	100 μ F	M	16V
CS003	70041596	Cap, Chip	10nF	K	50V	CT070	70041596	Cap, Chip	10nF	K	50V
CS004	70041328	Cap, Chip	100nF	Z	25V	CT071	24774090	Cap, Chip	9pF	D	50V
CS005	70041328	Cap, Chip	100nF	Z	25V	CT072	70041328	Cap, Chip	100nF	Z	25V
CS006	70042121	Cap, Electrolytic	10 μ F	M	6.3V	CT076	70042386	Cap	200pF	J	50V
CS009	70041328	Cap, Chip	100nF	Z	25V	CT077	70042386	Cap	200pF	J	50V
CS010	70041639	Cap, Electrolytic	4.7 μ F	M	16V	CV001	70041298	Cap, Electrolytic	1 μ F	M	50V
CS011	24206010	Cap, Electrolytic	1 μ F	M	50V	CV002	70042205	Cap, Chip	27nF	K	
CS013	24203100	Cap, Electrolytic	10 μ F	M	16V	CV003	70041692	Cap, Chip	0.022 μ F	Z	50V
CS014	70041648	Cap, Chip	1000pF	J	50V	CV004	70041596	Cap, Chip	10nF	K	50V
CS015	24815152	Cap, Chip	1500pF	K	50V	CV005	24783200	Cap, Chip	20pF	J	50V
CS017	70041704	Cap, Chip	47nF	K	10V	CV006	24814103	Cap, Chip	0.01 μ F	Z	50V
CS018	70041704	Cap, Chip	47nF	K	10V	CV008	70041532	Cap, Chip	330pF	J	50V
CS019	70041596	Cap, Chip	10nF	K	50V	CV009	70041692	Cap, Chip	0.022 μ F	Z	50V
CS020	24203470	Cap, Electrolytic	47 μ F	M	16V	CV010	24287103	Cap, Chip	0.01 μ F	Z	50V
CS022	24815152	Cap, Chip	1500pF	K	50V	CV011	70042395	Cap, Ceramic	200pF	J	50V
CS023	70042112	Cap, Electrolytic	47 μ F	M	16V	CV012	70042101	Cap, Electrolytic	1 μ F	M	50V
CS024	24815272	Cap, Chip	2700pF	K	50V	CV013	24774390	Cap, Chip	39pF	J	50V
CS025	24774101	Cap, Chip	100pF	J	50V	CV014	70041328	Cap, Chip	100nF	Z	25V
CS026	70041704	Cap, Chip	47nF	K	10V	CV015	24092178	Cap, Chip	0.1 μ F	K	25V
CS030	24203470	Cap, Electrolytic	47 μ F	M	16V	CV016	70041316	Cap, Electrolytic	1 μ F	M	50V
CS031	70041596	Cap, Chip	10nF	K	50V	CV017	24814103	Cap, Chip	0.01 μ F	Z	50V
CS032	70041596	Cap, Chip	10nF	K	50V	CV018	70041640	Cap, Electrolytic	10 μ F	M	50V
CS033	70042382	Cap	18nF	J	50V	CV019	24774330	Cap, Chip	33pF	J	50V
CS050	70041596	Cap, Chip	10nF	K	50V	CV020	70041713	Cap, Electrolytic	100 μ F	M	16V
CS051	24815272	Cap, Chip	2700pF	K	50V	CV021	70041328	Cap, Chip	100nF	Z	25V
CS052	70041596	Cap, Chip	10nF	K	50V	CV022	70040998	Cap, Chip	100nF	Z	25V
CS053	24203470	Cap, Electrolytic	47 μ F	M	16V	CV023	24797100	Cap, Electrolytic	10 μ F	M	50V
						CV024	70042101	Cap, Electrolytic	1 μ F	M	50V

LOCATION NUMBER	PART NUMBER	DESCRIPTION
CV025	70042279	Cap, Electrolytic 1μF M 50V
CV028	70040725	Cap, Electrolytic 100μF M 25V
CV029	70041328	Cap, Chip 100nF Z 25V
CV030	70042279	Cap, Electrolytic 1μF M 50V
CV031	70041657	Cap, Chip 22nF K 25V
CV032	70042101	Cap, Electrolytic 1μF M 50V
CV033	70041298	Cap, Electrolytic 1μF M 50V
CV034	24814103	Cap, Chip 0.01μF Z 50V
CV035	70042374	Cap, Ceramic 22nF K
CV036	70041704	Cap, Chip 47nF K 10V
CV037	70042153	Cap, Electrolytic 22μF M 16V
CV038	70041692	Cap, Chip 0.022μF Z 50V
CV039	24774101	Cap, Chip 100pF J 50V
CV045	70041596	Cap, Chip 10nF K 50V
CV047	70041328	Cap, Chip 100nF Z 25V
CV049	70042274	Cap, Ceramic 22nF Z 50V
CV050	24774560	Cap, Chip 56pF J 50V
CV051	70041692	Cap, Chip 0.022μF Z 50V
CV052	70040725	Cap, Electrolytic 100μF M 25V
CV053	70040998	Cap, Chip 100nF Z 25V
CV054	24287103	Cap, Chip 0.01μF Z 50V
CV055	24814103	Cap, Chip 0.01μF Z 50V
CV057	24287103	Cap, Chip 0.01μF Z 50V
CV058	70041596	Cap, Chip 10nF K 50V
CV059	24092178	Cap, Chip 0.1μF K 25V
CV061	70041704	Cap, Chip 47nF K 10V
CV063	70040980	Cap, Chip 100pF J 50V
CV064	70041328	Cap, Chip 100nF Z 25V
CV065	24783101	Cap, Chip 100pF J 50V
CV068	70041704	Cap, Chip 47nF K 10V
CV083	70041640	Cap, Electrolytic 10μF M 50V
CV084	24814103	Cap, Chip 0.01μF Z 50V
CV087	70040244	Cap, Chip 100pF J 50V
CV102	24815102	Cap, Chip 1000pF K 50V
CV132	70041596	Cap, Chip 10nF K 50V
CV133	24774820	Cap, Chip 82pF J 50V
CV140	24783820	Cap, Chip 82pF J 50V
CV401	24783330	Cap, Chip 33pF J 50V
CV404	70041530	Cap, Chip 330nF Z 16V
CV405	24815152	Cap, Chip 1500pF K 50V
CV407	70041323	Cap, Chip 8pF C 50V
CV409	24774120	Cap, Chip 12pF J 50V
CV410	24794101	Cap, Electrolytic 100μF M 16V
CV412	70042263	Cap, Chip 18pF J 50V
CV413	70041923	Cap, Chip 75pF J 50V
CV416	70041530	Cap, Chip 330nF Z 16V
CV501	70042122	Cap, Electrolytic 1μF M 50V
CV502	70042161	Cap, Chip 56nF K 16V
CV503	70041657	Cap, Chip 22nF K 25V
CV504	70040982	Cap, Chip 820pF J 50V
CV505	24814103	Cap, Chip 0.01μF Z 50V
CV506	70041328	Cap, Chip 100nF Z 25V
CV507	70041570	Cap, Electrolytic 100μF M 10V
CV508	70042122	Cap, Electrolytic 1μF M 50V
CV509	70042385	Cap 43pF J 50V
CW001	24203100	Cap, Electrolytic 10μF M 16V
CW002	70041713	Cap, Electrolytic 100μF M 16V
CW003	70040738	Cap, Electrolytic 4.7μF 25V
CW004	70042112	Cap, Electrolytic 47μF M 16V
CW008	24794101	Cap, Electrolytic 100μF M 16V
CY001	24774151	Cap, Chip 150pF J 50V
CY002	70042376	Cap, Ceramic 0.33μF K
CY003	70041865	Cap, Chip 33nF Z
CY004	70040998	Cap, Chip 100nF Z 25V
CY005	70040530	Cap, Electrolytic 100μF M 16V
CY006	70040530	Cap, Electrolytic 100μF M 16V
CY007	70040998	Cap, Chip 100nF Z 25V
CY010	24815222	Cap, Chip 2200pF K 50V
CZ011	24815222	Cap, Chip 2200pF K 50V
CZ015	70041500	Cap, Electrolytic 47μF M 50V
CZ018	24203100	Cap, Electrolytic 10μF M 16V
CZ021	70041629	Cap, Chip 1nF M 50V
CZ033	24794101	Cap, Electrolytic 100μF M 16V
CZ072	70041328	Cap, Chip 100nF Z 25V
CZ076	70042319	Cap 270pF K

LOCATION NUMBER	PART NUMBER	DESCRIPTION
CZ101	70040998	Cap, Chip 100nF Z 25V
CZ105	70041156	Cap, Chip 330nF Z 25V
- RESISTORS -		
D1003	70041096	Chip Jumper
D1041	70041096	Chip Jumper
PI050	70042314	Res, Variable 22kΩ
RI001	24872100	Res, Chip 10Ω J 1/16W
RI004	24872181	Res, Chip 180Ω J 1/16W
RI011	24872181	Res, Chip 180Ω J 1/16W
RI012	24872330	Res, Chip 33Ω J 1/16W
RI013	24872682	Res, Chip 6.8kΩ J 1/16W
RI014	24872222	Res, Chip 2.2kΩ J 1/16W
RI019	24872391	Res, Chip 390Ω J 1/16W
RI020	24872332	Res, Chip 3.3kΩ J 1/16W
RI021	24872102	Res, Chip 1kΩ J 1/16W
RI022	70040342	Res, Chip 12Ω J 1/16W
RI023	24872220	Res, Chip 22Ω J 1/16W
RI024	24872101	Res, Chip 100Ω J 1/16W
RI025	24872470	Res, Chip 47Ω J 1/16W
RI053	24872331	Res, Chip 330Ω J 1/16W
RI065	24872331	Res, Chip 330Ω J 1/16W
RI066	24872561	Res, Chip 560Ω J 1/16W
RI067	24872332	Res, Chip 3.3kΩ J 1/16W
RI068	24872271	Res, Chip 270Ω J 1/16W
RI069	24871332	Res, Chip 3.3kΩ J 1/8W
RI070	24872682	Res, Chip 6.8kΩ J 1/16W
RI071	24871103	Res, Chip 10kΩ J 1/8W
RI077	24872273	Res, Chip 27kΩ J 1/16W
RI078	24872273	Res, Chip 27kΩ J 1/16W
RI080	24872472	Res, Chip 4.7kΩ J 1/16W
RI083	70041096	Chip Jumper
RI086	70041096	Chip Jumper
RP004	24871184	Res, Chip 180kΩ J 1/8W
RP005	24871184	Res, Chip 180kΩ J 1/8W
RP006	24871184	Res, Chip 180kΩ J 1/8W
RP007	24871184	Res, Chip 180kΩ J 1/8W
RP008	24871184	Res, Chip 180kΩ J 1/8W
RP009	24871184	Res, Chip 180kΩ J 1/8W
RP011	24871474	Res, Chip 470kΩ J 1/8W
RP012	24871681	Res, Chip 680Ω J 1/8W
RP013	24871681	Res, Chip 680Ω J 1/8W
RP014	24871681	Res, Chip 680Ω J 1/8W
RP018	70041093	Chip Jumper
RP019	70041969	Res, Carbon 2kΩ J 1/4W
RP020	70042315	Res 4.7 J
RP021	70042341	Res 22 J 1/4W
RP022	24871273	Res, Chip 27kΩ J 1/8W
RP025	24871101	Res, Chip 100Ω J 1/8W
RP026	24871102	Res, Chip 1kΩ J 1/8W
RP027	70041665	Res, Carbon 5.6kΩ J 1/4W
RP028	70042391	Res 10Ω J 1/4W
RP029	24871223	Res, Chip 22kΩ J 1/8W
RP030	70040854	Res, Carbon 22kΩ J 0.2W
RP033	70042363	Res 1kΩ J 1/4W
RP035	24871102	Res, Chip 1kΩ J 1/8W
RP037	70040106	Res, Carbon 10kΩ J 1/4W
RP038	24871101	Res, Chip 100Ω J 1/8W
RP040	24871102	Res, Chip 1kΩ J 1/8W
RP041	70040106	Res, Carbon 10kΩ J 1/4W
RP052	70042383	Res 1Ω K
RP053	70040390	Chip Jumper
△RP058	70041074	Res, Fusible 27Ω J 0.3W
RP065	70040841	Res, Carbon 220Ω J 1/4W
RP067	70042384	Res 680Ω G
RP068	70042388	Res 2.2kΩ G
RP069	70041093	Chip Jumper
RP071	24871101	Res, Chip 100Ω J 1/8W
RP072	70041093	Chip Jumper
RP073	24871331	Res, Chip 330Ω J 1/8W
RP077	70042363	Res 1kΩ J 1/4W
RP081	24871100	Res, Chip 10Ω J 1/8W
RP082	24872104	Res, Chip 100kΩ J 1/16W
RP083	24872473	Res, Chip 47kΩ J 1/16W
RP084	24871474	Res, Chip 470kΩ J 1/8W
RP085	24872102	Res, Chip 1kΩ J 1/16W

LOCATION NUMBER	PART NUMBER	DESCRIPTION			LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RP086	24872103	Res, Chip	10kΩ	J 1/16W	RT063	24872221	Res, Chip	220Ω	J 1/16W
RP087	24872103	Res, Chip	10kΩ	J 1/16W	RT064	24872221	Res, Chip	220Ω	J 1/16W
RS001	24872151	Res, Chip	150Ω	J 1/16W	RT065	24872222	Res, Chip	2.2kΩ	J 1/16W
RS003	24872334	Res, Chip	330kΩ	J 1/16W	RT066	24872222	Res, Chip	2.2kΩ	J 1/16W
RS004	24872123	Res, Chip	12kΩ	J 1/16W	RT067	24871471	Res, Chip	470Ω	J 1/8W
RS005	24871562	Res, Chip	5.6kΩ	J 1/8W	RT068	24872101	Res, Chip	100Ω	J 1/16W
RS006	24872472	Res, Chip	4.7kΩ	J 1/16W	RT069	24872222	Res, Chip	2.2kΩ	J 1/16W
RS007	24872125	Res, Chip	1.2MΩ	J 1/16W	RT072	24872103	Res, Chip	10kΩ	J 1/16W
RS008	24872273	Res, Chip	27kΩ	J 1/16W	RT073	24872473	Res, Chip	47kΩ	J 1/16W
RS009	24872222	Res, Chip	2.2kΩ	J 1/16W	RT074	24872303	Res, Chip	30kΩ	J 1/16W
RS010	70040850	Res, Carbon	2.7kΩ	J	RT075	24872102	Res, Chip	1kΩ	J 1/16W
RS011	24872272	Res, Chip	2.7kΩ	J 1/16W	RT076	24871221	Res, Chip	220Ω	J 1/8W
RS012	24872471	Res, Chip	470Ω	J 1/16W	RT077	24871221	Res, Chip	220Ω	J 1/8W
RS013	24872202	Res, Chip	2kΩ	J 1/16W	RT081	24872101	Res, Chip	100Ω	J 1/16W
RS014	24872273	Res, Chip	27kΩ	J 1/16W	RT083	24871272	Res, Chip	2.7kΩ	J 1/8W
RS016	24871151	Res, Chip	150Ω	J 1/8W	RT084	24871182	Res, Chip	1.8kΩ	J 1/8W
RS017	24872123	Res, Chip	12kΩ	J 1/16W	RT085	70042024	Res, Carbon	1.8kΩ	J 1/4W
RS019	24872103	Res, Chip	10kΩ	J 1/16W	RT090	70040099	Res, Carbon	6.8kΩ	J 1/4W
RS020	24872103	Res, Chip	10kΩ	J 1/16W	RT091	24872102	Res, Chip	1kΩ	J 1/16W
RS031	24871470	Res, Chip	47Ω	J 1/8W	RT093	24871102	Res, Chip	1kΩ	J 1/8W
RS032	24872273	Res, Chip	27kΩ	J 1/16W	RT095	70041096	Chip Jumper		
RS033	24871479	Res, Chip	4.7Ω	J 1/8W	RT100	24871272	Res, Chip	2.7kΩ	J 1/8W
RS034	24872181	Res, Chip	180Ω	J 1/16W	RT102	24872472	Res, Chip	4.7kΩ	J 1/16W
RS036	70042391	Res	10Ω	J 1/4W	RT103	24872472	Res, Chip	4.7kΩ	J 1/16W
RS050	70041671	Res, Fusible	18Ω	J 0.3W	RT104	24872561	Res, Chip	560Ω	J 1/16W
RS051	24872101	Res, Chip	100Ω	J 1/16W	RT105	24872101	Res, Chip	100Ω	J 1/16W
RS052	24872563	Res, Chip	56kΩ	J 1/16W	RT106	24872472	Res, Chip	4.7kΩ	J 1/16W
RS053	24871479	Res, Chip	4.7Ω	J 1/8W	RT107	24871561	Res, Chip	560Ω	J 1/8W
RS054	24871152	Res, Chip	1.5kΩ	J 1/8W	RT108	24872222	Res, Chip	2.2kΩ	J 1/16W
RS055	24872152	Res, Chip	1.5kΩ	J 1/16W	RT109	24872561	Res, Chip	560Ω	J 1/16W
RT001	24871221	Res, Chip	220Ω	J 1/8W	RT110	24871102	Res, Chip	1kΩ	J 1/8W
RT002	24872103	Res, Chip	10kΩ	J 1/16W	RT165	70041096	Chip Jumper		
RT003	24872113	Res, Chip	11kΩ	J 1/16W	RT176	70041093	Chip Jumper		
RT004	70040702	Res, Carbon	12kΩ	J 1/4W	RV001	24871471	Res, Chip	470Ω	J 1/8W
RT005	24871473	Res, Chip	47kΩ	J 1/8W	RV002	24872431	Res, Chip	430Ω	J 1/16W
RT006	70041708	Res, Carbon	47kΩ	J 1/4W	RV003	24872152	Res, Chip	1.5kΩ	J 1/16W
RT007	24871103	Res, Chip	10kΩ	J 1/8W	RV004	24872102	Res, Chip	1kΩ	J 1/16W
RT008	24871229	Res, Chip	2.2Ω	J 1/8W	RV005	70041354	Res, Chip	3.9kΩ	J 1/8W
RT009	24871229	Res, Chip	2.2Ω	J 1/8W	RV006	70040355	Res, Chip	1.5kΩ	J 1/16W
RT010	24872472	Res, Chip	4.7kΩ	J 1/16W	RV007	24872102	Res, Chip	1kΩ	J 1/16W
RT011	24871821	Res, Chip	820Ω	J 1/8W	RV008	24872183	Res, Chip	18kΩ	J 1/16W
RT012	24872103	Res, Chip	10kΩ	J 1/16W	RV009	24872103	Res, Chip	10kΩ	J 1/16W
RT013	24872472	Res, Chip	4.7kΩ	J 1/16W	RV010	24872152	Res, Chip	1.5kΩ	J 1/16W
RT014	70042025	Res, Carbon	110kΩ	J 1/4W	RV011	24872472	Res, Chip	4.7kΩ	J 1/16W
RT015	24872114	Res, Chip	110kΩ	J 1/16W	RV012	24872122	Res, Chip	1.2kΩ	J 1/16W
RT017	24871201	Res, Chip	200Ω	J 1/8W	RV013	70041096	Chip Jumper		
RT018	24871201	Res, Chip	200Ω	J 1/8W	RV014	70041096	Chip Jumper		
RT019	24871103	Res, Chip	10kΩ	J 1/8W	RV015	24872122	Res, Chip	1.2kΩ	J 1/16W
RT020	24871103	Res, Chip	10kΩ	J 1/8W	RV016	24872822	Res, Chip	8.2kΩ	J 1/16W
RT022	24872102	Res, Chip	1kΩ	J 1/16W	RV017	24872182	Res, Chip	1.8kΩ	J 1/16W
RT023	24872472	Res, Chip	4.7kΩ	J 1/16W	RV018	24872132	Res, Chip	1.3kΩ	J 1/16W
RT024	24872472	Res, Chip	4.7kΩ	J 1/16W	RV019	24872152	Res, Chip	1.5kΩ	J 1/16W
RT025	24872472	Res, Chip	4.7kΩ	J 1/16W	RV020	24872222	Res, Chip	2.2kΩ	J 1/16W
RT027	70040845	Res, Carbon	680Ω	J 1/4W	RV027	24872152	Res, Chip	1.5kΩ	J 1/16W
RT030	70040118	Res, Carbon	4.7kΩ	J 1/4W	RV028	24871222	Res, Chip	2.2kΩ	J 1/8W
RT031	24871821	Res, Chip	820Ω	J 1/8W	RV031	70042396	Res	560kΩ	J
RT032	24871562	Res, Chip	5.6kΩ	J 1/8W	RV032	24872104	Res, Chip	100kΩ	J 1/16W
RT033	70041665	Res, Carbon	5.6kΩ	J 1/4W	RV033	24872683	Res, Chip	68kΩ	J 1/16W
RT034	24871273	Res, Chip	27kΩ	J 1/8W	RV035	24872473	Res, Chip	47kΩ	J 1/16W
RT035	24871273	Res, Chip	27kΩ	J 1/8W	RV036	70041096	Chip Jumper		
RT036	70042369	Res	330Ω	J 1/2W	RV037	24871472	Res, Chip	4.7kΩ	J 1/8W
RT037	24872181	Res, Chip	180Ω	J 1/16W	RV038	24872223	Res, Chip	22kΩ	J 1/16W
RT041	24872471	Res, Chip	470Ω	J 1/16W	RV039	24872123	Res, Chip	12kΩ	J 1/16W
RT042	24872684	Res, Chip	680kΩ	J 1/16W	RV040	24871339	Res, Chip	3.3Ω	J 1/8W
RT043	24872224	Res, Chip	220kΩ	J 1/16W	RV041	24872102	Res, Chip	1kΩ	J 1/16W
RT044	24872105	Res, Chip	1MΩ	J 1/16W	RV042	24872102	Res, Chip	1kΩ	J 1/16W
RT045	24872105	Res, Chip	1MΩ	J 1/16W	RV043	24872102	Res, Chip	1kΩ	J 1/16W
RT046	24872563	Res, Chip	56kΩ	J 1/16W	RV047	70041096	Chip Jumper		
RT047	24871182	Res, Chip	1.8kΩ	J 1/8W	RV050	24871820	Res, Chip	82Ω	J 1/8W
RT048	24871182	Res, Chip	1.8kΩ	J 1/8W	RV055	70040350	Res, Chip	220Ω	J 1/16W
RT049	24872563	Res, Chip	56kΩ	J 1/16W	RV056	24872271	Res, Chip	270Ω	J 1/16W
RT050	70041093	Chip Jumper			RV060	24872124	Res, Chip	120kΩ	J 1/16W
RT051	24871182	Res, Chip	1.8kΩ	J 1/8W	RV066	24872473	Res, Chip	47kΩ	J 1/16W
RT052	24872102	Res, Chip	1kΩ	J 1/16W	RV067	24872473	Res, Chip	47kΩ	J 1/16W
RT053	24872102	Res, Chip	1kΩ	J 1/16W	RV081	24872123	Res, Chip	12kΩ	J 1/16W

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RV082	24872104	Res, Chip	100kΩ	J 1/16W
RV090	24871101	Res, Chip	100Ω	J 1/8W
RV096	24872222	Res, Chip	2. 2kΩ	J 1/16W
RV097	24872222	Res, Chip	2. 2kΩ	J 1/16W
RV102	70041093	Chip Jumper		
RV103	70041388	Res, Chip	270kΩ	J 1/10W
RV105	24872562	Res, Chip	5. 6kΩ	J 1/16W
RV107	24872473	Res, Chip	47kΩ	J 1/16W
RV108	70041093	Chip Jumper		
RV114	70041096	Chip Jumper		
RV134	70040847	Res, Carbon	1. 5kΩ	J
RV135	24872471	Res, Chip	470Ω	J 1/16W
RV136	24872222	Res, Chip	2. 2kΩ	J 1/16W
RV140	70040844	Res, Carbon	1kΩ	J 1/4W
RV141	24872102	Res, Chip	1kΩ	J 1/16W
RV167	24872103	Res, Chip	10kΩ	J 1/16W
RV401	24872103	Res, Chip	10kΩ	J 1/16W
RV407	24872102	Res, Chip	1kΩ	J 1/16W
RV408	24872102	Res, Chip	1kΩ	J 1/16W
RV410	24872102	Res, Chip	1kΩ	J 1/16W
RV411	24872105	Res, Chip	1MΩ	J 1/16W
RV414	24872105	Res, Chip	1MΩ	J 1/16W
RV415	24872302	Res, Chip	3kΩ	J 1/16W
RV417	24872362	Res, Chip	3. 6kΩ	J 1/16W
RV418	24872102	Res, Chip	1kΩ	J 1/16W
RV420	70041096	Chip Jumper		
RV421	24872561	Res, Chip	560Ω	J 1/16W
RV501	24872154	Res, Chip	150kΩ	J 1/16W
RV502	24872561	Res, Chip	560Ω	J 1/16W
RV503	24872392	Res, Chip	3. 9kΩ	J 1/16W
RV504	24872103	Res, Chip	10kΩ	J 1/16W
RV505	24872472	Res, Chip	4. 7kΩ	J 1/16W
RV506	24872472	Res, Chip	4. 7kΩ	J 1/16W
RV945	70041096	Chip Jumper		
△RW001	70042047	Res, Chip	4. 7kΩ	J 0. 3W
RW002	70040118	Res, Carbon	4. 7kΩ	J 1/4W
RW003	24872122	Res, Chip	1. 2kΩ	J 1/16W
RW004	70042027	Res, Carbon	3kΩ	J 1/4W
RW005	70042027	Res, Carbon	3kΩ	J 1/4W
RW006	24871331	Res, Chip	330Ω	J 1/8W
RW007	24871331	Res, Chip	330Ω	J 1/8W
RW008	24872271	Res, Chip	270Ω	J 1/16W
RW009	24871181	Res, Chip	180Ω	J 1/8W
RW010	24871472	Res, Chip	4. 7kΩ	J 1/8W
RW011	24871222	Res, Chip	2. 2kΩ	J 1/8W
RW012	70041093	Chip Jumper		
RW013	70040132	Res, Chip	22kΩ	J 1/8W
RW014	24871123	Res, Chip	12kΩ	J 1/8W
RW015	70040785	Res, Carbon	5. 6kΩ	J 1/4W
RW016	70040106	Res, Carbon	10kΩ	J 1/4W
RW017	24871272	Res, Chip	2. 7kΩ	J 1/8W
RW018	24872103	Res, Chip	10kΩ	J 1/16W
RW019	24872472	Res, Chip	4. 7kΩ	J 1/16W
RW021	24872472	Res, Chip	4. 7kΩ	J 1/16W
RW026	24871331	Res, Chip	330Ω	J 1/8W
RW028	24871152	Res, Chip	1. 5kΩ	J 1/8W
RW085	70042348	Res	1. 5Ω	J
RX353	24872102	Res, Chip	1kΩ	J 1/16W
RX355	24872103	Res, Chip	10kΩ	J 1/16W
RX356	70041665	Res, Carbon	5. 6kΩ	J 1/4W
RX358	70012914	Diode, Zener	ZMM6. 2	
RY001	24872222	Res, Chip	2. 2kΩ	J 1/16W
RY002	24872105	Res, Chip	1MΩ	J 1/16W
RY003	24872125	Res, Chip	1. 2MΩ	J 1/16W
RY004	24872682	Res, Chip	6. 8kΩ	J 1/16W
RY006	24871104	Res, Chip	100kΩ	J 1/8W
RY009	24872682	Res, Chip	6. 8kΩ	J 1/16W
RY010	24872125	Res, Chip	1. 2MΩ	J 1/16W
RY916	70041096	Chip Jumper		
RZ004	70041096	Chip Jumper		
RZ011	70040850	Res, Carbon	2. 7kΩ	J
RZ015	70042363	Res	1kΩ	J 1/4W
RZ019	24871122	Res, Chip	1. 2kΩ	J 1/8W
RZ032	24872102	Res, Chip	1kΩ	J 1/16W
RZ033	24872102	Res, Chip	1kΩ	J 1/16W

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RZ034	24872331	Res, Chip	330Ω	J 1/16W
RZ035	24872102	Res, Chip	1kΩ	J 1/16W
RZ037	24872152	Res, Chip	1. 5kΩ	J 1/16W
RZ038	24871561	Res, Chip	560Ω	J 1/8W
RZ039	24871102	Res, Chip	1kΩ	J 1/8W
RZ060	24872270	Res, Chip	27Ω	J 1/16W
RZ070	24871221	Res, Chip	220Ω	J 1/8W
RZ071	24871221	Res, Chip	220Ω	J 1/8W
RZ072	70040848	Res, Carbon	100kΩ	J
RZ076	24872471	Res, Chip	470Ω	J 1/16W
RZ105	24871103	Res, Chip	10kΩ	J 1/8W
RZ109	24872103	Res, Chip	10kΩ	J 1/16W
RZ110	24872103	Res, Chip	10kΩ	J 1/16W
RZ111	24872103	Res, Chip	10kΩ	J 1/16W
RZ112	24872103	Res, Chip	10kΩ	J 1/16W
RZ113	24872103	Res, Chip	10kΩ	J 1/16W
RZ114	24872222	Res, Chip	2. 2kΩ	J 1/16W
RZ115	24872103	Res, Chip	10kΩ	J 1/16W
RZ116	24872103	Res, Chip	10kΩ	J 1/16W
JI003	70041093	Chip Jumper		
JI011	70041093	Chip Jumper		
JI017	70041093	Chip Jumper		
JI033	70041093	Chip Jumper		
JI045	70041093	Chip Jumper		
JI046	70041093	Chip Jumper		
JP008	70041093	Chip Jumper		
JP015	70041093	Chip Jumper		
JS020	70041093	Chip Jumper		
JS021	70041093	Chip Jumper		
JS022	70041093	Chip Jumper		
JS023	70041096	Chip Jumper		
JS024	70041093	Chip Jumper		
JS025	70041093	Chip Jumper		
JS027	70041096	Chip Jumper		
JS028	70041093	Chip Jumper		
JS030	70041093	Chip Jumper		
JT005	70041093	Chip Jumper		
JT108	70041093	Chip Jumper		
JT109	70041093	Chip Jumper		
JT110	70041093	Chip Jumper		
JT111	70041093	Chip Jumper		
JT112	70041093	Chip Jumper		
JT113	70041096	Chip Jumper		
JT114	70041093	Chip Jumper		
JT115	70041096	Chip Jumper		
JT116	70041096	Chip Jumper		
JT117	70041093	Chip Jumper		
JT118	70041096	Chip Jumper		
JT120	70041093	Chip Jumper		
JT121	70041093	Chip Jumper		
JT122	70041093	Chip Jumper		
JT123	70041093	Chip Jumper		
JT124	70041093	Chip Jumper		
JT125	70041093	Chip Jumper		
JT150	70041093	Chip Jumper		
JT151	70041093	Chip Jumper		
JT152	70041093	Chip Jumper		
JT153	70041093	Chip Jumper		
JT154	70041093	Chip Jumper		
JT157	70041096	Chip Jumper		
JT158	70041093	Chip Jumper		
JT159	70041093	Chip Jumper		
JT160	70041093	Chip Jumper		
JT161	70041093	Chip Jumper		
JT162	70041096	Chip Jumper		
JT163	70041093	Chip Jumper		
JT164	70041093	Chip Jumper		
JT165	70041093	Chip Jumper		
JT166	70041093	Chip Jumper		
JT167	70041093	Chip Jumper		
JT168	70041093	Chip Jumper		
JT169	70041093	Chip Jumper		
JT171	70041093	Chip Jumper		
JT172	70041093	Chip Jumper		
JT173	70041096	Chip Jumper		

LOCATION NUMBER	PART NUMBER	DESCRIPTION	LOCATION NUMBER	PART NUMBER	DESCRIPTION
JT174	70041096	Chip Jumper	△BP001	70012912	Power Inlet
JT175	70041093	Chip Jumper	BT001	70011830	Connector
JT176	70041093	Chip Jumper	FI010	70012836	Filter
JT177	70041096	Chip Jumper	FI020	70012857	Filter
JT178	70041093	Chip Jumper	FI030	70012871	Coil
JT179	70041093	Chip Jumper	FI090	70010706	Filter 6MHz
JT180	70041093	Chip Jumper	△FP001	70010445	Fuse, 1A, 250V
JT181	70041093	Chip Jumper	FP01A	70010597	Fuse Holder
JT182	70041093	Chip Jumper	△FP051	70011781	IC Protector ICP-N10
JT315	70041096	Chip Jumper	GT001	70011828	Hall Sensor HW300B
JV003	70041093	Chip Jumper	GT003	70011793	Photo Interrupter GP1S562
JV021	70041093	Chip Jumper	GT004	70011793	Photo Interrupter GP1S562
JV027	70041093	Chip Jumper	GT02A	70051136	LED Holder
JV028	70041096	Chip Jumper	MT001	70031317	Stator
JV031	70041096	Chip Jumper	QT001	70012888	Filter
JV037	70041093	Chip Jumper	QT002	70010116	Crystal, 32kHz
JV067	70041093	Chip Jumper	QT003	70011861	Crystal 16MHz
JV073	70041093	Chip Jumper	QV002	70012889	Filter
JV075	70041093	Chip Jumper	QV500	70012809	Resonator
JV108	70041093	Chip Jumper	ST001	70011826	Switch, Push
JV110	70041096	Chip Jumper	■0030M	70095281	P C Board Assy Terminal/Audio - INTEGRATED CIRCUITS -
JV120	70041093	Chip Jumper	IN101	70012902	IC TA1246AF
JV121	70041093	Chip Jumper	IN102	70010980	IC HEF4052BT
JV125	70041096	Chip Jumper	IN103	70011903	IC TA78L09S
JV126	70041093	Chip Jumper	IN201	70012901	IC MSP3416D
JV128	70041093	Chip Jumper	IN202	70012900	IC TL074CDP
JV129	70041093	Chip Jumper	IN203	70011902	IC TA78L008AP
JV130	70041093	Chip Jumper	IX101	70011881	IC STV6400
JV133	70041093	Chip Jumper			- TRANSISTORS -
JV137	70041093	Chip Jumper	TN101	A6541130	Transistor, Chip 2SA1162-Y
JV139	70041093	Chip Jumper	TN102	A6004040	Transistor, Chip RN1404
JV146	70041093	Chip Jumper	TN103	A6541130	Transistor, Chip 2SA1162-Y
JV148	70041093	Chip Jumper	TN201	70010331	Transistor BC847B
JV154	70041093	Chip Jumper	TN202	A6541130	Transistor, Chip 2SA1162-Y
JV156	70041093	Chip Jumper	TN203	70010331	Transistor BC847B
JV157	70041093	Chip Jumper	TN204	A6014040	Transistor, Chip RN2404
JV160	70041096	Chip Jumper	TN205	A6004040	Transistor, Chip RN1404
JV400	70041093	Chip Jumper	TN207	A6335470	Transistor, Chip 2SC2712-Y
JV401	70041093	Chip Jumper	TN208	A6335470	Transistor, Chip 2SC2712-Y
JV402	70041096	Chip Jumper	TX101	70010947	Transistor BC858
JW008	70041093	Chip Jumper			- DIODES -
JW011	70041096	Chip Jumper	DN202	70012760	Diode LS4148
JW012	70041096	Chip Jumper	DN204	70012760	Diode LS4148
JW015	70041093	Chip Jumper	DX101	70012760	Diode LS4148
JW019	70041096	Chip Jumper	DX102	70012760	Diode LS4148
JW020	70041096	Chip Jumper			- COILS -
JW021	70041093	Chip Jumper	LN201	70012903	Coil
JW022	70041093	Chip Jumper	LN202	70012903	Coil
JW034	70041093	Chip Jumper	LN203	70012904	Coil
JW041	70041096	Chip Jumper	LN204	70012903	Coil
JW044	70041093	Chip Jumper	LX101	70012903	Coil
JX001	70041093	Chip Jumper	LX102	70012903	Coil
JY001	70041093	Chip Jumper	LX103	70012905	Coil
JY004	70041096	Chip Jumper	LX104	70012906	Coil
JZ001	70041093	Chip Jumper			- CAPACITORS -
JZ002	70041093	Chip Jumper	CN101	24815561	Cap, Chip 560pF K 50V
JZ005	70041093	Chip Jumper	CN102	24815561	Cap, Chip 560pF K 50V
JZ006	70041096	Chip Jumper	CN103	70041130	Cap, Chip 470nF Z 16V
JZ044	70041093	Chip Jumper	CN104	70041130	Cap, Chip 470nF Z 16V
JZ075	70041093	Chip Jumper	CN105	70042277	Cap 22μF
JZ100	70041093	Chip Jumper	CN106	70041130	Cap, Chip 470nF Z 16V
JZ104	70041093	Chip Jumper	CN108	70041130	Cap, Chip 470nF Z 16V
JZ106	70041096	Chip Jumper	CN110	70042277	Cap 22μF
JZ203	70041093	Chip Jumper	CN111	70041130	Cap, Chip 470nF Z 16V
JZ204	70041096	Chip Jumper	CN112	70041130	Cap, Chip 470nF Z 16V
JZ206	70041093	Chip Jumper	CN113	70041042	Cap, Electrolytic 10μF X
JZ207	70041093	Chip Jumper	CN114	24792331	Cap, Electrolytic 330μF M 6.3V
JZ209	70041096	Chip Jumper	CN115	24591103	Cap, Plastic 0.01μF J 50V
JZ213	70041093	Chip Jumper	CN116	70041042	Cap, Electrolytic 10μF X
JZ220	70041096	Chip Jumper	CN117	24591103	Cap, Plastic 0.01μF J 50V
JZ221	70041093	Chip Jumper	CN118	70041042	Cap, Electrolytic 10μF X
JZ226	70041093	Chip Jumper	CN119	24591103	Cap, Plastic 0.01μF J 50V
		- MISCELLANEOUS -	CN120	70042277	Cap 22μF
0010M	70012896	Tuner			
0060M	70052220	Back Panel			

LOCATION NUMBER	PART NUMBER	DESCRIPTION			LOCATION NUMBER	PART NUMBER	DESCRIPTION		
CN121	70042277	Cap	22 μ F		CX103	70041051	Cap, Electrolytic	47 μ F	M 16V
CN124	24793101	Cap, Electrolytic	100 μ F	M 10V	CX105	70041328	Cap, Chip	100nF	Z 25V
CN125	70041328	Cap, Chip	100nF	Z 25V	CX106	70041328	Cap, Chip	100nF	Z 25V
CN126	24203100	Cap, Electrolytic	10 μ F	M 16V	CX107	70041051	Cap, Electrolytic	47 μ F	M 16V
CN127	24591103	Cap, Plastic	0.01 μ F	J 50V	CX108	70041328	Cap, Chip	100nF	Z 25V
CN128	24203100	Cap, Electrolytic	10 μ F	M 16V	CX109	70041328	Cap, Chip	100nF	Z 25V
CN129	70041130	Cap, Chip	470nF	Z 16V	CX110	70041328	Cap, Chip	100nF	Z 25V
CN130	70041279	Cap, Chip	680pF	K 50V	CX111	70041328	Cap, Chip	100nF	Z 25V
CN131	24203100	Cap, Electrolytic	10 μ F	M 16V	CX112	70040262	Cap, Chip	100pF	J 50V
CN132	70041596	Cap, Chip	10nF	K 50V	CX113	70040241	Cap, Chip	47pF	J 50V
CN133	24792331	Cap, Electrolytic	330 μ F	M 6.3V	CX114	70041328	Cap, Chip	100nF	Z 25V
CN134	70041529	Cap, Chip	1 μ F	Z 16V	CX123	70040262	Cap, Chip	100pF	J 50V
CN135	70042161	Cap, Chip	56nF	K 16V	- RESISTORS -				
CN136	70041130	Cap, Chip	470nF	Z 16V	CN247	24872101	Res, Chip	100 Ω	J 1/16W
CN137	70042277	Cap	22 μ F		CN250	24872101	Res, Chip	100 Ω	J 1/16W
CN141	70041130	Cap, Chip	470nF	Z 16V	CN252	24872101	Res, Chip	100 Ω	J 1/16W
CN142	24203100	Cap, Electrolytic	10 μ F	M 16V	CN256	24872101	Res, Chip	100 Ω	J 1/16W
CN143	70041130	Cap, Chip	470nF	Z 16V	DN201	70041093	Chip Jumper		
CN144	70041130	Cap, Chip	470nF	Z 16V	DN203	70041093	Chip Jumper		
CN201	24203100	Cap, Electrolytic	10 μ F	M 16V	RN101	24872471	Res, Chip	470 Ω	J 1/16W
CN203	24815102	Cap, Chip	1000pF	K 50V	RN102	24872471	Res, Chip	470 Ω	J 1/16W
CN204	24201220	Cap, Electrolytic	22 μ F	M 6.3V	RN103	24872273	Res, Chip	27k Ω	J 1/16W
CN205	24815561	Cap, Chip	560pF	K 50V	RN104	24872333	Res, Chip	33k Ω	J 1/16W
CN206	24815102	Cap, Chip	1000pF	K 50V	RN105	24872273	Res, Chip	27k Ω	J 1/16W
CN207	24815102	Cap, Chip	1000pF	K 50V	RN106	24872333	Res, Chip	33k Ω	J 1/16W
CN208	24815102	Cap, Chip	1000pF	K 50V	RN107	24872273	Res, Chip	27k Ω	J 1/16W
CN209	24815102	Cap, Chip	1000pF	K 50V	RN109	24872752	Res, Chip	7.5k Ω	J 1/16W
CN210	24815561	Cap, Chip	560pF	K 50V	RN110	24872273	Res, Chip	27k Ω	J 1/16W
CN211	24815102	Cap, Chip	1000pF	K 50V	RN112	24872752	Res, Chip	7.5k Ω	J 1/16W
CN217	70041882	Cap, Chip	4pF	C	RN116	24872105	Res, Chip	1M Ω	J 1/16W
CN218	70041944	Cap, Chip	5pF	C	RN119	70040335	Res, Chip	2.7k Ω	J 1/16W
CN219	70041497	Cap, Chip	56pF	J 50V	RN120	70040493	Cap, Chip	10nF	K 50V
CN220	70041497	Cap, Chip	56pF	J 50V	RN121	24872333	Res, Chip	33k Ω	J 1/16W
CN221	70041497	Cap, Chip	56pF	J 50V	RN122	24872473	Res, Chip	47k Ω	J 1/16W
CN222	24203100	Cap, Electrolytic	10 μ F	M 16V	RN123	24872333	Res, Chip	33k Ω	J 1/16W
CN223	24815102	Cap, Chip	1000pF	K 50V	RN124	70041093	Chip Jumper		
CN225	70041529	Cap, Chip	1 μ F	Z 16V	RN125	70041464	Res, Chip	150 Ω	J 1/10W
CN226	70041328	Cap, Chip	100nF	Z 25V	RN126	70041380	Res, Chip	300 Ω	J 1/16W
CN228	24203100	Cap, Electrolytic	10 μ F	M 16V	RN127	70040335	Res, Chip	2.7k Ω	J 1/16W
CN229	70041130	Cap, Chip	470nF	Z 16V	RN128	24872132	Res, Chip	1.3k Ω	J 1/16W
CN230	70041130	Cap, Chip	470nF	Z 16V	RN130	70040354	Res, Chip	1k Ω	J 1/16W
CN231	70041130	Cap, Chip	470nF	Z 16V	RN131	24872101	Res, Chip	100 Ω	J 1/16W
CN232	70041130	Cap, Chip	470nF	Z 16V	RN132	24872333	Res, Chip	33k Ω	J 1/16W
CN233	70041529	Cap, Chip	1 μ F	Z 16V	RN133	24872333	Res, Chip	33k Ω	J 1/16W
CN234	70041529	Cap, Chip	1 μ F	Z 16V	RN134	24872273	Res, Chip	27k Ω	J 1/16W
CN237	70041328	Cap, Chip	100nF	Z 25V	RN135	24872273	Res, Chip	27k Ω	J 1/16W
CN238	24206339	Cap, Electrolytic	3.3 μ F	M 50V	RN137	70041096	Chip Jumper		
CN239	24815102	Cap, Chip	1000pF	K 50V	RN138	24872102	Res, Chip	1k Ω	J 1/16W
CN240	70041328	Cap, Chip	100nF	Z 25V	RN139	24872105	Res, Chip	1M Ω	J 1/16W
CN242	70041130	Cap, Chip	470nF	Z 16V	RN141	24872104	Res, Chip	100k Ω	J 1/16W
CN243	70041042	Cap, Electrolytic	10 μ F	X	RN142	24872472	Res, Chip	4.7k Ω	J 1/16W
CN244	70040530	Cap, Electrolytic	100 μ F	M 16V	RN144	24872103	Res, Chip	10k Ω	J 1/16W
CN245	70041130	Cap, Chip	470nF	Z 16V	RN145	24872104	Res, Chip	100k Ω	J 1/16W
CN246	24781330	Cap, Chip	33pF	J 50V	RN146	24872162	Res, Chip	1.6k Ω	J 1/16W
CN248	24781330	Cap, Chip	33pF	J 50V	RN147	24872102	Res, Chip	1k Ω	J 1/16W
CN253	24781330	Cap, Chip	33pF	J 50V	RN149	70041093	Chip Jumper		
CN254	24203100	Cap, Electrolytic	10 μ F	M 16V	RN150	70040358	Res, Chip	10k Ω	J 1/16W
CN255	24203100	Cap, Electrolytic	10 μ F	M 16V	RN151	24872102	Res, Chip	1k Ω	J 1/16W
CN256	24872101	Res, Chip	100 Ω	J 1/16W	RN152	24872103	Res, Chip	10k Ω	J 1/16W
CN257	24781330	Cap, Chip	33pF	J 50V	RN154	70041096	Chip Jumper		
CN260	24203100	Cap, Electrolytic	10 μ F	M 16V	RN201	24872101	Res, Chip	100 Ω	J 1/16W
CN261	24203100	Cap, Electrolytic	10 μ F	M 16V	RN202	24872331	Res, Chip	330 Ω	J 1/16W
CX001	24815102	Cap, Chip	1000pF	K 50V	RN203	24872221	Res, Chip	220 Ω	J 1/16W
CX002	24815102	Cap, Chip	1000pF	K 50V	RN205	24872123	Res, Chip	12k Ω	J 1/16W
CX003	70040262	Cap, Chip	100pF	J 50V	RN206	70041096	Chip Jumper		
CX004	24815561	Cap, Chip	560pF	K 50V	RN208	24872273	Res, Chip	27k Ω	J 1/16W
CX005	70040262	Cap, Chip	100pF	J 50V	RN209	24872332	Res, Chip	3.3k Ω	J 1/16W
CX006	24815561	Cap, Chip	560pF	K 50V	RN210	24872332	Res, Chip	3.3k Ω	J 1/16W
CX007	24815102	Cap, Chip	1000pF	K 50V	RN211	24872332	Res, Chip	3.3k Ω	J 1/16W
CX008	24815102	Cap, Chip	1000pF	K 50V	RN212	24872332	Res, Chip	3.3k Ω	J 1/16W
CX009	70040262	Cap, Chip	100pF	J 50V	RN213	24872102	Res, Chip	1k Ω	J 1/16W
CX010	24815561	Cap, Chip	560pF	K 50V	RN214	70041096	Chip Jumper		
CX011	70040262	Cap, Chip	100pF	J 50V	RN216	24872151	Res, Chip	150 Ω	J 1/16W
CX012	24815561	Cap, Chip	560pF	K 50V	RN217	24872102	Res, Chip	1k Ω	J 1/16W
CX102	70041328	Cap, Chip	100nF	Z 25V	RN218	24872102	Res, Chip	1k Ω	J 1/16W

LOCATION NUMBER	PART NUMBER	DESCRIPTION			LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RN220	24872223	Res, Chip	22k Ω	J 1/16W	IR001	70119971	IC	MC74HC4053N	
RN221	24872752	Res, Chip	7.5k Ω	J 1/16W			- TRANSISTORS -		
RN223	24872123	Res, Chip	12k Ω	J 1/16W	TR001	70011543	Transistor	2SC2458-Y	
RN224	24872912	Res, Chip	9.1k Ω	J 1/16W	TR003	70011543	Transistor	2SC2458-Y	
RN225	24872123	Res, Chip	12k Ω	J 1/16W	TR006	70011543	Transistor	2SC2458-Y	
RN226	24872912	Res, Chip	9.1k Ω	J 1/16W	TR008	70011543	Transistor	2SC2458-Y	
RN227	24872123	Res, Chip	12k Ω	J 1/16W	TR009	70011644	Transistor	2SC2458-Y	
RN228	24872912	Res, Chip	9.1k Ω	J 1/16W	TR010	70011543	Transistor	2SC2458-Y	
RN229	24872123	Res, Chip	12k Ω	J 1/16W			- COILS -		
RN230	24872912	Res, Chip	9.1k Ω	J 1/16W	LR020	70011204	Coil, Peaking		
RN231	24872123	Res, Chip	12k Ω	J 1/16W			- CAPACITORS -		
RN232	24872912	Res, Chip	9.1k Ω	J 1/16W	CR005	70041997	Cap, Ceramic	10nF	Z 50V
RN233	24872123	Res, Chip	12k Ω	J 1/16W	CR011	70041310	Cap, Electrolytic	47 μ F	M 10V
RN234	24872912	Res, Chip	9.1k Ω	J 1/16W	CR012	70042126	Cap, Ceramic	10nF	M 16V
RN235	24872473	Res, Chip	47k Ω	J 1/16W	CR020	70041981	Cap, Electrolytic	100 μ F	K 10V
RN236	24872473	Res, Chip	47k Ω	J 1/16W	CR021	70040047	Cap, Plastic	100nF	K 63V
RN239	24872101	Res, Chip	100 Ω	J 1/16W	CR031	70041999	Cap, Ceramic	22nF	K 25V
RN242	24872101	Res, Chip	100 Ω	J 1/16W			- RESISTORS -		
RN243	24872473	Res, Chip	47k Ω	J 1/16W	RR003	70040844	Res, Carbon	1k Ω	J 1/4W
RN244	24872473	Res, Chip	47k Ω	J 1/16W	RR020	70040844	Res, Carbon	1k Ω	J 1/4W
RN245	24872473	Res, Chip	47k Ω	J 1/16W	RR021	70040844	Res, Carbon	1k Ω	J 1/4W
RN246	24872473	Res, Chip	47k Ω	J 1/16W	RR022	70042393	Res	240 Ω	J 1/4W
RN247	70041096	Chip Jumper			RR023	70042017	Res, Carbon	150 Ω	J 1/4W
RN249	24872101	Res, Chip	100 Ω	J 1/16W	RR024	70040844	Res, Carbon	1k Ω	J 1/4W
RN251	24872621	Res, Chip	620 Ω	J 1/16W	RR025	70040842	Res, Carbon	470 Ω	J
RN252	24872101	Res, Chip	100 Ω	J 1/16W	RR026	70042394	Res	2.4k Ω	J 1/4W
RN253	24872473	Res, Chip	47k Ω	J 1/16W	RR027	70040844	Res, Carbon	1k Ω	J 1/4W
RN254	24872473	Res, Chip	47k Ω	J 1/16W	RR028	70041898	Res, Carbon	1.2k Ω	J 1/4W
RN255	70041096	Chip Jumper			RR029	70042029	Res, Carbon	4.7k Ω	J 1/4W
RN256	24872621	Res, Chip	620 Ω	J 1/16W	RR031	70040854	Res, Carbon	22k Ω	J 0.2W
RN261	70041096	Chip Jumper			RR032	70040852	Res, Carbon	10k Ω	J 1/4W
RN262	24872103	Res, Chip	10k Ω	J 1/16W	RR033	70040847	Res, Carbon	1.5k Ω	J
RN263	24872103	Res, Chip	10k Ω	J 1/16W	RR034	70040844	Res, Carbon	1k Ω	J 1/4W
RN264	24872103	Res, Chip	10k Ω	J 1/16W	JR101	70041665	Res, Carbon	5.6k Ω	J 1/4W
RN265	24872103	Res, Chip	10k Ω	J 1/16W			- MISCELLANEOUS -		
RX001	70040333	Res, Chip	100 Ω	J 1/8W	HR001	70012641	3DNR module		
RX002	24872101	Res, Chip	100 Ω	J 1/16W					
RX003	24872101	Res, Chip	100 Ω	J 1/16W	■0210M	70095275	P C Board Assy	KDB	
RX004	24872101	Res, Chip	100 Ω	J 1/16W			- INTEGRATED CIRCUITS -		
RX005	24872101	Res, Chip	100 Ω	J 1/16W	IK01	70012925	IC	TMP87CP71F-6699	
RX006	24872101	Res, Chip	100 Ω	J 1/16W			- TRANSISTORS -		
RX007	24872101	Res, Chip	100 Ω	J 1/16W	TK02	A6335580	Transistor, Chip	2SC2714-Y	
RX008	24872101	Res, Chip	100 Ω	J 1/16W	TK03	A6004020	Transistor, Chip	RN1402	
RX009	24872101	Res, Chip	100 Ω	J 1/16W	TK04	A6004010	Transistor, Chip	RN1401	
RX010	24872101	Res, Chip	100 Ω	J 1/16W	TK05	A6325549	Transistor	2SC2236-Y	
RX011	24872101	Res, Chip	100 Ω	J 1/16W			- DIODES -		
RX012	24872101	Res, Chip	100 Ω	J 1/16W	DK01	70011969	Diode, Zener	ZMM5.6V	
RX101	70041441	Res, Chip	75 Ω	J 1/10W	DK02	70010341	Diode	1SS226	
RX102	70041441	Res, Chip	75 Ω	J 1/10W	DK11	70012707	Diode, LED	TLN105B	
RX103	70041441	Res, Chip	75 Ω	J 1/10W	DK12	70012707	Diode, LED	TLN105B	
RX104	70041441	Res, Chip	75 Ω	J 1/10W	DK13	70012707	Diode, LED	TLN105B	
RX110	70040348	Res, Chip	100 Ω	J 1/16W			- CAPACITORS -		
RX111	70040348	Res, Chip	100 Ω	J 1/16W	CK01	70041690	Cap, Chip	30pF	J 50V
RX113	24872682	Res, Chip	6.8k Ω	J 1/16W	CK02	70041690	Cap, Chip	30pF	J 50V
RX114	24872102	Res, Chip	1k Ω	J 1/16W	CK03	70041376	Cap, Chip	10nF	Z 50V
RX115	24872103	Res, Chip	10k Ω	J 1/16W	CK04	70041376	Cap, Chip	10nF	Z 50V
RX120	70041096	Chip Jumper			CK05	70041376	Cap, Chip	10nF	Z 50V
RX124	70041093	Chip Jumper			CK06	70041376	Cap, Chip	10nF	Z 50V
RX907	70041096	Chip Jumper			CK07	24814223	Cap, Chip	2200pF	Z 50V
JN201	70041096	Chip Jumper			CK08	70040262	Cap, Chip	100pF	J 50V
JN203	70041096	Chip Jumper			CK09	70040243	Cap, Chip	82pF	J 50V
JN205	70041096	Chip Jumper			CK10	70041529	Cap, Chip	1 μ F	Z 16V
JN206	70041093	Chip Jumper			CK21	70040647	Cap, Electrolytic	47 μ F	M 10V
JN207	70041093	Chip Jumper			CK22	70040647	Cap, Electrolytic	47 μ F	M 10V
JN208	70041093	Chip Jumper			CK23	70041292	Cap, Electrolytic	100 μ F	M 6.3V
		- MISCELLANEOUS -					- RESISTORS -		
BN003	70012939	FFC			RK01	70040568	Res, Chip	220 Ω	J 1/8W
BN103	70060759	Phono Jack			RK02	70040350	Res, Chip	220 Ω	J 1/16W
BN104	70012358	Pin Jack			RK03	70040350	Res, Chip	220 Ω	J 1/16W
BX101	70010209	Socket			RK04	70040350	Res, Chip	220 Ω	J 1/16W
BX102	70012102	Scart 21P			RK05	70040373	Res, Chip	4.7k Ω	J 1/16W
QN201	70012642	Crystal	18.432MHz		RK09	70041352	Res, Chip	4.7k Ω	J 1/8W
					RK10	70040373	Res, Chip	4.7k Ω	J 1/16W
■0094M	70095280	P C Board Assy	3D DNR		RK101	70040391	Chip Jumper		
		- INTEGRATED CIRCUITS -			RK102	70040391	Chip Jumper		

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RK109	70040391	Chip Jumper		
RK13	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK14	70041352	Res, Chip	4. 7kΩ	J 1/8W
RK15	70041198	Res, Chip	47kΩ	J 1/8W
RK16	70041198	Res, Chip	47kΩ	J 1/8W
RK22	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK23	70041352	Res, Chip	4. 7kΩ	J 1/8W
RK24	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK27	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK28	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK29	70041709	Res, Chip	2. 2kΩ	G 1/10W
RK30	70040358	Res, Chip	10kΩ	J 1/16W
RK31	70040391	Chip Jumper		
RK32	70040337	Res, Chip	270Ω	J 1/16W
RK33	70040340	Res, Chip	47Ω	J 1/16W
RK34	70040391	Chip Jumper		
RK35	70040391	Chip Jumper		
RK36	70041138	Res, Chip	5. 6kΩ	J 1/10W
RK37	70040341	Res, Chip	10Ω	J 1/16W
RK40	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK41	70041171	Res, Chip	1. 2kΩ	J 1/10W
RK44	70011425	Res, Chip	3kΩ	
RK45	70011425	Res, Chip	3kΩ	
RK46	70011425	Res, Chip	3kΩ	
RK47	70011425	Res, Chip	3kΩ	
RK48	70011425	Res, Chip	3kΩ	
RK51	70040354	Res, Chip	1kΩ	J 1/16W
RK56	70011426	Res, Chip	2kΩ	
RK60	70040361	Res, Chip	27kΩ	J 1/16W
RK61	70040361	Res, Chip	27kΩ	J 1/16W
RK62	70040568	Res, Chip	220Ω	J 1/8W
RK63	70040358	Res, Chip	10kΩ	J 1/16W
		- MISCELLANEOUS -		
GK01	70012214	FIP	7-MT-171GNK	
QK01	70010937	Resonator	8MHz	
SK05	23344094	Push Switch		
SK06	23344094	Push Switch		
SK10	23344094	Push Switch		
ZK01	70012418	F. U.	GP1U281X	
■0212M	70095276	P C Board Assy	FCB	
		- INTEGRATED CIRCUITS -		
ICM02	70011889	IC	LA6462M	
		- TRANSISTORS -		
TK06	A6004020	Transistor, Chip	RN1402	
TK07	A6004020	Transistor, Chip	RN1402	
TK08	A6004020	Transistor, Chip	RN1402	
		- DIODES -		
DK14	70052221	Diode, LED	LTL-10CHJ	
DM01	70010341	Diode	1SS226	
		- CAPACITORS -		
CK11	70041707	Cap, Chip	1nF	Z 50V
CK12	70041707	Cap, Chip	1nF	Z 50V
CM27	70041472	Cap, Chip	1nF	K 50V
CM28	24630852	Cap, Electrolytic	22μF	M 16V
CM29	24206338	Cap, Electrolytic	0. 33μF	M 50V
CM30	24781151	Cap, Chip	150pF	J 50V
CM31	24781151	Cap, Chip	150pF	J 50V
CM32	70041038	Cap, Electrolytic	10μF	M 16V
		- RESISTORS -		
RK103	70040391	Chip Jumper		
RK52	70040354	Res, Chip	1kΩ	J 1/16W
RK53	70040354	Res, Chip	1kΩ	J 1/16W
RK66	70040350	Res, Chip	220Ω	J 1/16W
RK67	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK68	70040350	Res, Chip	220Ω	J 1/16W
RK69	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK73	70040374	Res, Chip	8. 2kΩ	J 1/16W
RK82	70041441	Res, Chip	75Ω	J 1/10W
RK83	70040354	Res, Chip	1kΩ	J 1/16W
RK84	70040354	Res, Chip	1kΩ	J 1/16W
RM24	70040358	Res, Chip	10kΩ	J 1/16W
RM26	70040359	Res, Chip	15kΩ	J 1/16W
RM28	70040359	Res, Chip	15kΩ	J 1/16W
RM29	70041173	Res, Chip	100kΩ	J 1/10W

LOCATION NUMBER	PART NUMBER	DESCRIPTION		
RM30	70040358	Res, Chip	10kΩ	J 1/16W
RM31	70040359	Res, Chip	15kΩ	J 1/16W
RM32	70041173	Res, Chip	100kΩ	J 1/10W
		- MISCELLANEOUS -		
BE06	70011981	Phono Jack		
BE07	70011627	Pin Jack		
BE08	70012611	Pin Jack		
BK01B	70011839	Connector, 1. 25mm		
BN006	70011350	Phono Jack		
SK01	70031729	Switch		
SK02	70031729	Switch		
SK03	70031729	Switch		
SK04	70031729	Switch		
SK09	70031729	Switch		
SK32	70011993	Slide Switch	1C3P	
■0213M	70095277	P C Board Assy	JSB	
		- RESISTORS -		
RK11	70040373	Res, Chip	4. 7kΩ	J 1/16W
RK12	70040373	Res, Chip	4. 7kΩ	J 1/16W
		- MISCELLANEOUS -		
SK41	70012649	Switch(JogShuttle)		

SPECIFICATIONS

SYSTEM

Format	: VHS standard
Recording system	: Rotary, 2-head helical scan system
Video heads	: 4 heads
Video signal system	: CCIR: 625 lines, 50 fields, PAL colour signal, NTSC colour, 525 lines
Tape speed	: SP : 23.39 mm/s (PAL) SP : 33.35 mm/s (NTSC) LP : 11.70 mm/s (PAL) SLP : 11.12 mm/s (NTSC)
Recording time	: SP : 240 minutes with E240 cassettes (PAL), LP : 480 minutes with E240 cassettes (PAL)
Winding time	: Approx. 110 seconds with E180 cassettes
Dimensions	: 430 (W) × 92.5 (H) × 315 (D) mm
Mass	: 4.3 kg
Operating temperature	: +5 to +40°C
Operating humidity	: Less than 80% RH
Mains power	: 230/240 V AC, 50 Hz
Power consumption	: 20 W (in operation) < 6 W (Normal standby) < 3 W (ECO.MODE standby)

CONNECTORS

Aerial input	: 75 Ω coaxial
Aerial output	: 75 Ω coaxial
Video input	: AUDIO/VIDEO SCART socket, 1.0 V(p-p), 75 Ω LINE IN 2 VIDEO Phono type jack, 1.0 V(p-p), 75 Ω
Audio input	: AUDIO/VIDEO SCART socket, 308 mV(rms), more than 10 kΩ LINE IN 2 AUDIO Phono type jacks, 308 mV(rms), more than 47 kΩ
Video output	: AUDIO/VIDEO SCART socket, 1.0 V(p-p), 75 Ω
Audio output	: AUDIO/VIDEO SCART socket, 308 mV(rms), less than 1.0 kΩ AUDIO OUT Phono type jacks, 308 mV(rms), less than 4.7 kΩ

VIDEO

Signal-to-noise ratio	: More than 43 dB (SP tape speed/PAL)
-----------------------	---------------------------------------

AUDIO

Signal-to-noise ratio	: More than 42 dB (SP tape speed/PAL/normal mono)
Frequency range	: 20 Hz to 20 kHz (Hi-Fi mode)
Dynamic range	: More than 90 dB (Hi-Fi mode)
Audio track	: 1 track (Normal-mono), 2 channels (Hi-Fi sound)

TIMER

Clock	: 24-hour digital indication
No. of events	: 6 events 1 month

TUNER

System	: Frequency synthesizer
Channel coverage	: PAL I VHF: A – J, 11, 13, E2 – E12 UHF: E21 – E69 CATV: X, Y, Z, S1 – S41, 1 – 53 (48MHz to 464MHz, 8MHz steps)
Stereo	: NICAM-I
RF converter	: UHF channel 21 – 69, adjustable, System-I

ACCESSORIES

Aerial cable...1	Remote controller...1	Batteries (R03)...2	Power cord...1
------------------	-----------------------	---------------------	----------------

Designs and specifications are subject to change without notice.

TOSHIBA VIDEO PRODUCTS PTE. LTD.
456 ALEXANDRA ROAD, #07-01/02 NOL BUILDING SINGAPORE 119962